


EPSON

Ink Jet Printer

EPSON *Stylus*™ COLOR 800



User's Guide

Where to Find Information

This User's Guide

Provides you with all the information you need to use your EPSON Stylus COLOR 800 and consumable products, from setting up to troubleshooting. If you use Microsoft® Windows NT®, see the Windows NT-based software users guide.

If you use DOS, see Appendix A to get information on installing the printer software, changing the print settings, and maintaining the printer using the control panel. Appendix A also may be useful for Windows and Macintosh users.

If you encounter problems with the printer, see Chapter 10, “Troubleshooting.”

Online Help

Provides you with detailed information and instructions on the Windows printer software that controls your printer. See Chapter 4 for information on accessing online help.

Color Guide

Explains the ABC's of color printing and shows you how to get impressive results from your printer.

Customer Support

Contact Customer Support if your printer is not operating properly and you cannot solve the problem with the troubleshooting information in this guide and online help. See “Contacting Customer Support” in Chapter 10.

EPSON Stylus™ COLOR 800

Color Ink Jet Printer

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of SEIKO EPSON CORPORATION. The information contained herein is designed only for use with this EPSON printer. EPSON is not responsible for any use of this information as applied to other printers.

Neither SEIKO EPSON CORPORATION nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with SEIKO EPSON CORPORATION's operating and maintenance instructions.

SEIKO EPSON CORPORATION shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original EPSON Products or EPSON Approved Products by SEIKO EPSON CORPORATION.

EPSON and EPSON ESC/P are registered trademarks and EPSON ESC/P 2 and EPSON Stylus are trademarks of SEIKO EPSON CORPORATION.

Microsoft and Windows are registered trademarks of Microsoft Corporation.

General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. EPSON disclaims any and all rights in those marks.

Copyright © 1996 by SEIKO EPSON CORPORATION, Nagano, Japan.



Printed on Recycled Paper.

User's Guide

Declaration of Conformity

According to ISO/IEC Guide 22 and EN 45014

Manufacturer: SEIKO EPSON CORPORATION
Address: 3-5, Owa 3-chome, Suwa-shi,
Nagano-ken 392 Japan

Representative: EPSON EUROPE B.V.
Address: Prof. J. H. Bavincklaan 5 1183
AT Amstelveen
The Netherlands

Declares that the Product:

Product Name: Ink Jet Printer
Type Name: EPSON Stylus COLOR 800
Model: P930A

Conforms to the following Directive(s) and Norm(s):

Directive 89/336/EEC:

EN 55022 Class B
EN 50082-1
IEC 801-2
IEC 801-3
IEC 801-4
EN 61000-3-2
EN 61000-3-3

Directive 73/23/EEC:

EN 60950

October 1996

M. Hamamoto
President of EPSON EUROPE B.V.

Contents

Safety Instructions

Important Safety Instructions	1
A few precautions	2
ENERGY STAR Compliance	3
For United Kingdom Users	4
Warnings, Cautions, and Notes	5

Chapter 1 Getting to Know Your Printer

Printer Parts and Control Panel Functions	1-2
System Requirements	1-4
When using your printer with a PC	1-4
When using your printer with a Macintosh	1-5
Options and Consumable Products	1-6
Options	1-6
Consumable products	1-8

Chapter 2 Getting Started

Unpacking the Printer	2-2
Attaching the Paper Support	2-3
Choosing a Place for the Printer	2-3
Using a printer stand	2-4
Plugging in the Printer	2-5
Installing the Ink Cartridges	2-6
Connecting the Printer to Your PC	2-12
Installing the Printer Software in Your PC	2-13
Installing in Windows 95	2-14
Installing in Windows 95 (using plug-and-play)	2-16
Installing in Windows 3.1	2-20

Connecting the Printer to Your Macintosh	2-22
Using the built-in serial interface	2-22
Using an optional EPSON interface card	2-23
Installing the Printer Software in Your Macintosh	2-24
Installing the printer software	2-24
Printer software components	2-26
Assigning a name to the printer	2-28
Using the Chooser to select your printer	2-28
Using the AppleTalk connection	2-31

Chapter 3 Starting to Print with Windows

Loading Paper	3-2
Printing	3-5

Chapter 4 Using the Printer Software for Windows

Introducing the Printer Software Functions	4-2
Accessing the Printer Software	4-2
From Windows applications	4-3
From Windows 95	4-3
From Windows 3.1	4-4
Using the Automatic Setting	4-5
Using the Predefined Settings	4-6
Customizing the Print Settings	4-8
Making the Media Type Setting	4-10
Using EPSON Printer Utilities	4-12
EPSON Status Monitor	4-13
Nozzle Check	4-14
Head Cleaning	4-14
Print Head Alignment	4-14

Checking Printer Status	4-15
Understanding the EPSON Spool Manager	4-15
Understanding the Despooler	4-16
Getting Information Through Online Help	4-17
From Windows applications	4-17
From Windows 95	4-17
From Windows 3.1	4-17

Chapter 5 Starting to Print with Macintosh

Loading Paper	5-2
Printing	5-5

Chapter 6 Using the Printer Software for Macintosh

Introducing the Printer Software Functions	6-2
Using the Automatic Setting	6-2
Using the Predefined Settings	6-5
Customizing the Print Settings	6-8
Making your settings	6-8
Saving your settings	6-9
Choosing your settings	6-10
Modifying visual effects	6-10
Controlling the printing quality	6-14
Making the Color and Halftoning settings	6-17
Changing the Paper Size	6-18
Defining a Custom Paper Size	6-19
Using EPSON Printer Utilities	6-21
EPSON StatusMonitor	6-22
Nozzle Check	6-23
Head Cleaning	6-24
Print Head Alignment	6-24
Using the EPSON Monitor2 Utility	6-25

Chapter 7 Printing on Special Paper

Loading Special Paper and Other Media	7-2
About special media cleaning sheets	7-5
Loading Envelopes	7-6
Loading Transparencies	7-7
Using EPSON Photo Paper (S041134)	7-8
Loading	7-8
Removing the perforated margins	7-10
Storing EPSON Photo Paper	7-10

Chapter 8 Using Optional Interfaces

Available Interfaces	8-2
Installing Optional Interfaces	8-3
Using the serial interface card (C82305*/C82306*)	8-5

Chapter 9 Maintenance and Transportation

Replacing an Ink Cartridge	9-2
Printing with an empty color ink cartridge	9-8
Cleaning the Printer	9-9
Transporting the Printer	9-10

Chapter 10 *Troubleshooting*

Diagnosing the Problem	10-2
Error indicators	10-2
Status Monitor	10-4
Self testing	10-5
Hex dump mode	10-7
Problems and Solutions	10-8
Power supply	10-8
Operation	10-9
Paper handling	10-16
Printing quality	10-19
Increasing the Print Speed	10-27
Cleaning the Print Heads	10-29
Aligning the Print Heads	10-32
Ink Cartridge Problems	10-33
Contacting Customer Support	10-35
For United Kingdom and the Republic of Ireland users	10-35
For Australian users	10-38
For Hong Kong and Singapore users	10-40
For Philippines users	10-41

Appendix A *Using the Printer with DOS*

Installing the Printer Software for DOS Programs	A-2
Changing the Print Settings	A-2
Using the default settings	A-4
Changing the default settings	A-7
Selecting fonts	A-8
Cleaning the Print Heads	A-10
Aligning the Print Heads	A-11
Using the print head alignment utility	A-12
Using the printer's control panel buttons	A-13
Using Power-On Functions	A-14

Appendix B Tips for Color Printing

Basics of Color B-2
Image Resolution and Image Size B-5
Basics of Color Documents B-7

Appendix C Specifications

Technical Specifications C-2
 Printing C-2
 Paper C-4
 Ink cartridges C-7
 Mechanical C-8
 Electrical C-9
 Environmental C-9
 Safety approvals C-10
Interface Specifications C-10
 Parallel interface C-10
 Serial interface C-11
 Initialization C-12
 Default settings C-13
Command List C-14
 ESC/P 2 control codes C-14
 IBM X24E emulation control codes C-15
Character Tables C-16
 International character sets C-20
 Characters available with ESC (^ command C-21

Glossary

Index

Safety Instructions

Important Safety Instructions

Read all of these instructions and save them for later reference. Follow all warnings and instructions marked on the printer.

- Do not place the printer on an unstable surface or near a radiator or heat source.
- Place the printer on a flat surface. The printer will not operate properly if it is tilted or at an angle.
- Do not block or cover the openings in the printer's cabinet. Do not insert objects through the slots.
- Use only the type of power source indicated on the printer's label.
- Connect all equipment to properly grounded power outlets. Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off.
- Do not use a damaged or frayed power cord.
- If you use an extension cord with the printer, make sure the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.
- Unplug the printer before cleaning. Clean with a damp cloth only. Do not spill liquid on the printer.
- Except as specifically explained in this guide, do not attempt to service the printer yourself.

- ❑ Unplug the printer and refer servicing to qualified service personnel under the following conditions:

If the power cord or plug is damaged; if liquid has entered the printer; if the printer has been dropped or the cabinet damaged; if the printer does not operate normally or exhibits a distinct change in performance. Adjust only those controls that are covered by the operating instructions.

- ❑ If you plan to use the printer in Germany, observe the following:

To provide adequate short-circuit protection and over-current protection for this printer, the building installation must be protected by a 16 Amp circuit breaker.

Bei Anschluß des Druckers an die Stromversorgung muß sichergestellt werden, daß die Gebäudeinstallation mit einem 16 A-Überstromschalter abgesichert ist.

A few precautions

Even if you are familiar with other types of printers, be sure to read through the following list of precautions before operating your ink jet printer.

- ❑ Do not put your hand inside the printer or touch the cartridge during printing.
- ❑ Under normal circumstances, ink will not come out of the cartridge. If it does get on your skin, wash it off with soap and water. If it gets in your eyes, flush them immediately with water.
- ❑ Keep ink cartridges out of the reach of children.
- ❑ Do not dismantle the ink cartridges or try to refill them. This could result in damage to the print heads.

- ❑ Once you install an ink cartridge, do not open the clamp or remove the cartridge except to replace it with a new one. The cartridge may become unusable otherwise.
- ❑ Install the ink cartridge immediately after you remove it from its package. Leaving the cartridge unpacked for a long time before use may result in reduced print quality.
- ❑ Do not use an ink cartridge beyond the date printed on the cartridge carton. For best results, use up the ink cartridges within six months of installing them.
- ❑ Do not shake an ink cartridge; this can cause leakage.
- ❑ Always turn the printer off using the ⏻ power button. When this button is pressed, the ⏻ power light flashes briefly then goes out. Do not unplug the printer or turn off the power to the outlet until the ⏻ power light is off.
- ❑ Before transporting the printer, make sure the print heads are capped in the far right position and the ink cartridges are in place.

ENERGY STAR Compliance



As an ENERGY STAR Partner, EPSON has determined that this product meets the ENERGY STAR guidelines for energy efficiency.

The International ENERGY STAR Office Equipment Program is a voluntary partnership with the computer and office equipment industry to promote the introduction of energy-efficient personal computers, monitors, printers, fax machines, and copiers in an effort to reduce air pollution caused by power generation.

For United Kingdom Users

Use of options

Epson (UK) Limited shall not be liable against any damages or problems arising from the use of any options or consumable products other than those designated as Original EPSON Products or EPSON Approved Products by Epson (UK) Limited.

Safety information



Warning: *This appliance must be earthed. Refer to rating plate for voltage and check that the appliance voltage corresponds to the supply voltage.*

Important: *The wires in the mains lead fitted to this appliance are coloured in accordance with the following code:*

Green and yellow — Earth

Blue — Neutral

Brown — Live

If you have to fit a plug:

As the colours of the mains lead of this appliance may not match coloured markings used to identify the terminals in a plug, please proceed as follows:

The green and yellow wire must be connected to the terminal in the plug which is marked with the letter E or the Earth symbol (\perp).

The blue wire must be connected to the terminal in the plug marked with the letter N.

The brown wire must be connected to the terminal in the plug marked with the letter L.

If damage occurs to the plug, replace the cord set or consult a qualified electrician.

Replace fuses only with a fuse of the correct size and rating.

Warnings, Cautions, and Notes



Warnings must be followed carefully to avoid bodily injury.









Cautions must be observed to avoid damage to your equipment.

Notes contain important information and useful tips on the operation of your printer.

Getting to Know Your Printer






Printer Parts and Control Panel Functions	1-2
System Requirements	1-4
When using your printer with a PC	1-4
When using your printer with a Macintosh	1-5
Options and Consumable Products	1-6
Options	1-6
Consumable products	1-8

Buttons

Buttons	Function
 load/eject	Loads and ejects paper. Starts charging ink (after you finish the ink cartridge replacement procedure).
 power	Turns the printer on and off. Clears the print buffer if pressed twice while the power is on.
 black print head cleaning	Cleans the black print head if pressed for about three seconds. Starts the black ink cartridge replacement procedure if pressed while the  ink out light is flashing or on. This button is located inside the printer cover.
 color print head cleaning	Cleans the color print head if pressed for about three seconds. Starts the color ink cartridge replacement procedure if pressed while the  ink out light is flashing or on. This button is located inside the printer cover.

Lights

The lights on the front of the printer indicate the printer status, such as receiving data, paper jam, or ink is low. The following table describes what the lights mean.

				Printer Status
-	-	-	◐	Receiving data, replacing an ink cartridge, charging ink, or cleaning print heads.
○	-	-	-	Paper out. Load paper in the sheet feeder; then press the  load/eject button to resume printing.
◐	●	●	-	Paper jam. Turn off the printer and gently pull all the paper out of the printer.
-	◐	-	-	Ink low. The black ink cartridge is nearly empty. Obtain a replacement black ink cartridge (S020108).
-	○	-	-	Ink out. The black ink cartridge is empty. Replace the black ink cartridge (S020108).
-	-	◐	-	Ink low. The color ink cartridge is nearly empty. Obtain a replacement color ink cartridge (S020089).
-	-	○	-	Ink out. The color ink cartridge is empty. Replace the color ink cartridge (S020089).

○ = on, ● = off, ◐ = flashing, - = irrelevant

System Requirements

When using your printer with a PC

To use your printer, you need Microsoft Windows 3.1, Windows for Workgroups, Windows 95, Windows NT, or DOS; a shielded, twisted-pair parallel cable. For system requirements and details on using the printer software with Windows NT, see the *Windows NT 3.51/4.0 Printer software User's Guide*.

To install and use the printer software (printer driver and utilities) included on the CD-ROM or floppy disk packed with your printer, the following is required:

Minimum system	Recommended system
80386/16 MHz processor	Pentium processor
16MB RAM	32MB RAM
20MB hard disk space	More than 50MB free disk space
VGA monitor	VGA or better monitor

Your computer dealer can help you update your system if it does not meet these requirements.

When using your printer with a Macintosh

The following are the hardware and system requirements that must be met to use this printer with a Macintosh.

Applicable computer models (as of July 1, 1996)

Macintosh LC II, LC III, LC475, LC520, LC575, LC630
 Macintosh IIcx, IIci, IIsi, IIvi, IIvx
 Macintosh Quadra Series
 Macintosh Centris Series
 Macintosh PowerBook™ Series (excluding PowerBook 100)
 Macintosh PowerBook Duo Series
 Macintosh Performa Series
 Power Macintosh Series

Interface cables

To use your printer with a Macintosh, you need a standard Apple System Peripheral-8 cable (8-pin mini-circular connector) or equivalent.

Environment

Minimum system	Recommended system
System 7.1	System 7.5 or later
3MB of available memory	8MB or more of available memory

Note:

- ❑ *The amount of available memory varies according to the number and kind of applications that are open. To see how much memory is available, choose About This Macintosh from the Apple menu and refer to the memory size (listed in kilobytes) under “Largest Unused Block” (1,024K=1MB).*
- ❑ *The memory requirements above are for printing on Letter size paper. These requirements may vary depending on the size of the paper, the type of application you are using, and the complexity of the document you want to print.*
- ❑ *You need an additional 1MB of available memory when background printing is turned on.*

In addition to these system and memory requirements, you also need 6MB of free hard disk space to install your printer software. To print, you need extra hard disk space amounting to about double the size of the file you want to print.

Options and Consumable Products

Options

The following options are available for use with your printer.

Interface cards

A number of optional interfaces are available to supplement the printer's built-in parallel and serial interfaces. See Chapter 8 for more information.

If you are not sure whether you need an optional interface or if you want to know more about interfaces, contact your dealer.

Serial Interface Card C82305*/C82306*
32KB Serial Interface Card C82307*/C82308*
32KB Parallel Interface Card C82310*
32KB IEEE-488 Interface Card C82313*
Twinax Interface Card C82315*
Coax Interface Card C82314*
LocalTalk™ Interface Card C82312*
Ethernet Interface Card C82331*
Type B Bi-directional Parallel Interface Card C82345*

Note:

The asterisk is a substitute for the last digit of the product number, which varies by country.

Interface cables

EPSON supplies several types of interface cables. You can use any interface cable that meets the specifications listed below. See your computer manual for any additional requirements.

Parallel Interface Cable (shielded) C83602* from
D-SUB 25-pin (computer) to Amphenol 57 (printer)

Serial Interface Cable C83603*/C83604* from
D-SUB 25-pin (computer) to D-SUB 25-pin (printer)

Serial Interface Cable C83605*/C83606* from
D-SUB 9-pin (computer) to D-SUB 25-pin (printer)

Note:

The asterisk is a substitute for the last digit of the product number, which varies by country.

Consumable products

Ink cartridges

Black ink cartridge	S020108
Color ink cartridge	S020089

EPSON special media

Most plain paper works well in your printer. In addition, paper specifically designed for ink jet printers such as EPSON's *360 dpi Ink Jet Paper* will meet most high-quality printing needs.

EPSON 360 dpi Ink Jet Paper (A4)	S041059
	S041025
EPSON 360 dpi Ink Jet Paper (Letter)	S041060
EPSON Photo Quality Ink Jet Paper (A4)	S041061
	S041026
EPSON Photo Quality Ink Jet Paper (Letter)	S041062
EPSON Photo Quality Ink Jet Paper (Legal)	S041067
EPSON Photo Quality Ink Jet Card (A6)	S041054
EPSON Photo Quality Ink Jet Card (5 × 8 in.)	S041121
EPSON Photo Quality Ink Jet Card (8 × 10 in.)	S041122
EPSON Photo Quality Glossy Film (A4)	S041071
EPSON Photo Quality Glossy Film (Letter)	S041072
EPSON Photo Quality Glossy Film (A6)	S041107
EPSON Photo Quality Glossy Paper (A4)	S041126
EPSON Photo Quality Glossy Paper (Letter)	S041124
EPSON Ink Jet Transparencies (A4)	S041063
EPSON Ink Jet Transparencies (Letter)	S041064
EPSON Photo Quality Self Adhesive Sheet (A4)	S041106
EPSON Photo Paper (4 × 6 in.)	S041134


Note:

- The availability of special media varies by country.*
- Ink jet printers are particularly sensitive to the condition of your paper. Keep unused paper in its original packaging and store it in a cool, dry place.*

Unpacking the Printer	2-2
Attaching the Paper Support	2-3
Choosing a Place for the Printer	2-3
Using a printer stand	2-4
Plugging in the Printer	2-5
Installing the Ink Cartridges	2-6
Connecting the Printer to Your PC	2-12
Installing the Printer Software in Your PC	2-13
Installing in Windows 95	2-14
Installing in Windows 95 (using plug-and-play)	2-16
Installing in Windows 3.1	2-20
Connecting the Printer to Your Macintosh	2-22
Using the built-in serial interface	2-22
Using an optional EPSON interface card	2-23
Installing the Printer Software in Your Macintosh	2-24
Installing the printer software	2-24
Printer software components	2-26
Assigning a name to the printer	2-28
Using the Chooser to select your printer	2-28
Using the AppleTalk connection	2-31

Unpacking the Printer

Your printer box should contain a CD-ROM, which includes the printer software that runs your printer, and the following items:




In some locations, the power cord comes attached to the printer. The shape of the AC plug varies by country; be sure the plug included is the right shape for your location.

Remove all protective materials packed with your printer before you set it up and turn on the power. Follow the instructions inserted with the printer to remove these materials. Save all packaging and protective materials in case you need to transport the printer later.

Attaching the Paper Support

Insert the paper support into the slots at the rear of the printer as shown below.



Note:

To print on transparencies, you need to reposition the paper support as described in “Loading Transparencies” in Chapter 7.

Choosing a Place for the Printer

Follow the guidelines listed below when placing your printer.

- Place the printer on a flat, stable surface. The printer will not operate properly if it is tilted or at an angle.
- Place the printer close enough to the computer for the interface cable to reach it easily.
- Leave adequate room for easy operation and maintenance.
- Leave enough room on the table at the front of the printer to lower the output tray.

- ❑ Avoid using or storing the printer in places subject to rapid changes in temperature and humidity. Also keep it away from direct sunlight, strong light, or heat sources.
- ❑ Avoid places subject to shocks and vibrations.
- ❑ Place the printer near a wall outlet where the plug can be easily unplugged.

Note for French-speaking users:

Placez l'imprimante près d'une prise de contact où la fiche peut être débranchée facilement.


- ❑ Avoid electrical outlets controlled by wall switches or automatic timers. Also, avoid outlets on the same circuit as large motors or other appliances that can cause fluctuations in line voltage.
- ❑ Keep the entire computer system away from potential sources of electromagnetic interference, such as loudspeakers or the base units of cordless telephones.
- ❑ Use a grounded power outlet; do not use an adapter plug.


Using a printer stand

When using a printer stand, note the following:

- ❑ Use a stand that can support at least 15.0 kg (33.2 lb).
- ❑ Never use a stand that tilts the printer. The printer should always be kept level.

Plugging in the Printer

1. Make sure that the printer is turned off. It is off when the  power button protrudes slightly from the surface of the control panel.



2. Check the label on the back of the printer to make sure the voltage required by the printer matches that of the electrical outlet you will be plugging it into. Also, make sure that you have the correct power cable for your power source.



Caution:

It is not possible to change the printer's voltage. If the rated voltage and your outlet voltage do not match, contact your dealer for assistance. Do not plug in the power cord.

3. If the power cord is not attached to the printer, connect it to the AC inlet on the back of the printer.
4. Plug the power cord into a properly grounded electrical outlet.

Installing the Ink Cartridges



Warning:


The ink cartridges are self-contained units. Under ordinary use, ink will not leak from a cartridge. If ink does get on your hands, wash them thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water.


Install the ink cartridges as follows:


Note:




Only open an ink cartridge package just before you install the cartridge, or the ink may dry up.


1. Lower the output tray at the front of the printer; then, holding the tab on the cover, open the printer cover.



2. Turn on the printer by pressing the  power button.





The print heads move slightly to the left, which is the black ink cartridge install position (color ink cartridge installation begins in step 7). The  and  ink out lights come on and the  power light flashes.



Caution:

Do not move the print heads by hand. Otherwise you may damage the printer.


3. Lift up the black ink cartridge clamp, which is marked with a  symbol.



4. Open the black ink cartridge package that came with your printer. Next, remove only the yellow tape seal from the cartridge as shown below.

Note:

To ensure that the ink charging process is completed properly, use the ink cartridge packed with your printer the first time you install the ink cartridges.




black ink cartridge
(S020108)

color ink cartridge
(S020089)




Caution:

- You must remove the yellow tape seals from the cartridges. If you attempt to print using a cartridge with this tape seal still attached, the cartridge may become unusable.*
 - Do not remove the whole tape seal (especially the white portion) from the top of the cartridge. Remove only the yellow portion.*
 - Do not remove the tape seals from the bottom of the cartridges; otherwise, ink will leak.*
5. Lower the ink cartridge into the ink cartridge holder with the label face-up and the arrow mark pointing to the rear.





6. Press the clamp down until it locks in place.



Caution:


Once you install the ink cartridges, do not open their clamps again until you replace the cartridges. Otherwise, the cartridges may become unusable.


Installation instructions for the color ink cartridge follow. If either of the cartridges is not installed, the printer will not work.

7. Press the  cleaning button. The printer moves the print heads to the color ink cartridge installation position. The clamp that secures the color ink cartridge is marked with a  symbol.





Caution:


Do not move the print heads by hand. Press the  cleaning button to move them to the color ink cartridge installation position. Otherwise you may damage the printer.




- Lift up the color ink cartridge clamp. Install the color ink cartridge as described in steps 4 to 6, substituting “color ink cartridge” for “black ink cartridge” where appropriate. Then go to step 9 to complete the ink cartridge installation.



- Press the  load/eject button then close the printer cover. The printer moves the print heads and begins charging the ink delivery system.





Note:

Even if you do not press the  load/eject button, the printer moves the print heads and begins the ink charging process about 60 seconds after you install the ink cartridges.

The ink charging process takes several minutes to complete, during which time the printer produces a variety of mechanical sounds. These sounds are normal. When the ink delivery system has been charged, the print heads return to their home position.



Caution:

During the ink charging process, the  power light flashes. Never turn off the printer while the  power light is flashing.

The number of pages a black ink cartridge can print varies according to the amount of text and graphics you print. The life of a color ink cartridge depends on the amount and the number of colors used in your documents.

Note:

When ink runs out, see “Replacing an Ink Cartridge” in Chapter 9.


Now you are ready to connect the printer to your computer. To connect the printer to your PC, see the following section. To connect it to your Macintosh, see page 2-21.

Connecting the Printer to Your PC

Connecting the printer to your computer using the built-in parallel interface requires a shielded, twisted-pair parallel cable. To connect the printer to a Macintosh, see page 2-21.

Follow the steps below to connect the printer to your computer:

1. Make sure both the printer and computer are turned off.
2. Plug the cable connector securely into the printer's interface connector. Then squeeze the wire clips together until they lock in place on both sides. If your cable has a ground wire, connect it to the ground connector below the interface connector.



3. Plug the other end of the cable into the computer's parallel interface. If there is a ground wire at the computer end of the cable, connect it to the ground connector at the back of the computer.

Now see the next section for instructions on installing the printer software. You must install the printer software before using your printer.

Installing the Printer Software in Your PC

After connecting the printer to your computer, install the Windows printer software. This software is included in the “Printer Software for EPSON Stylus™ COLOR 800” CD-ROM shipped with your printer. For installation instructions for the NT-based printer software, see the *Windows NT 3.51/4.0 Printer Software User’s Guide*.

Your printer software includes:

- ❑ **Printer driver**
The printer driver gives you complete control over your printer. With it, you can make settings such as Print Quality, Media Type, and Paper Size.
- ❑ **Utilities**
The Status Monitor utility allows you to check the current status of your printer. The Nozzle Check, Head Cleaning, and Print Head Alignment utilities help you to keep your printer in top operating condition.
- ❑ **EPSON folder or program group**
The EPSON folder (Windows 95) or program group (Windows 3.1) contains the EPSON Stylus COLOR 800 Help, Spool Manager 4, and EPSON ReadMe files. Help gives you instant on-screen access to detailed information and instructions on how to use your printer and printer software, Spool Manager 4 provides you with extra control over the printing process, and ReadMe contains the most up-to-date information available regarding your printer and printer software.

If you are using the floppy disk version of the software, before you begin installation, make a backup copy of the EPSON printer software disk. If you wish to make a floppy disk version of the printer software on your CD-ROM, you can use the Driver disk creation utility included on the CD. See page 2-16 for Windows 95, or page 2-19 for Windows 3.1.

Installing in Windows 95

Follow the steps below to install the printer software in Windows 95.

1. Make sure Windows 95 is running and the printer is off.
2. Insert the printer software CD shipped with your printer in the CD-ROM drive. Click Install in the dialog box that appears, shown below.



If this dialog box does not appear when you insert the printer software CD, double-click the My Computer icon, then double-click the CD-ROM drive icon (or floppy disk drive icon if using the floppy disk version). If the dialog box shown above still does not appear, double-click the Setup.exe icon. You may need to use the arrows to scroll through the folder to find it.

Note:

If you wish to make a floppy disk version of the printer software included on your CD-ROM, click the Driver disk creation utility button and follow the on-screen instructions.

3. Select your printer icon in the EPSON Printer Utility Setup dialog box.



4. Make sure EPSON Stylus COLOR 800 is selected, and click OK to start the printer software installation. Follow the on-screen messages and when the installation is complete, click OK again.

Your printer software is now installed. For information on opening and using the software, see Chapter 3, “Printing With Windows.”


Installing in Windows 95 (using plug-and-play)

Follow these steps to install the printer software using Windows 95 plug-and-play capabilities.

Note:

To install the printer software using Windows* 95 plug-and-play capabilities, your computer's parallel port must be an IEEE 1284 compatible, bidirectional parallel port. See your computer documentation for more information.

1. Make sure the printer is connected to the computer's parallel port.
2. Turn off your printer and computer, if necessary.
3. Turn on the printer first; then turn on the computer. Your computer begins loading Windows 95.
4. If you defined a password, enter it at the prompt. You see the New Hardware Found screen.



Note:

If you do not see the New Hardware Found screen or if you run into any kind of problem, click Cancel and follow the installation procedure on page 2-13 instead.

5. Make sure your printer model name is displayed on the screen. Then click the Driver from disk provided by hardware manufacturer button. Do not select any of the other buttons.
6. Click OK. You see the Install From Disk screen.
7. Insert the printer software CD shipped with your printer in the CD-ROM drive. Depending on the country, the CD-ROM may contain multiple-language versions of the printer software.

First try typing D:\Win95 and clicking OK. If an error message does not appear, proceed to step 8. If an error message does appear, you have the multiple-language version and you need to click OK to return to the Install From Disk screen. Type D:\ then specify your preferred language by typing English, Francais, German, Italian, Portugal, or Spanish, followed by \Win95. Click OK. (If your CD-ROM drive uses a drive letter other than “D”, substitute the appropriate letter.)

If you use the floppy disk version, insert it in a disk drive. If the drive you are installing from is displayed on the screen, click OK. Otherwise, change the drive letter in the Copy manufacturer’s files from box and click OK.

8. At the next screen you can type a unique name for the printer in the Printer name box. We recommend that you keep the model name as shown. The program will copy the files to your hard disk and add an icon to the Printers folder using the printer name you assign. To use this printer as the default printer for Windows 95 applications, select Yes. (No is the default setting.)
9. Click the Finish button.

The printer software that controls your printer is now installed. For information on accessing and using the software, see Chapter 3, “Printing With Windows.”

Using your printer on a network with Windows 95

To use your printer on a network, you need to set up your printer as a network printer. Follow these steps:

1. Double-click the My Computer icon.
2. Double-click the Printers folder.
3. Right-click the icon of your printer, and click Properties. Be sure to right-click.
4. Click the Details tab. The following window appears:



5. Click the Add Port button, then specify the network path to the printer. Click OK.

Note:

If you want to print from DOS applications as well as from Windows applications, click the Capture Printer Port button instead of the Add Port button. Click anywhere in the Device box and select the printer port your printer is connected to, then specify the network path to the printer. Make sure Reconnect at logon is selected, then click OK.


6. After you have made your settings on the Details menu, click Start, point to Programs and Epson, then click Spool Manager⁴. The Spool Manager window opens.
7. Select your printer, click the Queue menu, then click Setup. The Queue setup window opens.
8. Make sure the Use Print Manager for this port option is on; it is on if the check box contains a check. Then click OK.

Now you can use your printer on a network.

Installing in Windows 3.1

Follow these steps to install the software using Windows 3.1:

1. Make sure Windows 3.1 is running and the Program Manager window is open.
2. Insert the Printer Software CD shipped with your printer in the CD-ROM drive. (If you use the floppy disk version, insert it in a floppy disk drive.)
3. In the File menu, select Run. You see the Run dialog box. In the Command Line box, type D:\SETUP. If the CD-ROM drive you are using is not drive D, substitute the correct letter. If you are installing from floppy disks, type A:\SETUP (or B:\SETUP).



Note:

If you wish to make a floppy disk version of the printer software included on your CD-ROM, type EPSETUP instead of SETUP. In the dialog box that appears, click the Driver disk creation utility button and follow the on-screen instructions.

4. Click OK. You see the EPSON Printer Utility Setup dialog box.



5. Select your printer name and click OK. The installation program begins copying the printer software files. Follow the message that appears if you are installing from floppy disks.

After a few moments, the installation program creates the EPSON program group in Windows.

6. When the installation is complete, click OK to exit the installation program.

The installation program automatically selects this printer as the default printer for Windows applications.

The printer software that controls your printer is now installed. For information on accessing and using the software, see Chapter 3, “Printing With Windows.”


Connecting the Printer to Your Macintosh

The method you use to connect the printer to your Macintosh depends on whether you are using the printer's built-in serial interface or an optional interface card (see page 8-2).

Using the built-in serial interface

To use the printer's built-in serial interface, you will need an Apple System Peripheral-8 cable. Read the following steps to connect the printer to your Macintosh.


1. Make sure both your printer and Macintosh are switched off.
2. Connect one end of the interface cable to the serial connector on the back of the printer.




3. Connect the other end of the interface cable to either the modem port or printer port on the Macintosh. The ports are marked with the following icons.



modem port



printer port

4. Turn on the printer by pressing the  power button.
5. Turn on your Macintosh.

See “Installing the Printer Software in Your Macintosh” on page 2-23 for instructions on installing the printer software. You must install the printer software before using your printer.

Using an optional EPSON interface card

An optional LocalTalk™ or Ethernet interface card lets you use your printer on an AppleTalk network.

To use the LocalTalk Interface Card (C82312*), you will need two LocalTalk Locking Connector Kits (DIN-8 version). Attach a connector box to the AppleTalk interface on the printer and to the printer port on the Macintosh. Then attach the LocalTalk cable between the two connector boxes. See the user’s guide that comes with the connector kits for more details.

To use the Ethernet Interface Card (C82331*), see the user’s guide that comes with the card for setup information.

For information on installing these interface cards in the printer, see Chapter 8, “Using Optional Interfaces.”

Note:

The asterisk in the product number is a substitute for the last digit, which varies by country.

Installing the Printer Software in Your Macintosh

Always use the EPSON Stylus COLOR 800 Macintosh printer software when printing with your printer. This software is specially designed to allow easy access to all the features of the printer.



Caution:

Turn off all virus protection programs before you install your printer software.

Installing the printer software

If you are using the floppy disk version of the software, before you begin installation, make a backup copy of the EPSON Macintosh printer software disk. Then perform the following procedure:

1. Turn on your Macintosh and insert the EPSON printer software CD shipped with your printer into its CD-ROM drive. (If you use the floppy disk version, insert it in a disk drive.)

The EPSON printer software disk opens automatically and, depending on the country, displays either a single installer icon or separate folders containing installer icons for several languages. Double-click the Installer icon if it is displayed, or open the folder for your preferred language, then open the Disk 1 folder and double-click the installer icon inside it.

2. After the initial screen appears, click Continue to advance to the following dialog box, where you can choose to install all or some of the software components included on your printer software CD. For information on the included software, see page 2-25.



3. If you want to install all of the printer software components included on your printer software CD-ROM, make sure the disk where you want to install the software is displayed in the Destination Disk box, then click Install.

If you are low on disk space, select Custom Install from the pop-up menu and click EPSON Stylus Printer Driver Package plus any other components you need to install. The first time you install your printer software, you must select EPSON Stylus Printer Driver Package. If you are going to use your printer on an AppleTalk network, install Epson Namer as well. Confirm the destination for installation, then click Install.

Note:

Click the  icon to get information on each component.

4. When a message appears informing you that installation is finished, click Restart to complete the installation and restart your computer.

If you are going to use the optional LocalTalk Interface Card (C82312*) or Ethernet Interface Card (C82331*), you need to assign a name to your printer using the EPSON Namer utility as described on page 2-27. If you are using a serial interface, skip to “Using the Chooser to select your printer” on page 2-27.

Printer software components

Your printer software CD-ROM contains the following software components:

EPSON Stylus Printer Driver Package

- ❑ **EPSON Stylus (EX)**
This is the printer driver software that runs your printer if you are using the serial interface.
- ❑ **EPSON Stylus (AT)**
This is the printer driver software that lets you use the printer on an AppleTalk network.
- ❑ **EPSON Monitor2**
Monitors and manages background printing jobs. You must turn on background printing in the Chooser to use this utility. For more information, see “Using the EPSON Monitor2 Utility” on page 6-25.
- ❑ **ColorSync™ 2.0 and Profiles**
Matches the colors in your printout with the colors displayed on your screen automatically. Use this when printing scanned photographs or computer graphics.

To use this feature, you may need to set the system profile for your monitor. Access the ColorSync System Profile utility through the Control Panel and click the Set Profile button. Select your monitor from the list of monitors that appears, and then click Select. Close the dialog box.

- ❑ **StatusMonitor**
Keeps track of the current status of your printer, and alerts you when printer errors occur. You can open it from the Utility dialog box in the printer driver software. For more information, see “Using EPSON Printer Utilities” in Chapter 6.
- ❑ **Nozzle Check**
Checks the print heads for clogging. You can open this utility from the Utility dialog box in the printer software. For more information, see “Using EPSON Printer Utilities” in Chapter 6.
- ❑ **Head Cleaning**
Cleans the print heads to maintain the best print quality. You can open this utility from the Utility dialog box in the printer software. For more information, see “Using EPSON Printer Utilities” in Chapter 6.
- ❑ **Print Head Alignment**
Adjusts the print heads so that vertical and horizontal lines are aligned. You can open this utility from the Utility dialog box in the printer software. For more information, see “Using EPSON Printer Utilities” in Chapter 6.

Power Macintosh Extension Module

Increases the printing speed, especially when printing CAD documents or line art. For more information, see your Macintosh user’s guide.

EPSON Namer

Assigns a unique name to the printer so that you can use it on an AppleTalk network.

Assigning a name to the printer

Use the following procedure to assign a name:

1. Double-click the Epson Namer icon.

The EPSON Namer utility should be located on your hard drive if you installed it. If you have not installed it, insert the Printer Software for EPSON Stylus™ COLOR 800 CD-ROM into your computer's CD-ROM drive and open the utility from there. (If you use the floppy disk version, insert it in a disk drive and open the utility from there.)

2. Click the EPSON Stylus(AT) icon in the Device Types window.
3. If there are multiple AppleTalk zones at your site, select the zone where the printer is located.
4. Under New Name, enter a name for your printer. You should assign a name that clearly distinguishes your printer from others on the network.
5. Click Rename and then click Done to quit the EPSON Namer.

Using the Chooser to select your printer

After you install the printer software, you need to open the Chooser to select your printer. You have to choose the printer only the first time you use it or whenever you want to switch to another printer. Your Macintosh will always print using the last printer selected.


If you are using the serial interface, choose your printer driver as described in the following section, “Using the serial interface connection.” If your system is connected to an AppleTalk network, see “Using the AppleTalk connection” on page 2-30.

Note:

If you are using a Macintosh Quadra 950 or 900, you need to choose Compatible in the Serial Switch dialog box before selecting your printer from the Chooser. To open the Serial Switch dialog box, choose Control Panel from the Apple menu, then choose Serial Switch.

Using the serial interface connection

1. Make sure the printer is connected to your Macintosh and turned on.
2. Choose Chooser from the Apple menu. Then click the EPSON Stylus(EX) icon and the port your printer is connected to.



Note:

If you don't see the EPSON Stylus(EX) icon, use the arrows on the right to scroll through the available icons.

3. If your printer is connected to the Macintosh's printer port and you are not using an AppleTalk network, make AppleTalk inactive by clicking the Inactive radio button. You may also need to restart your Macintosh to make AppleTalk inactive.

You do not need to make AppleTalk inactive if the printer is connected to the modem port.



Caution:


Do not make AppleTalk inactive if the Macintosh is connected to an AppleTalk network. See "Using the AppleTalk connection" on page 2-30 for details.

4. Click the Background Printing radio buttons to turn background printing on or off.

When background printing is on, you can use your Macintosh while it is preparing a document for printing. You must turn on background printing to use the EPSON Monitor2 utility to manage print jobs. For more information, see "Using the EPSON Monitor2 Utility" in Chapter 6.

5. Close the Chooser.

Your Macintosh will check that the printer is connected correctly. If the message below appears, follow the instructions on the screen, click OK, and repeat the steps above.




Using the AppleTalk connection


1. Turn on your printer.
2. Choose Chooser from the Apple menu. Click the EPSON Stylus(AT) icon. Select the AppleTalk zone you want to use. A list of all the printers connected to the selected zone appears on the right.

Note:

If you don't see the EPSON Stylus(AT) icon, use the arrows on the right to scroll through the available icons.



3. Click the name you assigned to your EPSON Stylus COLOR 800. The following dialog box appears and prompts you to confirm the selected printer model name.



4. Click OK if the printer model name is correct.

If your printer name does not appear, make sure the printer is turned on and correctly connected, then click RETRY.

5. Click the Background Printing radio button to turn background printing on or off.

When background printing is on, you can use your Macintosh while it is preparing a document for printing. You must turn on background printing to use the EPSON Monitor2 utility to manage print jobs. For more information, see "Using the EPSON Monitor2 Utility" in Chapter 6.

6. Close the Chooser.

Chapter 3

Starting to Print with Windows

Loading Paper	3-2
Printing	3-5

Loading Paper


The following procedure describes how to load plain paper into the printer.

You can also print on ink jet paper, transparencies, photo-quality glossy film or paper, envelopes, index cards, and adhesive sheets. For details on using such media, see Chapter 7, “Printing on Special Paper.”


Note:

To print on transparencies, you need to reposition the paper support as described in Chapter 7.

1. Lower the output tray at the front of the printer and slide out the extension.




2. Slide the left edge guide to the left as far as it will go.



3

If you load long paper (for example, legal size paper), pull up the paper support extension.




3. Fan a stack of paper; then tap it on a flat surface to even the edges.

Windows


4. Load the stack of paper with the printable surface up and the right edge of the paper resting against the right side of the sheet feeder.

Note:

- Always load paper into the sheet feeder short edge first. Load envelopes flap edge first with the flap side down.
- Load preprinted forms or letterhead top edge first.



5. Slide the left edge guide against the left edge of the paper. Make sure the paper stack fits under both the edge guide tab and arrow mark as shown below.



Printing

To get started printing right away, follow the printing method explained below, which is typical of many Windows applications. The actual way you print may vary depending on the application you use. See your application manual for details.

Note:

While many Windows applications override the settings made with the printer driver, some do not, so you must verify the settings to get the results you expect.

1. From your application, open the document you want to print.
2. Click Print on the File menu. The Print dialog box (or a similar dialog box) appears.
3. Make sure your printer is selected and then click Printer, Setup, Properties, or Options. You may need to click a combination of these buttons. The printer software window appears.



4. Click the Main tab if necessary, and make sure the Mode option is set to Automatic.

Note:

When Automatic is selected, the printer software determines the best settings according to the Media Type and Ink settings you make.

5. Click anywhere in the Media Type box, and select the media you loaded in the printer. If you don't see your media in the list, use the arrow on the right to scroll through the list. See "Making the Media Type Setting" on page 4-10 for more information.
6. Select Color as the Ink setting if your document includes color. Select Black if you are printing black text, a draft, or if you want colors to print as varying shades of gray.
7. Click the Paper tab. The Paper menu appears.



8. Select the size of the paper you loaded in the printer from the Paper Size list. If you don't see your paper size in the list, use the arrow on the right to scroll through the list.

Note:

If your paper size is not included in the list, select User Defined and enter the paper size in the dialog box that appears. For more information on the User Defined option, see online help.

9. Make the Orientation setting. The effect of your setting is shown in the display to the left.

Note:

Always load paper into the sheet feeder short edge first. Load envelopes flap edge first with the flap side down.

10. Click OK at the bottom of the window. You return to the Print dialog box (or a similar dialog box).
11. Click Close, OK, or Print to print. You may need to click a combination of these buttons.

While your document is printing, the EPSON Despooler dialog box will appear, showing the printing progress and the status of your printer. If you are printing from Windows 95, this dialog box also displays the Status Monitor.

See Chapter 4 and online help for detailed information on printer driver settings, the EPSON Despooler, and the Status Monitor.

Chapter 4

Using the Printer Software for Windows

Introducing the Printer Software Functions	4-2
Accessing the Printer Software	4-2
From Windows applications	4-3
From Windows 95	4-3
From Windows 3.1	4-4
Using the Automatic Setting	4-5
Using the Predefined Settings	4-6
Customizing the Print Settings	4-8
Making the Media Type Setting	4-10
Using EPSON Printer Utilities	4-12
EPSON Status Monitor	4-13
Nozzle Check	4-14
Head Cleaning	4-14
Print Head Alignment	4-14
Checking Printer Status	4-15
Understanding the EPSON Spool Manager	4-15
Understanding the Despooler	4-16
Getting Information Through Online Help	4-17
From Windows applications	4-17
From Windows 95	4-17
From Windows 3.1	4-17

Introducing the Printer Software Functions

The printer software includes a printer driver and printer utilities. The printer driver lets you choose from a wide variety of settings to get the best results from your printer. The printer utilities help you check the printer and keep it in top condition.

The quickest and easiest way to start printing is to leave the Mode option set to Automatic on the printer driver's Main menu. This way you only need to check the Media Type and Ink settings, as described on page 3-5.

Basically, there are three levels of settings: the Automatic setting; the predefined settings, which give you more control over printer settings; and the custom settings, which you make to fit your individual needs. These settings are described in detail starting on page 4-5.

Several printer utilities are provided to help you check the condition of the printer and perform maintenance procedures. See pages 5-20 through 5-23 for information on the Status Monitor, Nozzle Check, Head Cleaning, and Print Head Alignment utilities. For instructions on using the Status Monitor, see page 5-21, and for instructions on using any of the other utilities, see Chapter 8, "Troubleshooting."

Accessing the Printer Software

As explained on the following pages, you can access the printer driver settings and printer utilities contained in your printer software directly from any Windows application, or from My Computer in Windows 95 or Program Manager in Windows 3.1. The print settings made in many Windows applications override similar settings made in the printer driver, so in most cases you should access the printer software from your application to make sure that the settings are appropriate for the document you want to print.

Note:

Online help is available for details about the printer driver settings.

From Windows applications

How you should access the printer software varies depending on the application, application version, and Windows version you are using. Read the following to get a general idea of how to access the software.

From the File menu, choose Print or Print Setup. In the dialog box that appears click Printer, Setup, Properties, or Options. You may need to click a combination of these buttons.

The Main and Paper menus contain the printer driver settings. The Utility menu contains the printer utilities. Click the tabs at the top of the menus to open them.

For information on the printer driver settings, see online help and pages 4-5 to 4-11 in this chapter. See page 4-12 for information on the printer utilities.

From Windows 95

Follow these steps to access the printer software from My Computer.

If you are using Windows 3.1, see the next page.

1. Double-click the My Computer icon.
2. Double-click the Printers folder.
3. Right-click the icon of your printer, and click Properties. Be sure to right-click. The Properties window appears.

4. Click the menu tabs at the top of the Properties window to open the printer software menus. The Main and Paper menus contain the printer driver settings. The Utility menu contains the printer utilities.

For information on the printer driver settings, see online help and pages 4-5 to 4-11 in this chapter. See page 4-12 for information on the printer utilities.

From Windows 3.1

Follow these steps to access the printer software from Program Manager:

1. Open the Main program group and double-click the Control Panel icon.
2. Double-click the Printers icon.
3. Choose your printer from the Installed Printers list.
4. Choose Setup. You see the Main menu of the printer software window. The Main and Paper menus contain the printer driver settings. The Utility menu contains the printer utilities. Click the tabs at the top of the menus to open them.

For information on the printer driver settings, see online help and pages 4-5 to 4-11 in this chapter. See page 4-12 for information on the printer utilities.

Using the Automatic Setting

When Automatic is selected on the Main menu, the printer driver takes care of all detailed settings according to the Media Type and Ink settings you make (see page 4-10 for details on the Media Type settings). If you leave Mode set to Automatic, the only settings you need to check yourself are the the Media Type and Ink settings. Most Windows applications feature paper size and page layout settings which override similar settings on the Paper menu, but if your application does not, you should also check the items on the Paper menu.



Note:

If you choose Plain Paper, Photo Quality Ink Jet Paper, Photo Quality Glossy Paper or Photo Quality Glossy Film as the Media Type setting while Automatic is selected, a slide bar appears in the Mode box that lets you choose Quality or Speed. Select Quality when print quality is more important than speed.

Online help provides more information about the printer driver settings. See page 4-17 for instructions on using online help.

Using the Predefined Settings

The predefined settings are provided to help you optimize the print settings for a particular kind of printout, such as presentation documents or images taken by a video or digital camera. You will find the predefined settings in the list below the Advanced button on the Main menu.

To choose a predefined setting, click *Advanced*, then select the most appropriate setting from the list according to the type of document or image you will print.

When you choose a predefined setting, other settings such as *Print Quality*, *Halftoning*, and *Color* are set automatically. Changes are shown in the *Current Settings* display at the bottom of the *Main* menu. Before printing, be sure to verify the *Media Type* and *Ink* settings, as they may be affected by the predefined setting you select. See page 4-10 for more information on the *Media Type* setting.

The printer driver provides the following predefined settings:

Photo	Good for printing scanned photos
Text/Graph	Good for printing presentation documents such as graphs and charts
PhotoEnhance	Good for printing images captured using a video, digital camera, or scanner. EPSON PhotoEnhance automatically adjusts the contrast, saturation, and brightness of the original image data to produce sharper, more vivid color printouts. PhotoEnhance does not affect your original image data.

Note:

Printing with PhotoEnhance selected may take longer depending on your computer system and the amount of data contained in your image.

Text	Good for printing text-only documents
Economy	Good for printing drafts of text
ICM	ICM means Image Color Matching. This feature automatically adjusts printout colors to match colors on your screen.


Note:

- ICM is only available for Windows 95.*

- Selecting PhotoEnhance or ICM automatically sets the Ink option to Color. Also, some Media Type settings are not available depending on the selected predefined setting and on the Ink setting if a predefined setting is selected.*

Customizing the Print Settings


Many users will never need to manually make their own print settings. However, if you need more control over the driver, want to make the most detailed settings available, or just want to experiment, click the Advanced button on the Main menu and then click the More Settings button. The More Settings dialog box appears:



Some settings are enabled or disabled depending on the Print Quality, Media Type, and Ink settings you make. To save time and effort, always customize your settings in this order: Print Quality, Media Type, Ink, and then make other settings. See the next section for details about making the Media Type setting.

After making your settings, click OK. Your settings will be applied and you will return to the Main menu. To return to the Main menu without applying your settings, click Cancel. For details on the settings, see online help.

To save your custom settings, click Save Settings on the Main menu. The Custom Settings dialog box appears:



Type a unique name for your custom settings in the Name box, and click the Save button. Your settings will appear in the list under the Advanced button on the Main menu.

Note:

- ❑ *You can not use a predefined setting name for your custom settings.*
- ❑ *To delete a custom setting, click Save Settings on the Main menu, select the setting in the Custom Settings dialog box and then click Delete.*
- ❑ *You can not delete the predefined settings.*

If you change the Media Type or Ink setting when one of your customized settings is selected in the Advanced settings list on the Main menu, the setting selected in the list changes to Custom Settings. The customized setting that was previously selected is not affected by this change. To return to your customized setting, simply reselect it in the settings list.

Making the Media Type Setting

On the Main menu, select the Media Type setting that matches the paper you loaded in the printer. See the following to determine the Media Type setting (shown in bold) for your paper. First find your paper, then click the corresponding Media Type setting.

Note:

If the corresponding Media Type option for your paper is not shown in the Media Type list, change the Print Quality setting in the More Settings dialog box, select Automatic as the Mode setting, or change the predefined setting in the Advanced settings list on the Main menu.

Plain Paper

Plain paper
Envelopes

360 dpi Ink Jet Paper

EPSON 360 dpi Ink Jet Paper (A4)	S041059
	S041025
EPSON 360 dpi Ink Jet Paper (Letter)	S041060

Photo Quality Ink Jet Paper

EPSON Photo Quality Ink Jet Paper (A4)	S041061
	S041026
EPSON Photo Quality Ink Jet Paper (Letter)	S041062
EPSON Photo Quality Ink Jet Paper (Legal)	S041067
EPSON Photo Quality Ink Jet Card (A6)	S041054
EPSON Photo Quality Ink Jet Card (5 × 8 in.)	S041121
EPSON Photo Quality Ink Jet Card (8 × 10 in.)	S041122
EPSON Photo Quality Self Adhesive Sheet (A4)	S041106

Ink Jet Transparencies

EPSON Ink Jet Transparencies (A4)	S041063
EPSON Ink Jet Transparencies (Letter)	S041064

Photo Quality Glossy Paper

EPSON Photo Quality Glossy Paper (A4)	S041126
EPSON Photo Quality Glossy Paper (Letter)	S041124
EPSON Photo Paper (4 × 6 in.)	S041134

Photo Quality Glossy Film


EPSON Photo Quality Glossy Film (A4)	S041071
EPSON Photo Quality Glossy Film (Letter)	S041072
EPSON Photo Quality Glossy Film (A6)	S041107

Note:

The availability of special media varies by country.

Using EPSON Printer Utilities

EPSON printer utilities allow you to check the current printer status and do some printer maintenance from your screen. To access the utilities, click the Utility tab in the printer software window, then click the button for the utility you want to use. The utilities are explained briefly below. For more details, see online help.



Note:

The letter in parentheses after the utility name indicates the shortcut key for that utility. Press Alt and the letter on the keyboard to open that utility.

EPSON Status Monitor

The Status Monitor utility helps you to keep track of the printer, and it alerts you if there are any problems. You can also check how much ink is remaining before printing and while printing. When you install the printer software for Windows 95, the Status Monitor is automatically copied to your hard disk.

Note:

The Status Monitor is only available for Windows 95.

The Status Monitor utility is available only when the printer is connected directly to the host computer. You cannot use this utility when printing over a network.

When you send a print job to the printer, the Status Monitor will appear in the Despooler dialog box. For information on the Despooler dialog box, see “Understanding the EPSON Spool Manager” on page 4-15.

The Status Monitor provides information about the printer status as shown by the icons below.



Checking the printer status.



An error has occurred. Your printer cannot print. Check your printer.



The printer is ready.



The printer is printing.



The ink level is low or out.

Nozzle Check

You can check the print head nozzles for clogging with this utility. Check the nozzles when you notice a decline in print quality and after cleaning to confirm that the print head nozzles have been cleared. In case the nozzle check indicates the print heads need cleaning, you can access the Head Cleaning utility directly from the Nozzle Check utility. See Chapter 10, “Troubleshooting,” for more information.

Head Cleaning

You can clean the print heads with this utility. You may need to clean the heads if you notice a decline in print quality. Before and after print head cleaning, use the Nozzle Check utility to check whether the print heads need to be cleaned (again). You can access the Nozzle Check utility directly from the Head Cleaning utility. See Chapter 10, “Troubleshooting,” for more information.

Print Head Alignment

This utility aligns the print heads. Use this utility when you notice a misalignment of vertical or horizontal lines. See Chapter 10, “Troubleshooting,” for more information.

Note:

- ❑ *Do not use the Nozzle Check, Head Cleaning, and Print Head Alignment utilities with printers connected to your computer through a network.*
- ❑ *Do not use the Nozzle Check, Head Cleaning, and Print Head Alignment utilities while printing is in progress; otherwise your printout may be marred.*

Checking Printer Status

When you send a print job to the printer, the EPSON Despooler and Status Monitor appear in the lower right portion of your screen. The Despooler shows the progress of the current print job and allows you to control the progress of the print job, as described below.

Understanding the EPSON Spool Manager

The EPSON Spool Manager is similar to Windows Print Manager. If it receives two or more print jobs at one time, it puts them in a line (with printers on a network this may be called a print queue) in the order received. When a print job reaches the top of the line, the EPSON Despooler sends the job to the printer.

The Spool Manager starts automatically when you print from your application. To access the Spool Manager from Windows 95, click the EPSON Spool Manager icon after it appears on the taskbar. To access the Spool Manager from Windows 3.1, double-click the EPSON Spool Manager icon after it appears at the bottom of your desktop. For more information, see online help.

Understanding the Despooler

When you send a print job to the printer, the EPSON Despooler dialog box appears in the lower right portion of your computer screen. This box shows the progress of the current print job and provides printer status information.



You can control printing from the Despooler dialog box using the stop, pause, and reprint buttons as explained below.



Stop Cancels printing



Pause Pauses printing until you press it again



Reprint Restarts printing from the current page, reprints the whole document, or holds the document for printing later

The Status Monitor at the bottom of the Despooler dialog box only appears if you are using Windows 95. See page 4-13 for more details.

Getting Information Through Online Help

Your printer software has an extensive online help feature that includes detailed information and instructions about printer driver settings and the printer utilities. Online help will answer most of your questions about your printer software.

From Windows applications

To access online help from your application, open the File menu and choose Print or Print Setup. Then click Printer, Setup, Options, or Properties (you may need to click a combination of these buttons) depending on the software you are using. Click the Help button at the bottom of the Main, Paper, or Utility menu for help related to the items on that menu.

If you are running Windows 95, or Windows NT 4.0 you can get specific help related to any item on a menu by right-clicking the item, then clicking the What's This? prompt.

From Windows 95

To access online help from Start, click the Start button, point to Programs and Epson, and then click EPSON Stylus COLOR 800 Help. You see the help contents window.

From Windows 3.1

To access online help from Program Manager, open the EPSON program group and double-click the EPSON Stylus COLOR 800 Help icon. You see the help contents window.

Chapter 5

Starting to Print with Macintosh

Loading Paper	5-2
Printing	5-5

Loading Paper


The following procedure describes how to load plain paper into the printer.

You can also print on ink jet paper, transparencies, photo-quality glossy film or paper, envelopes, index cards, and adhesive sheets. For details on using such media, see Chapter 7, “Printing on Special Paper.”


Note:

To print on transparencies, you need to reposition the paper support as described in Chapter 7.


1. Lower the output tray at the front of the printer and slide out the extension.



2. Slide the left edge guide to the left as far as it will go.



If you load long paper (for example, legal size paper), pull up the paper support extension.




3. Fan a stack of paper; then tap it on a flat surface to even the edges.


4. Load the stack of paper with the printable surface up and the right edge of the paper resting against the right side of the sheet feeder.

Note:

- Always load paper into the sheet feeder short edge first. Load envelopes flap edge first with the flap side down.
- Load preprinted forms or letterhead top edge first.



5. Slide the left edge guide against the left edge of the paper. Make sure the paper stack fits under both the edge guide tab and arrow mark as shown below.



Printing



To get started printing right away, follow the printing method explained below, which is typical of many Macintosh applications. The actual way you print may vary depending on the application you use. See your application manual for details.

Note:

While many Macintosh applications override the settings made with the printer driver, some do not, so you must verify the settings to get the results you expect.

1. From your application, open the document you want to print.
2. Choose Page Setup from the File menu. This brings up the dialog box shown below.



3. Select the paper size you loaded in the printer from the Paper Size list.
4. Check the Orientation option for  Portrait or  Landscape orientation.

Note:

Always load paper into the sheet feeder short edge first. Load envelopes flap edge first with the flap side down.

5. After making your settings, click the OK button to close the Page Setup dialog box.

Note:

You can not print from the Page Setup dialog box. You can only print from the Print dialog box.

6. Choose Print from the File menu. This brings up the dialog box shown below.



7. Make sure the Mode option is set to Automatic.

When Automatic is selected, the printer software determines the best settings according to the Media Type and Ink settings you make.

8. Select the type of paper you loaded in the printer from the Media Type list.
9. Select Color as the Ink option if your document includes color. Select Black if you are printing black text, a draft, or if you want colors to print as varying shades of gray.
10. Click Print to start printing.

Chapter 6

Using the Printer Software for Macintosh

Introducing the Printer Software Functions	6-2
Using the Automatic Setting	6-2
Using the Predefined Settings	6-5
Customizing the Print Settings	6-8
Making your settings	6-8
Saving your settings	6-9
Choosing your settings	6-10
Modifying visual effects	6-10
Controlling the printing quality	6-14
Making the Color and Halftoning settings	6-17
Changing the Paper Size	6-18
Defining a Custom Paper Size	6-19
Using EPSON Printer Utilities	6-21
EPSON StatusMonitor	6-22
Nozzle Check	6-23
Head Cleaning	6-24
Print Head Alignment	6-24
Using the EPSON Monitor2 Utility	6-25

Introducing the Printer Software Functions

The printer software includes a printer driver and printer utilities. The printer driver lets you choose from a wide variety of settings to get the best results from your printer. The printer utilities help you check the printer and keep it in top condition.

The quickest and easiest way to start printing is to leave the Mode option set to Automatic in the Print dialog box. This way you only need to check the Media Type and Ink settings, as described on page 6-3.

Basically, there are three levels of settings: the Automatic setting; the predefined settings, which give you more control over printer settings; and the custom settings, which you make to fit your individual needs. These settings are described in detail below.

Several printer utilities are provided to help you check the condition of the printer and perform maintenance procedures. See pages 5-20 through 5-23 for information on the Status Monitor, Nozzle Check, Head Cleaning, and Print Head Alignment utilities. For instructions on using the Status Monitor, see page 5-21, and for instructions on using any of the other utilities, see Chapter 8, "Troubleshooting."

Using the Automatic Setting

When Automatic is selected as the Mode setting in the Print dialog box, the printer driver takes care of all detailed settings according to the Media Type and Ink settings you make (see page 6-3 for details on the Media Type setting). Most users will never have to change this setting. However, if your application program does not give you enough control over the printout, you may want to experiment with the predefined settings or make your own custom settings. See page 6-6 for information on the predefined settings, and page 6-8 for information on making custom settings.

To access the Print dialog box, click Print on the File menu of your application or click Options in the Page Setup dialog box. The Print dialog box appears:



Note:

If you choose Plain Paper, Photo Quality Ink Jet Paper, Photo Quality Glossy Paper or Photo Quality Glossy Film as the Media Type setting while Automatic is selected, a slide bar appears in the Mode box that lets you choose Quality or Speed. Select Quality when print quality is more important than speed.

Before printing, be sure to verify the Media Type and Ink settings as described below because they also have an effect on the other settings. You may also need to check the Page Setup dialog box for other basic settings such as paper size. See page 6-18 for information on the Page Setup dialog box.

Media Type

Select the Media Type setting that matches the kind of paper you loaded in the printer. See below to determine which Media Type setting (shown in bold) best matches your paper.

Plain Paper

Plain paper
Envelopes

360 dpi Ink Jet Paper

EPSON 360 dpi Ink Jet Paper (A4)	S041059
	S041025
EPSON 360 dpi Ink Jet Paper (Letter)	S041060

Photo Quality Ink Jet Paper

EPSON Photo Quality Ink Jet Paper (A4)	S041061
	S041026
EPSON Photo Quality Ink Jet Paper (Letter)	S041062
EPSON Photo Quality Ink Jet Paper (Legal)	S041067
EPSON Photo Quality Ink Jet Card (A6)	S041054
EPSON Photo Quality Ink Jet Card (5 × 8 in.)	S041121
EPSON Photo Quality Ink Jet Card (8 × 10 in.)	S041122
EPSON Photo Quality Self Adhesive Sheet (A4)	S041106

Ink Jet Transparencies

EPSON Ink Jet Transparencies (A4)	S041063
EPSON Ink Jet Transparencies (Letter)	S041064

Photo Quality Glossy Paper

EPSON Photo Quality Glossy Paper (A4)	S041126
EPSON Photo Quality Glossy Paper (Letter)	S041124
EPSON Photo Paper (4 × 6 in.)	S041134

Photo Quality Glossy Film

EPSON Photo Quality Glossy Film (A4)	S041071
EPSON Photo Quality Glossy Film (Letter)	S041072
EPSON Photo Quality Glossy Film (A6)	S041107

Note:

The availability of special media varies by country.

Ink

If your document includes color, select Color. If you are printing black text, a draft, or if you want colors to print as varying shades of gray, choose Black.

Using the Predefined Settings

The predefined settings are provided to help you optimize the print settings for a particular kind of printout such as presentation documents or images taken by a video or digital camera.

The predefined settings appear in a list located between the More Settings and Save Settings buttons in the Print dialog box. This list is enabled when you click the Advanced button.

To select a predefined setting, click the Advanced button, then click in the list and select a setting according to the type of document or image you want to print.

When you choose a predefined setting, other settings such as Print Quality, Halftoning, and Color are set automatically. Changes are shown in the Current Settings display on the right side of the Print dialog box. Before printing, be sure to verify the Media Type and Ink settings, as they may be affected by the predefined setting you select. See the previous section for more information on the Media Type and Ink settings.

The printer driver provides the following predefined settings:

Photo

This setting is best for printing scanned photographs. It increases the contrast in an image.

Note:

Changing the Ink setting after Photo is selected returns the settings list to Custom Settings, so always make your Ink setting before you select this option.

Text/Graph

This setting is best for graphics-intensive documents such as charts and graphs for presentations. It intensifies the colors but lightens the midtones and highlights of an image.

Note:

Changing the Ink setting after Text/Graph is selected returns the settings list to Custom Settings, so always make your Ink setting before you select this option.

PhotoEnhance

This setting is best for printing images captured using a video, digital camera, or scanner. EPSON PhotoEnhance feature produces sharper images and more vivid colors by automatically adjusting the contrast, saturation, and brightness of the original image data.

Note:

- Selecting PhotoEnhance automatically sets the Ink option to Color. Changing the Ink setting after PhotoEnhance is selected returns the settings list to Custom Settings.*
- Printing with PhotoEnhance selected may take longer depending on your computer system and the amount of data contained in your image.*

Economy

This setting provides you with faster printing and saves ink. The printer uses less ink by printing fewer dots per character. Choose this setting for rough drafts of text only.

Note:

Changing the Ink setting after Economy is selected returns the settings list to Custom Settings, so always make your Ink setting before you select this option.

ColorSync™

This setting automatically adjusts printout colors to match the colors on your screen.

Note:

Selecting ColorSync automatically sets the Ink option to Color. Changing the Ink setting after ColorSync is selected returns the settings list to Custom Settings.

Text

This setting is best for printing text-only documents. It provides you with faster printing than the Text/Graph setting with only a slight decrease in printing quality.

Note:


Changing the Ink setting after Text is selected returns the setting list to Custom Settings, so always make your Ink setting before you select this option.

Customizing the Print Settings

Many users will never need to manually make their own print settings. However, if you need more control over the driver, want to make the most detailed settings available, or just want to experiment, customize your print settings as described below.

Making your settings

1. Click the Advanced button in the Print dialog box.
2. Click the More Settings button. The More Settings dialog box appears. The settings in the More Settings dialog box are explained in detail later in this chapter.



Note:


The Print Quality, Media Type, and Ink settings affect the availability of other options, so always make your settings in this order: Print Quality, Media Type, Ink, then other settings.

3. After making your settings, click OK. Your settings will be applied and you will return to the Print dialog box. To return to the Print dialog box without applying your settings, click Cancel.

Saving your settings

To save your custom settings as a group, follow these steps:

1. Click Save Settings in the Print dialog box. The Custom Settings dialog box appears.



2. Type a unique name (up to 16 characters) for your custom settings in the Name box.
3. Click Save.

You can save up to 10 groups of settings. You can select your saved group of settings from the settings list in the Print dialog box.

Note:

- ❑ *You can not use a predefined settings name for your custom settings.*
- ❑ *To delete a custom setting, select the setting in the Custom Settings dialog box and click Delete.*
- ❑ *You can not delete the predefined settings.*

Choosing your settings

To choose your settings, click **Advanced** in the **Print** dialog box, then click in the settings list beside the **More Settings** button and select your setting.

If you change the **Media Type** or **Ink** option when one of your customized settings is selected in the settings list, the selection shown in the list returns to **Custom Settings**. The customized setting that was previously selected is not affected by this change. To return to your customized setting, simply reselect it in the list.

Modifying visual effects

If you prefer to modify a document's color or grayscale value (various colors printed in shades of gray), you can adjust these settings and more with the **Color** settings in the **More Settings** dialog box.

You may need to experiment with different settings to get the output you want.

Note:

*When **Color** is selected as the **Ink** setting, all **Color** settings are available. When **Black** is selected, only **Contrast** and **Brightness** are available.*

Color Adjustment

The **Color Adjustment** settings provide you with a level of control over printed colors that you can not find in many applications.

Mode

There are four color adjustment modes as follows:

Automatic

Analyzes the print data and optimizes color correction for the type of data sent to the printer.

Photo-realistic

Provides output that closely matches the original data. Use this setting for color photographs.

Vivid

Intensifies the colors and lightens the midtones and highlights of an image. Use this setting for presentation graphics, such as charts and graphs.

No Color Adjustment

The printer driver does not enhance the color. Choose this option only when making a ColorSync profile for this printer. When printing normally, choose one of the other modes.

Slide bars

For the settings below, drag the slide bar to the right or left with your mouse or type a value in the box next to the slide bar to adjust a setting. The range varies from -25% to +25%.

Brightness

Changes the overall lightness or darkness of an image.

Contrast

Magnifies or minimizes the difference between the bright or dark parts of an image.

Saturation

Modifies the vividness of color. Lower saturation produces colors that are duller than those produced with higher saturation.

Cyan, Magenta, Yellow

Adjusts the amount of each of the three primary colors.

PhotoEnhance

Select this option when printing images taken with a video camera, digital camera, or scanner. EPSON PhotoEnhance automatically adjusts the contrast, saturation, and brightness of the original image data to produce sharper, more vivid color printouts. PhotoEnhance does not affect your original image data.

When PhotoEnhance is selected, other settings are dimmed, meaning you cannot change those settings.

Note:

- ❑ *PhotoEnhance is only available when Color is selected as the Ink option.*
- ❑ *Printing with PhotoEnhance selected may take longer depending on your computer system and on the amount of data contained in your image.*

ColorSync™

Select ColorSync when matching printed colors with the colors on your screen is important. It automatically adjusts the color range to print colors the way they appear on your screen. There are two settings, Profile and Rendering Intent. See below for details.

To use this feature, make sure you set the system profile for your monitor. To set your monitor profile, access the ColorSync System Profile utility through the Control Panel and click the Set Profile button. Select your monitor from the list of monitors that appears, and then click Select. Close the dialog box.

Note:

ColorSync is available only when Color ink is selected.

Profile

Matches the colors in your output with the colors displayed on your monitor. This software provides one profile, EPSON Standard, which is custom-designed to work with your printer. When this option is selected, the printer software uses the profile provided by EPSON.

Some companies may provide other profiles with their products. If installed, these profiles will appear in the Profile list.

Rendering Intent

Transfers the color information using the profile you have chosen from the Profile list.

Perceptual

The best option for reproducing photographs and printouts that are not suited to the other options.

Saturation

The best option for reproducing vivid images. Use this setting for presentation graphics, such as charts and graphics.

Colorimetric

The best option when precise matching of colors is most important, for example, when printing a company logo. Colorimetric attempts to reproduce colors the way the eye distinguishes them. Keep in mind that Colorimetric, or any other color matching method, may not always reproduce colors perfectly due to differences in the way scanners, printers, and other devices process color data. See Appendix B, “Tips for Color Printing,” for more information.

Controlling the printing quality

Use the controls in the More Settings dialog box to adjust the quality of the output. Some settings in this dialog box may be determined by Print Quality and Media Type settings.

Print Quality

The available Print Quality settings are:

SuperFine - 1440 dpi

Select this setting when you want the highest quality output at 1440 dpi. With this setting, we recommend the use of EPSON Photo Quality media. See page 6-4 for a complete list of EPSON special media.

Fine - 720 dpi

Select this setting when you want high-quality output at 720 dpi. With this setting, we recommend the use of EPSON Photo Quality media. See page 6-4 for a complete list of EPSON special media.

Normal - 360 dpi

Select this setting for most types of documents. Use this setting for plain paper, EPSON Ink Jet Transparencies, or EPSON 360 dpi Ink Jet Paper. See page 6-4 for a complete list of EPSON special media.

Economy

Select this option for printing rough drafts of text. This setting speeds printing and saves ink by printing fewer dots per character.

Note:

The Print Quality settings limit the availability of Media Type settings.

Media Type

The available Media Type options are determined by the Print Quality setting. Before selecting the Media Type, make the Print Quality setting.

See page 6-3 for details on the Media Type settings.

MicroWeave

MicroWeave allows your printer to generate superior output because graphics data is re-ordered and printed in finer increments. This technology reduces the possibility of banding, the light horizontal lines that can mar an image.

Note:

- You can select MicroWeave when printing with black ink, but the printing time is significantly longer.*
- MicroWeave is switched off automatically when Economy is selected as the predefined setting in the Print dialog box or as the Print Quality setting in the More Settings dialog box.*

High Speed

This setting activates bidirectional printing, which reduces the time it takes to print an image. Keep in mind that High Speed should be switched off for highest quality printing.

Note:

If vertical lines printed when High Speed is selected appear misaligned, you may need to align the print heads. For details, see “Aligning the Print Heads” on page 10-31.

Flip Horizontal

This feature flips the image 180° along its vertical axis. Printed images and text appear backwards.

Finest Detail

If you select Fine - 720 dpi as the Print Quality setting, you can turn on Finest Detail to print text and line art with very sharp edges. Be aware that it may take considerably longer to print using this feature and it will increase your Macintosh memory requirements. Additionally, you may not be able to print some larger images, and some patterns may not print correctly. If you experience problems printing with Finest Detail on, turn it off or add more memory.

Making the Color and Halftoning settings

The following settings control color quality and the halftone pattern.

Ink

Select Color if your printout includes color. Select Black if you are printing black text only, a draft, or if you want colors to print as varying shades of gray.

Halftoning

This setting lets you select one of four options: No Halftoning, Error Diffusion, Coarse Dithering, or Fine Dithering.

- Select No Halftoning when printing text only. Although this setting provides faster printing, it should never be used with color.
- Select Error Diffusion to make edges and colors softer when printing photographic images. Error diffusion blends every colored dot in your image with the surrounding colored dots.

- ❑ Dithering arranges dots in orderly patterns and is best suited for printing charts, graphs, and other images that require precise, solid areas of bright colors. Select Coarse Dithering for images with limited detail and shading. Select Fine Dithering for images with significant detail but limited shading.

Changing the Paper Size

To change a paper size, choose Page Setup from the File menu of your application. The following dialog box appears:



Paper size

You can use any of the following predefined paper sizes:

A4	Envelope #10
B5	Envelope C6
A5	Envelope DL
Letter	A6 Index card
Executive	Index card 5 × 8 in
Legal	Index card 8 × 10 in
Half Letter	EPSON Photo Paper 4 × 6 in

Note:

Always load paper into the sheet feeder short edge first. Load envelopes flap edge first with the flap side down.

Orientation

Use this setting to specify the direction of printing on the page,

 Portrait or  Landscape.

Reduce or Enlarge

Use this setting to reduce or enlarge the size of your image.


Printable Area

Select Maximum to make your printout as large as possible on the paper. Select Centered to position your printout at equal distances from the edges.


Defining a Custom Paper Size

If your paper size is not included in the paper size list in the Page Setup dialog box, follow the steps below to define a custom paper size.

1. In the Page Setup dialog box, click Customize.
The following dialog box appears:



2. To define a new paper size, click New. The dialog box updates to allow you to enter a name for the new size.



3. Type the paper size name in the New Paper Size box.
4. Specify the measurement unit as either inches or cm.
5. Type in the width and the height.
6. Click OK. You return to the Page Setup dialog box.

You can define up to eight paper sizes. The paper size names you create will appear in the Paper Size menu in the Page Setup dialog box.

To delete a custom paper size, click **Customize** in the Page Setup dialog box, select its name from the list in the Custom Paper dialog box, and click **Delete**.

Using EPSON Printer Utilities

EPSON printer utilities allow you to check the current printer status and do some printer maintenance from your screen. You can start them from the Utility dialog box. Click Utility in the Print dialog box to view the following dialog box:




EPSON StatusMonitor

The StatusMonitor utility regularly monitors the printer status. If it detects a printer error, it will inform you with an error message.

You can also use this utility to check how much ink is remaining before printing.


To use the StatusMonitor, follow these steps:

Click the EPSON StatusMonitor button in the Utility dialog box. The following dialog box appears:



The StatusMonitor checks the amount of ink remaining once when you click the StatusMonitor button on the Utility dialog box. To update the ink-level information, click the Update button.

The StatusMonitor provides an error message when a printer error occurs while printing. You can choose how error information will be displayed using the Configuration setting dialog box. Click the Configuration button while the StatusMonitor dialog box is open. The following dialog box appears:



Choose the method and click OK.

Nozzle Check

Checks whether or not the print head nozzles need to be cleaned. If the print heads need cleaning, you can directly enter the Head Cleaning utility from this utility. After you clean the print heads, you can return to the Nozzle Check utility directly from the Head Cleaning utility.

For detailed information on print head cleaning, see Chapter 10, “Troubleshooting.”

Head Cleaning

Cleans the color and black print heads. If print quality declines, use this utility to ensure the nozzles are delivering ink properly. Before and after print head cleaning, use the Nozzle Check utility to check whether the print heads need to be cleaned (again). You can access the Nozzle Check utility directly from the Head Cleaning utility. If the print quality does not improve, repeat print head cleaning.

Note:

- ❑ *To avoid wasting ink, clean the print head only if print quality declines.*
- ❑ *For detailed information on print head cleaning, see Chapter 10, “Troubleshooting.”*

Print Head Alignment

Aligns the print heads so that images print clearly. If you find that your printed image is fuzzy or the vertical or horizontal lines in your printout are not properly aligned, you may need to use this utility.

The Print Head Alignment utility includes both black and color print head alignment features. This utility affects only the print heads.


For more details on using this utility, see Chapter 10, “Troubleshooting.”

Using the EPSON Monitor2 Utility

After you send a print job to the printer, you can use the EPSON Monitor2 utility to check on what print jobs are queued for printing. You can cancel any print job in the queue. This utility also shows the status of the job currently being printed.

Before using EPSON Monitor2, you must first turn on Background Printing in the Chooser.

After starting a printing operation, select Epson Monitor2 from the Application menu at the right end of the menu bar. This opens a dialog box similar to the following:



To cancel a print job, click the name of the job and then click Cancel Printing.

Printing on Special Paper

Loading Special Paper and Other Media	7-2
About special media cleaning sheets	7-5
Loading Envelopes	7-6
Loading Transparencies	7-7
Using EPSON Photo Paper (S041134)	7-8
Loading	7-8
Removing the perforated margins	7-10
Storing EPSON Photo Paper	7-10


Loading Special Paper and Other Media

You can use most plain bond paper to achieve good results. However, coated papers and glossy paper/film give you better results because they reduce the amount of ink that is absorbed.

EPSON provides special media that are formulated for the ink used in EPSON ink jet printers. EPSON recommends you to use media distributed by EPSON to ensure high-quality results. For a list of EPSON special media, see page 1-6, or “Printing Supplies” in online help.

When loading special paper distributed by EPSON, read the instruction sheet packed with your special media first and keep the following in mind:

- ❑ Make sure the printable surface of the paper is face up when loading media into the sheet feeder. See the instruction sheets packed with the media to determine which side is the printable surface. Some media features cut corners to help identify the correct loading direction, as shown below.



- ❑ Make sure the paper stack fits under the edge guide tab and the arrow mark, both of which are located on the inside surface of the left edge guide. Basic loading capacity for special media is explained below.

EPSON 360 dpi
Ink Jet Paper and Photo
Quality Ink Jet Paper

You can load paper up to the arrow mark. If you load legal-size ink jet paper, do not load it more than halfway to the arrow mark.

EPSON Photo Quality
Ink Jet Card

You can load up to 30 index cards. Always place the included support sheet under the cards when loading them.

EPSON Photo Quality
Glossy Paper

You can load up to 20 sheets.

EPSON Photo Quality
Glossy Film

For best results, you should load glossy film one sheet at a time. Before loading glossy film, always put a support sheet* or a sheet of plain paper under it. If you wish to load multiple sheets of glossy film, load only up to 30 sheets and set the minimum top margin of the page to 30 mm. Be sure to remove each printout from the output tray immediately after printing. Before stacking or storing your printout, allow enough time for the ink to dry thoroughly and except for A6 size glossy film cover the printed side of every sheet with an enclosed protective sheet.

**EPSON Ink Jet
Transparencies**

You can load up to 10 transparencies. Always put a support sheet* or a sheet of plain paper under the stack of transparencies. You also need to reposition the paper support. See page 7-8. Be sure to remove each printout from the output tray immediately after printing. Before stacking or storing your printout, allow enough time for the ink to dry thoroughly and cover the printed side of every sheet with an enclosed protective sheet.

**EPSON Photo Quality
Self Adhesive Sheet**

You can load one sheet at a time.

Envelopes


You can load up to 10 envelopes.

*If a support sheet is packed with the paper, load it underneath the paper, but do not print on it.

- If you are printing from DOS, keep in mind the following:

When loading transparencies, set the print direction to Uni-D in the default-setting mode. See “Changing the Print Settings” in Appendix A.

- ❑ If ink smears on your documents when printing on thick special media, such as envelopes or index cards, set the adjust lever to the “+” position. To change the setting, open the printer cover and position the lever as shown below.



Note:

Return the adjust lever to the “0” position before printing on media of normal thickness. Leaving the lever in the “+” position may cause gaps in the printed image.


About special media cleaning sheets

Cleaning sheets packaged with EPSON special media should not be used with this printer. The cleaning function performed by these sheets is not necessary with this printer, and the sheets could jam in the printer.

Loading Envelopes

When printing on envelopes, please note the following:

- ❑ You can load up to 10 envelopes into the sheet feeder.
- ❑ Load envelopes flap edge first with the flap side down, as shown below.



- ❑ Do not use envelopes that are curled or folded. Also avoid using envelopes that are too thin; they may curl during printings.
- ❑ Select Plain Paper as the Media Type setting in the printer driver. For more details on making printer driver settings, see online help for Windows, or Chapter 6 for Macintosh.
- ❑ If ink smears on your documents, set the adjust lever to the "+" position. To change the setting, open the printer cover and reposition the lever. See the illustration on page 7-6.


Note:

Return the adjust lever to the "0" position, which is the normal position, after you finish printing on envelopes. Leaving the lever in the "+" position may cause the printed image to have gaps on other media.

Loading Transparencies

When printing on transparencies, please note the following:

- ❑ Before loading transparencies, remove the paper support and reinstall it into the slots at the back of the printer as shown below.




- ❑ Always put a support sheet or a sheet of plain paper under the stack of transparencies.
- ❑ You can load up to 10 transparencies.
- ❑ Make sure the printable surface of the paper is face up when loading transparencies into the sheet feeder. See the illustration on page 7-4.
- ❑ Select Ink Jet Transparencies as the Media Type setting in the printer driver. For more details on making printer driver settings, see online help for Windows, or Chapter 6 for Macintosh.

Using EPSON Photo Paper (S041134)

EPSON Photo Paper (S041134) is perforated around the margins so you can trim your printed images to look like 4 × 6 inch (102 × 152 mm) photographs. Please note the following when using this paper.

Loading

- ❑ Load the paper printable side up with the perforated margins positioned as shown below.




loading position

- ❑ Use flat, undamaged paper. If the paper or the support sheet is curled, flatten it before loading to avoid paper feeding problems.
- ❑ Always place the included support sheet under the stack of Photo Paper, but do not print on it.
- ❑ You can load up to 20 sheets of Photo Paper into the sheet feeder.

- ❑ To print on the coated (whiter) side of Photo Paper, select Photo Quality Glossy Paper as the Media Type setting and EPSON PhotoPaper 4X6 in as the Paper Size setting in your printer driver.

Note:


The outside edge of your image might be cut off when you remove the perforated margins.



- ❑ You can also print with black ink on the non-coated side (EPSON logo side) of Photo Paper. To print on this side, select 360 dpi Ink Jet Paper as the Media Type setting and then select EPSON Photo Paper 4X6 in as the Paper Size setting.
- ❑ Cut or tear the paper at the perforation only after printing. Do not cut, tear, or fold the paper before printing.

Removing the perforated margins

- ❑ To remove the perforated margins, fold the paper back and forth a few times along the perforations, then carefully tear the margins off.



- ❑ You may also remove the margins by cutting along the perforations.

Storing EPSON Photo Paper

- ❑ Return unused paper to the original package as soon as you finish printing, and avoid storing it in places exposed to high temperature, humidity, or direct sunlight.

Chapter 8

Using Optional Interfaces

8

Available Interfaces	8-2
Installing Optional Interfaces	8-3
Using the serial interface card (C82305*/C82306*)	8-5

Available Interfaces

You can use various interface cards to supplement the capabilities of your printer's built-in hardware interface. The following EPSON interface cards are compatible with your printer:

Interface card	Model number
Serial Interface Card	C82305*/C82306*
32KB Serial Interface Card	C82307*/C82308*
32KB Parallel Interface Card	C82310*
32KB IEEE-488 Interface Card	C82313*
LocalTalk™ Interface Card	C82312*
Twinax Interface Card	C82315*
Coax Interface Card	C82314*
Ethernet Interface Card	C82331*
Type B Bi-directional Parallel Interface Card	C82345*

*The asterisk is a substitute for the last digit, which varies by country.

If you are not sure whether you need an optional interface, or if you want to know more about interfaces, contact your dealer.

If you are planning to install the LocalTalk interface card in your printer, you will need two LocalTalk Locking Connector Kits (DIN-8 version). Attach one connector box to the AppleTalk interface on the printer and the other box to the printer port on the Macintosh. Then attach the LocalTalk cable between the two connector boxes. See the owner's guide that comes with the connector kits for more details.

Installing Optional Interfaces


1. Make sure the printer is turned off and all the printer's lights are off.
2. Unplug the power cord from the electrical outlet (and from the back of the printer, if your printer's power cord is removable).



Caution:


Do not install the interface card when the printer is connected to an electrical outlet. If you do, you may damage the printer or your computer.

3. Turn the printer around so that its back faces you, and disconnect any existing interface cables.
4. Use a cross-head screwdriver to remove the two screws securing the shield plate to the optional interface slot; then lift off the plate. Be sure to keep both screws; you may need to use them again when you reinstall the shield plate.



5. Be sure to set any switches and jumpers on the card. See the interface card's manual for details. If your interface card has a jumper labeled JG, make sure that you set it to on, or the card will not work properly.

- Slide the interface card along the slots on both sides of the interface compartment. Push it in firmly to fully insert the connector at the rear of the interface card into the printer's internal socket.



- Secure the interface card in the slot with the two screws included with the interface card.
- Connect the proper interface cable to the interface card and to your computer. If the cable has a grounding wire, connect it to one of the screws securing the parallel interface.

Also, if you are using more than one computer, reconnect the other interface cable.

- Make sure the printer is turned off. Then plug in the power cord.

Before you use the optional interface, you may need to change the setting for the interface option, such as I/F (interface) mode in the default-setting mode. If you need to change any settings, see “Changing the Print Settings” in Appendix A for instructions.

To remove the interface card, follow the above steps in reverse order.

Using the serial interface card (C82305/C82306*)*

When using a serial interface card (C82305*/C82306*), see the sections below to set the correct baud rate, handshake timing, and error handling.

For all other data transfer conventions, such as word structure and communications protocol, see the C82305*/C82306* interface card manual.

Selecting the baud rate

You can select the following baud rates: 600, 1200, 2400, 4800, 9600, and 19200 bps (bits per second). To set the baud rate, see the bit-rate selection table in the C82305*/C82306* interface card manual.

Handshake timing

When the vacant area for data in the input buffer drops to 256 bytes, the printer outputs an X-OFF code or sets the DTR flag to 1 (MARK) to indicate that it cannot receive data. When the vacant area for data in the buffer increases to 512 bytes, the printer outputs an X-ON code or sets the DTR flag to 0 (SPACE) to indicate that it is ready to receive data.

Error handling

When the printer detects a parity error, it prints an asterisk (*). The printer ignores all other errors, including framing and overrun errors.

Chapter 9

Maintenance and Transportation

Replacing an Ink Cartridge	9-2
Printing with an empty color ink cartridge	9-8
Cleaning the Printer	9-9
Transporting the Printer	9-10

Replacing an Ink Cartridge

The printer's indicator lights will inform you as described below when it is time to obtain a replacement ink cartridge and when it is time to replace an empty cartridge.


Note:

If you need to replace an ink cartridge when the  black or  color ink out light is off, see "Ink Cartridge Problems" on page 10-32.

EPSON recommends the use of genuine EPSON ink cartridges. Other products not manufactured by EPSON may cause damage to your printer not covered by EPSON's warranties.

When the  ink out light is

- flashing obtain a replacement black ink cartridge (S020108).
- on replace the empty black ink cartridge.

When the  ink out light is

- flashing obtain a replacement color ink cartridge (S020089).
- on replace the empty color ink cartridge.

Note:



When the color ink cartridge is empty, the printer can continue to work using only black ink. To print with black ink only, see "Printing with an empty color ink cartridge" on page 9-8.







Caution:



- Once you open the ink cartridge clamp, the ink cartridge becomes unusable and cannot be reinstalled even if ink remains.*
- Leave the old cartridge installed in the printer until you are ready to replace it with a new one.*


To replace an ink cartridge, follow these steps.




1. Make sure the printer is on. Determine which cartridge needs to be replaced as indicated by the  black or  color ink out light.

Note:

If you press the  cleaning button when the  ink out light is off or the  cleaning button when the  ink out light is off, the printer starts cleaning that print head.



2. Make sure the output tray at the front of the printer is lowered; then open the printer cover. You see the  and  cleaning buttons.




3. Hold down the  or  cleaning button (depending on which ink you need to replace) for three seconds. The print heads move left, to the black or color ink cartridge replacement position as shown below, and the  power light flashes.




Caution:

Do not move the print heads by hand. Always press the  cleaning button or the  cleaning button to move them; otherwise you may damage the printer.

- ❑ Black ink cartridge replacement position:



- ❑ Color ink cartridge replacement position:




Note:

The printer automatically moves the print heads back to their home (far right) position after 60 seconds if you have not started the replacement procedure.


- Lift up the ink cartridge clamp as shown below. The cartridge rises part way out of the cartridge holder.

**Caution:**

Once you open the ink cartridge clamp, the ink cartridge becomes unusable and cannot be reinstalled even if ink remains.



- Lift the cartridge out of the printer and dispose of it properly. Do not take the used cartridge apart or try to refill it.


**Warning:**

If ink gets on your hands, wash them thoroughly with soap and water. If ink gets into your eyes, flush them immediately with water.

6. Make sure the replacement ink cartridge is the correct one, color or black. Remove the ink cartridge from its protective bag. Next, remove only the yellow tape seal from the cartridge as shown below.



black ink cartridge
(S020108)




color ink cartridge
(S020089)




Caution:

- You must remove the yellow tape seal from the cartridge. Leaving the tape on when you install the cartridge will permanently damage it.*
 - Do not remove the whole tape seal (especially the white portion) from the top of the cartridge. Remove only the yellow portion.*
 - Do not remove the tape seal from the bottom of the cartridge; otherwise, ink will leak.*
7. Lower the ink cartridge into the cartridge holder with the label on the cartridge face up and the arrow on the cartridge pointing to the rear of the printer.



8. Press the ink cartridge clamp down until it locks in place.



9. If you need to replace the other ink cartridge as well, press the appropriate cleaning button (♣ for black, ♣ for color), then repeat steps 4 through 8.
10. Press the ⏴ load/eject button then close the printer cover. The printer moves the print heads and begins charging the ink delivery system. This operation takes about two minutes to complete.


**Caution:**

The ⏴ power light continues to flash while the printer performs the ink charging operation. Never turn off the printer while the ⏴ power light is flashing. Doing so can result in incomplete charging of ink.

When the ink charging process is finished, the printer resumes printing any data remaining in its memory or returns the print heads to their home position. Then the ⏴ power light stops flashing.

Even if you do not press the ⏴ load/eject button, the printer moves the print heads and begins the ink charging process about 60 seconds after you replace the ink cartridge.

Printing with an empty color ink cartridge

Even if the color ink cartridge is empty, you can still print documents with black ink as long as both cartridges are installed. To continue printing when the  ink out light is lit continuously, turn the printer off and back on again. Be aware that any data you sent to the printer before turning it off will be lost.

Note:

The empty color ink cartridge must be installed.

Before sending data to the printer, choose Black as the Ink setting in the printer driver. For details on the printer driver settings, see online help for Windows, or Chapter 6 for Macintosh.

To switch back to color printing, you must install a new color ink cartridge as described in this chapter, and then turn the printer off and back on again.

If the black ink runs out, you cannot continue printing until you replace it even though the color ink cartridge still contains ink.

Cleaning the Printer

To keep your printer operating at its best, you should clean it thoroughly several times a year.

1. Make sure the printer is turned off and all the printer's lights are off. Then unplug the power cord.
2. Remove any paper from the sheet feeder.
3. Use a soft brush to carefully clean away all dust and dirt.
4. If the outer case or the inside of the sheet feeder is dirty, clean it with a soft, clean cloth dampened with mild detergent. Keep the printer cover closed to prevent water from getting inside.
5. If the inside of the printer accidentally gets soiled with ink, wipe it off with a damp cloth.



Warning:

Be careful not to touch the gears inside the printer.



Caution:

- Never use alcohol or thinners to clean the printer; these chemicals can damage the components as well as the case.*
- Be careful not to get water on the printer mechanism or electronic components.*
- Do not use a hard or abrasive brush.*
- Do not spray the inside of the printer with lubricants; unsuitable oils can damage the mechanism. Contact your dealer or a qualified service person if lubrication is needed.*

Transporting the Printer

If you need to transport your printer some distance, carefully repack it using the original box and packing materials as follows:

1. Open the printer cover and make sure that the print heads are capped. They are capped when they are in the far right (home) position. If the print heads are not capped, turn on the printer and then turn it off again. The print heads return to the home position and are capped. Close the printer cover.



Caution:

Leave the ink cartridges installed when you transport the printer. Removing the cartridges during transport can damage the printer.

2. Unplug the power cord from the electrical outlet; then disconnect the interface cable from the printer.
3. Remove the paper from the sheet feeder and remove the paper support.
4. Push in the output extension tray, and then raise the output tray.
5. Attach the protective materials to the printer.
6. Repack the printer and power cord in the original box.
7. Keep the printer level during transport.

Chapter 10

Troubleshooting

Diagnosing the Problem	10-2
Error indicators	10-2
Status Monitor	10-4
Self testing	10-5
Hex dump mode	10-7
Problems and Solutions	10-8
Power supply	10-8
Operation	10-9
Paper handling	10-16
Printing quality	10-19
Increasing the Print Speed	10-27
Cleaning the Print Heads	10-29
Aligning the Print Heads	10-32
Ink Cartridge Problems	10-33
Contacting Customer Support	10-35
For United Kingdom and the Republic of Ireland users	10-35
For Australian users	10-38
For Hong Kong and Singapore users	10-40
For Philippines users	10-41













Diagnosing the Problem

Troubleshooting printer problems is best handled in two easy steps: first diagnose the problem, then apply likely solutions until the problem is fixed. The information that you need to diagnose the most common problems is provided by the printer's control panel lights and by the Status Monitor utility (Windows 95 and Macintosh only). In addition, you can determine whether a problem lies with the printer itself or with the computer by performing a self test. Experienced users may also want to use the printer's hex dump mode to pinpoint communication problems.


















In "Problems and Solutions" later in this chapter you can find causes and solutions to specific printer problems. Use the information presented in this chapter to pinpoint the source of your problem, then apply the recommended solutions until the problem is solved.

Error indicators

You can identify many common printer problems with the lights on the control panel. If your printer stops working and the lights are on or flashing, use the following table of panel light patterns to diagnose the problem, then follow the recommended corrective measures.

Lights	Problem and Solution	
	Paper Out	
	No paper is loaded in the printer.	Load paper in the sheet feeder; then press the  load/eject to turn the  paper out light off. The printer resumes printing.
	The paper is not loaded correctly.	Remove and reload paper; then press the  load/eject to turn the  paper out light off. See "Loading Paper" in Chapter 3 or Chapter 5.
  	Paper Jam	
	Paper has jammed in the printer.	Turn off the printer and gently pull out all the jammed paper. If it tears and pieces remain inside the printer, open the printer cover and remove the pieces of paper.
	Ink Low (black ink cartridge)	
	The black ink cartridge is nearly empty.	Obtain a replacement black ink cartridge (S020108). See page xx for details.
	Ink Out (black ink cartridge)	
	The black ink cartridge is empty.	Replace the black ink cartridge with a new one (S020108). See page xx for details.
	Ink Low (color ink cartridge)	
	The color ink cartridge is nearly empty.	Obtain a replacement color ink cartridge (S020089). See page xx for details.
	Ink Out (color ink cartridge)	
	The color ink cartridge is empty.	Replace the color ink cartridge with a new one (S020089). See page xx for details.

□ = on, ■ = off, ◻ = flashing

Lights	Problem and Solution	
       	Carriage Error	
	Printer failed.	Remove any paper from the paper path then press the  load/eject button for about 30 seconds. The paper feed roller rotates for as long as you press this button. Release the button then press it again, which causes the paper feed roller to rotate in the opposite direction. Release the button after about 30 seconds. Then turn off the printer. After a few seconds turn it on and try printing again. If the error is not cleared, contact your dealer.
       	Unknown Printer Error	
	An unknown printer error has occurred.	Turn off the printer, and contact your dealer.

□ = on, ■ = off, □ = flashing

Status Monitor

If you are printing with Windows 95 or a Macintosh, you can use the Status Monitor to check the printer's current status. For more details, see Chapter 4, "Using the Printer Software for Windows", or Chapter 6, "Using the Printer Software for Macintosh."

Self testing

Self testing can help you determine whether the problem comes from the printer or the computer.

- ❑ If the self test results are satisfactory, this means that the printer itself is all right and that the problem probably lies in the printer software settings, application settings, the interface cable (be sure to use a shielded cable), or the computer itself.
- ❑ If the self test does not print satisfactorily, this tells you there is a problem with the printer. See “Problems and Solutions” on page 10-7 for possible causes and solutions to the problem.



To perform a self test, follow these steps:


1. Make sure both the printer and computer are turned off.
2. Unlock the wire clips on both sides of the interface connector and remove the ground connector, if necessary. Then disconnect the cable from the printer’s interface connector.
3. Make sure that paper is loaded in the sheet feeder.



Caution:

Use paper at least 210 mm (8.27 inches) wide; for example A4 size paper loaded short edge first. Otherwise, the print heads will spray ink directly onto the platen. This may cause any documents you print afterwards to be smeared.

4. Hold down the  load/eject button and press the  power button to turn the printer on. Then release both buttons.



The printer prints a nozzle check pattern and samples of the factory default fonts and colors continuously until you end the test.

The above sample is in black and white, but the actual test prints in color.

5. To end the self test, turn off the printer. The printer ejects any paper from the paper path.

Hex dump mode



Experienced users can use the hex dump mode to pinpoint communication problems between the printer and a software program. To enter the hex dump mode, follow these steps.


1. Make sure the printer is turned off and paper is loaded into the sheet feeder.



Caution:

Use paper at least 210 mm (8.27 inches) wide, for example, A4 size paper loaded short edge first. Otherwise, the print heads will spray ink directly onto the platen, which could mar future printouts.

2. Open the printer cover.
3. Hold down the  load/eject button and the  cleaning button and turn on the printer. The printer prints Hex Dump Mode at the top of a page and stops.



4. Send data from the computer.

The printer prints the exact code it receives from the computer in hexadecimal format.

Problems and Solutions

This section divides printer problems into five categories:

- Power supply page 10-7
- Operation page 10-8
- Paper handling page 10-15
- Printing quality page 10-18

Go to the category for the type of problem you have and look for the description that most closely matches the problem. The most likely causes and solutions are listed first, so try them in the order that they are written until the problem is solved.

Power supply

The lights come on briefly but then go off and stay off.

Cause	What to do
The printer's voltage rating may not match the voltage of your electrical outlet.	Check the printer and the outlet voltage ratings. If the voltages do not match, unplug the printer immediately and contact your dealer.



Warning:

Do not reconnect the power cord to an electrical outlet that does not have matching voltage.

The printer does not work and the control panel lights are off.

Cause	What to do
The printer is turned off.	Press the ⏻ power button. The ⏻ power light will come on.
The power cord is not properly plugged into the electrical outlet.	Turn off the printer, make sure the power cord is firmly plugged into the electrical outlet, and turn the printer back on.
The electrical outlet is controlled by an outside switch or automatic timer.	Use a different outlet.
The electrical outlet is out of order.	Plug another electric device into the outlet to determine whether the outlet is working. If it is not, use a different outlet.

Operation

The ⏻ power light is on but nothing prints.

Cause	What to do
The interface cable is not plugged in securely.	Confirm that the cable is fastened to the printer and the computer securely. If the cable is connected correctly, run a self test as described on page 10-4.
Your interface cable does not meet both the printer and computer specifications.	Use an interface cable that meets both printer and computer specifications. See “Interface Specifications” in Appendix C.



Your software is not properly set up for your printer.	Make sure that your printer is properly selected in your software.
--	--

Install or reinstall the printer software as described in Chapter 2.

Nothing prints and the control panel lights are on or flashing.	
--	--

Cause	What to do
Several common printer errors have occurred at once.	Use the table in “Error indicators” earlier in this chapter to determine what combination of errors may have occurred, and apply the recommended solutions.

The printer sounds like it is printing, but nothing prints.	
--	--

Cause	What to do
The print head nozzles are clogged.	Clean the print heads. See “Cleaning the Print Heads,” later in this chapter. If this does not work after four or five trials, see below.
One or both of the ink cartridges have been used longer than six months or beyond the date on the packaging.	Try cleaning the print heads. If that does not solve the problem, replace the ink cartridges as needed. If the  or  ink out light is not on or flashing, see “Ink Cartridge Problems,” on page 10-32 to replace the ink cartridge.

The self test prints well, but nothing prints from an application program.

Cause

What to do

Your printer is not selected in your software.

Select your printer in the printer setup section of your software.

The interface cable does not meet both the printer and computer requirements.

Use a printer cable that meets the requirements shown under “System Requirements” on page 1-4.

Your computer is not 100% IBM[®] AT compatible.

Select Use Print Manager for this port in the Queue Setup window. To access this window, click the EPSON Spool Manager4 icon in the EPSON folder (Windows 95) or double-click this icon in the EPSON program group (Windows 3.1), and select Setup from the Queue menu.

Your computer system’s memory is too small to handle the volume of data in your document.

Try reducing the image resolution of your document in your image-editing software.

Install more memory in your computer if you can.

Select lower resolution or less colors for your display setting as described below.

For Windows 95, choose a lower resolution setting as the Color Palette setting. To access the Color Palette, click Start, point to Settings, and choose Control Panel. Then double-click the Display icon and click the Settings tab. For detailed information on making this setting, see your Windows 95 user’s guide.

For Windows 3.1, double-click the Windows Setup icon on the Main menu; then click Options and choose Change System Settings. Then choose a lower resolution setting for your display from the Display pop-up list. For detailed information on making this setting, see your Windows 3.1 user's guide.

If you have a display-adapter setting utility, use it to set the lower resolution. For detailed information, see your display board user's guide.

For Macintosh, choose Control Panel from the Apple menu and select Monitors. Select a lower resolution. For detailed information on making this setting, see your Macintosh user's guide.

The "Sorry, EPSON Stylus COLOR cannot be used" error appears. (Macintosh only)

Cause	What to do
The printer driver has been corrupted.	Remove and reinstall the driver: From the printer software floppy disk or CD-ROM, click Installer, click Continue, and select Custom Remove from the pop-up list that displays "Easy Install." Then select EPSON Stylus Series Printer Driver, and click Remove. Click Continue, if necessary, and click Restart. See page 2-20 for instructions on installing the printer driver.

Color documents print out in black and white.

Cause	What to do
Your printer is not selected in your software.	Select your printer in your software.
Color printing is not selected in your application or in the printer driver.	Select color printing in your application and the printer driver. Try to print again. If the image still comes out in black and white, try printing from another program. If this fixes the problem, contact the manufacturer of the software you had trouble with.
The printer is being used with an empty color ink cartridge installed.	Replace the color ink cartridge, then turn the printer off and back on. Be aware that any data sent to the printer will be lost. See “Printing with an empty color ink cartridge” on page 9-8.

Printing starts too high or too low on the page.

Cause	What to do
Margins are set incorrectly in your application.	Check that the margins are set correctly in your program. See the printable area specifications on page C-6 of Appendix C.
The size of the paper loaded in the printer does not match the paper size setting within your application program or printer driver.	Load the correct size of paper, or change the paper size settings within your application program or printer driver to match the size of paper you are using.

Print speed is not what you expect.

Cause	What to do
The image resolution and the amount of color used in the document may be too high.	Carefully considering your use of color and resolution can help you optimize your printing times. For more details, see “Increasing the Print Speed” later in this chapter.

Note:

High resolution printing and color printing significantly increase the amount of data to be processed. These two factors have the greatest effect on print speed.

Something on the page is wrong or missing.

Cause	What to do
An unknown problem has occurred.	Disconnect the interface cable from the computer; then try the self test described earlier in this chapter.
The printer settings within your application are incorrect.	Adjust the printer settings within your application and print again.
The interface cable is not plugged in securely.	Check that the cable is securely connected to the printer and the computer.
The data transfer rate does not match that of your computer.	Set the Parallel I/F mode to Normal in the default-setting mode. See “Changing the Print Settings” in Appendix A.

Software settings are overriding those made in the default-setting mode.

Always try making a setting in your application first. If that is not possible, use the printer driver. If that is also impossible, use the default-setting mode.

For DOS users:

The Network I/F mode is set to Off.

Set the Network I/F mode to On in the default-setting mode. To enter the default-setting mode, see “Changing the Print Settings” in Appendix A.

The New Hardware Found screen appears even though the printer software has already been installed.

Cause

What to do





This error may occur when using Windows 95.

Click the Do not install a driver (Windows will not prompt you again) button; then click OK.

The print heads moved to the ink cartridge replacement position unexpectedly.

Cause

What to do

The  or  cleaning button was pressed while the  or  light was flashing or on.

One or both of the ink cartridges is low or out of ink. Replace the ink cartridges as described on page 9-2.

Paper handling

Paper does not feed properly from the sheet feeder.	
--	--

Cause	What to do
Too many sheets are loaded in the sheet feeder.	Take the paper stack out of the feeder, remove some sheets, and reload the stack. Before you load paper, check the amount of paper you can load in the sheet feeder. See Chapter 7.
The edge guides are not set correctly.	Adjust the guides against the stack of paper. See “Loading Paper” in Chapter 3 or Chapter 5.
Paper is jammed in the paper path.	Turn off the printer and gently pull out all of the jammed paper. If it tears and pieces remain inside the printer, open the printer cover; then remove any remaining pieces of paper.
The paper stack does not fit under the edge guide tab inside the left edge guide.	Reload the paper so that it fits under the edge guide tab. See “Loading Paper” in Chapter 3 or Chapter 5.
The paper is curled or folded.	Use flat, undamaged paper.
The paper is old or creased.	Use only new, smooth sheets of paper.
The paper’s size is not compatible with the printer.	Use paper that meets the paper requirements for this printer. See “Paper” in Appendix C.


The printer loads more than one sheet at a time.

Cause	What to do
Too many sheets are loaded in the sheet feeder.	Take the paper stack out of the feeder, remove some sheets, and reload paper. Before you load paper, check the amount of paper you can load in the sheet feeder. See Chapter 7.
The edge guides are not set correctly.	Adjust the guides against the stack of paper. See “Loading Paper” in Chapter 3 or Chapter 5.
The paper is too thin.	Make sure the paper meets the paper requirements for this printer. See “Paper” in Appendix C.

Ejected paper is wrinkled.

Cause	What to do
The paper is damp.	Do not store your paper in a damp or humid environment. Store paper in its original packaging.

Paper does not fully eject.

Cause	What to do
The paper is too long.	Press the  load/eject button to eject the paper. Use paper that meets the paper requirements for this printer. See “Paper” in Appendix C.

Paper feed or paper jam problems occur frequently.

Cause	What to do
Sheets of paper are stuck together.	Fan the stack of paper and align the edges before loading.
The paper is too thin or rough.	Make sure the paper meets the paper requirements for this printer. See “Paper” in Appendix C.
Too many sheets are loaded in the sheet feeder.	Check the paper package and Chapter 7, “Printing on Special Paper”, for the amount of paper you can load in the sheet feeder .
The printable side of the paper is not correctly loaded.	Try turning the stack of paper over in the sheet feeder. Most packages of paper indicate the printable side with an arrow on the end of the package. Make sure the printable side is loaded face up.

Printing quality

The printed image has gaps or faint areas.

Cause	What to do
The print head nozzles are clogged.	Clean the print heads. See “Cleaning the Print Heads,” later in this chapter.
The paper quality has degraded due to age.	Use new paper.
The printer driver settings may not be correct.	Select Automatic on the printer driver’s Main menu (Windows) or Print dialog box (Macintosh), and make sure the Media Type setting is appropriate for the type of paper loaded in the printer.

For DOS users:

The Economy mode is set to On in the default-setting mode.	Turn Economy mode off in the default-setting mode. To enter the default-setting mode, see “Changing the Print Settings” in Appendix A.
--	--

The printed image is blurred.

Cause	What to do
Your paper is damp.	Do not store your paper in a damp or humid environment. Store the paper in its original packaging.
The printer driver settings may not be correct.	Select Automatic on the printer driver’s Main menu (Windows) or Print dialog box (Macintosh), and make sure the Media Type setting is appropriate for the type of paper loaded in the printer.

The printer driver's Ink setting is Color even though the printer is being used with an empty color ink cartridge installed.	Select Black as the Ink setting in your printer driver. See "Printing with an empty color ink cartridge" on page 9-8. Replace the color ink cartridge.
--	---


For DOS users:

The print direction setting is set to Bi-D in the default-setting mode.	Set the print direction to Uni-D in the default-setting mode. To enter the default-setting mode, see "Changing the Print Settings" in Appendix A.
---	---

The printed image is smeared.

Cause	What to do
The paper you loaded is too thick.	Open the printer cover and set the adjust lever to the "+" position. See Chapter 7, "Printing on Special Paper."
Special paper was loaded without the support sheet or a regular sheet of paper under it. Glossy film, glossy paper, and transparencies should be loaded with the support sheet or a piece of plain paper under them.	Load the support sheet or a piece of plain paper under the special paper. See Chapter 7, "Printing on Special Paper," or the instructions packed with your paper.
Multiple sheets of EPSON Photo Quality Glossy Film are loaded.	Load glossy film one sheet at a time with the loading support sheet or a piece of plain paper under it. If you need to load multiple sheets of glossy film, load only up to 30 sheets with the loading support sheet or a piece of plain paper under them and set the top margin of the page to 30 mm or more.

Ink has leaked on the platen. Wipe the inside of the printer as shown below with a soft, clean cloth.





Warning:

Be careful not to touch the gears inside the printer.

The print head nozzles are clogged. Clean the print heads. See “Cleaning the Print Heads” later in this chapter.

White horizontal lines appear in the printed image.

Cause	What to do
The print head nozzles are clogged.	Clean the print heads. See “Cleaning the Print Heads” later in this chapter.
One of the ink cartridges is low on ink.	Check the control panel to confirm that the  or  ink out light is flashing, and replace the appropriate ink cartridge.
The MicroWeave option in your printer driver is not selected.	Turn on MicroWeave in your printer driver.
The Media Type setting in your printer driver is incorrect.	Make sure the Media Type setting matches the type of paper loaded in the printer.

**Vertical or horizontal printed lines do not align.
White banding appears between color and black graphics.**

Cause	What to do
The print heads are misaligned.	Align the print heads with the Print Head Alignment utility. See “Aligning the Print Heads” later in this chapter.
The printing position is misaligned.	Make sure the High Speed option in your printer driver is not selected.
<i>For DOS users:</i> The print direction setting is set to Bi-D in the default-setting mode.	Set the print direction to Uni-D in the default-setting mode. To enter the default-setting mode, see “Changing the Print Settings” in Appendix A.

Printing quality is not what you expect.

Cause	What to do
The paper loaded is not the paper selected in your application or the printer driver.	Make sure you loaded the correct paper in the printer and that you selected the same media type in your application and/or the printer software. Make sure you are using paper that meets the paper requirements for this printer. See “Paper” in Appendix C.
You are not printing on the correct side of the paper.	Check the paper packaging for the correct side for printing; then load the printable side of the paper face up in the sheet feeder.

The printer driver settings are not correct.	Check the printer driver settings to make sure they are appropriate. If these settings are correct, check your application because some settings are overridden by application settings. Also, for more information on making printer driver settings, see online help for Windows, or Chapter 6 for Macintosh.
--	---

The High Speed setting is selected in the printer driver.	To obtain higher quality output, make sure High Speed is not selected.
---	--

For DOS users:

The print direction setting is set to Bi-D in the default-setting mode.	To obtain higher quality output, set the print direction to Uni-D in the default-setting mode. To enter the default-setting mode, see “Changing the Print Settings” in Appendix A.
---	--

Colors are different than you expect.	
--	--

Cause	What to do
The color print head nozzles are clogged.	Clean the color print head. See “Cleaning the Print Heads” later in this chapter.
Black ink is selected in your printer driver.	Set the Ink setting to Color.
The paper is not loaded printable side up.	Check that the printable side of the paper is facing up.
The Media Type setting does not match the paper loaded.	Change the Media Type setting in your printer driver to match the type of media you have loaded. Load media that matches the Media Type setting you selected in the printer driver.

The print head nozzles for a particular color of ink are clogged.	Clean the print heads. See “Cleaning the Print Heads” later in this chapter.
---	--

The ICM (Windows) or ColorSync (Macintosh) setting in your driver is not appropriate for your document.	Select Automatic as the Mode setting in the printer driver.
---	---

Your printer and monitor are not properly calibrated for color matching.	See the user’s guides of your image-editing software and your monitor for information on calibrating your system for color matching.
--	--

Since monitors and printers produce colors differently, printed colors will not always match on-screen colors perfectly.	See Appendix B, “Tips for Color Printing.”
--	--

Colors are not very vibrant.

Cause	What to do
The image was printed on wrong side of EPSON Ink Jet Paper.	Make sure that you are printing on the coated side of the paper. If necessary, flip over the paper and try printing again. If printing has not improved, clean the print heads as described later in this chapter.
The Media Type setting does not match the paper loaded.	Change the Media Type setting in your printer driver to match the type of media you have loaded, or load media that matches the Media Type setting.

**Color dots are missing in printed characters or graphics.
The printed color image has gaps or faint areas.**

Cause	What to do
The color print head nozzles are clogged.	Clean the color print head. See “Cleaning the Print Heads” later in this chapter.

For DOS users:

The Network I/F mode is set to Off.	Set the Network I/F mode to On in the default-setting mode. To enter the default-setting mode, see “Changing the Print Settings” in Appendix A.
-------------------------------------	---

**Black dots are missing in printed characters or graphics.
The printed black image is light or faint.**

Cause	What to do
The black print head nozzles are clogged.	Clean the black print head. See “Cleaning the Print Heads” later in this chapter.

Photographic images look grainy or rough.

Cause	What to do
The printing position is misaligned.	Align the print heads with the Print Head Alignment utility. See “Aligning the Print Heads” later in this chapter.
The resolution of the original image data or the resolution setting for the image in your image-editing software may be too low.	Increase the image resolution in your image-editing software. Keep in mind that higher resolution images take longer to print.

Dots are missing in printed characters or graphics.

Cause

What to do

For DOS users:

The Network I/F mode is set to Off.

Set the Network I/F mode to On in the default-setting mode. To enter the default-setting mode, see “Changing the Print Settings” in Appendix A.

The Status Monitor window does not appear when you are using Windows 95.

Cause

What to do



The Use Print Manager for this port option is checked in the Queue Setup window.

Make sure Use Print Manager for this port is not checked. Click the Start button, point to Programs, point to Epson, and click Spool Manager⁴. Then click Queue and Setup in the EPSON Spool Manager window.

The Enable bi-directional support for this printer option is not selected in the Spool Settings window.

You must select Enable bi-directional support for this printer **in the Spool Settings window to use the Status Monitor.** To access the Spool Settings window, click the Start button, point to Settings, and click Printers. Right-click the icon for your printer and choose Properties from the drop-down menu. Click the Details tab; then click Spool Settings. Select Enable bi-directional support for this printer.

When you clean the print heads using the Head Cleaning utility, the output quality does not improve.

Cause	What to do
You attempted to clean the print heads while the ink cartridges were low or out of ink.	Check the  or  ink out light. When the ink cartridges are low or out, the Head Cleaning utility has no effect. Replace the ink cartridges as needed. See page 9-2.

Increasing the Print Speed

Just as printing at a high resolution requires more processing time, printing in color takes longer than printing in black and white because the volume of data in a color document is much greater. For this reason, it is important to be selective in your use of color if you also require a faster print speed.

Even if your document requires the highest resolution and extensive use of color, for example when printing a camera-ready composite that includes color photographs, it may still be possible to optimize the print speed by adjusting other printing conditions. Keep in mind that changing some conditions to increase the print speed may also lower print quality.

The following table shows the factors that inversely affect print speed and print quality (increasing one will decrease the other).

Print quality Print speed	Lower Faster	Higher Slower
Printer driver settings		
Print Quality	Economy	SuperFine-1440 dpi
MicroWeave	Off	On
High Speed	On	Off

Print quality Print speed	Lower Faster	Higher Slower
Halftoning	No Halftoning	Error Diffusion
Data characteristics		
Image size	Small	Large
Resolution	Low	High

The table below shows the factors related to print speed only.

	Print speed	
	Faster	Slower
Printer driver settings		
Ink	Black	Color
Collate*	Off	On
Page reverse*	Off	On
Page rotate*	Off	On
Data characteristics		
Variety of colors	Grayscale **	Full color
Hardware resources		
System speed	Fast	Slow
HDD free space	Large	Small
Memory free space	Large	Small
Software status		
Running applications	One	Many
Virtual memory	Not in use	In use

*Varies depending on the printer software and application software you are using.

**Grayscale means using black ink only to print varying shades of gray, from pure black to pure white.

Cleaning the Print Heads

If you find that the printed image is unexpectedly faint or dots in the printed image are missing, you may be able to solve these problems by cleaning the print heads, which ensures that the nozzles are delivering ink properly.

You can clean the print heads from your computer using the Head Cleaning utility in the printer software.



If you are using DOS or you cannot clean the print heads with this utility, you can use the printer's control panel instead. For more details, see "Cleaning the Print Heads" in Appendix A.

Note:

- Print head cleaning uses ink. To avoid wasting ink, clean the print heads only if print quality declines.*
- Use the Nozzle Check utility to confirm that the print heads need to be cleaned.*
- Do not start the Head Cleaning or Nozzle Check utility while printing is in progress; otherwise your printout may be marred.*

To clean the print heads, follow these steps:

For Windows users:


1. When you clean the black print head, make sure the  ink out light is off. When you clean the color print head, make sure the  light is off.

Note:

If you try to clean the black print head while the black ink cartridge is low or empty, or try to clean the color print head while the color ink cartridge is low or empty, the print head cannot be cleaned until the ink cartridge is replaced.


2. Access the Utility menu as described in Chapter 4.


3. Click the Head Cleaning button.
4. Follow the on-screen messages.

While the printer performs the cleaning cycle, the  power light flashes. It takes about two minutes to clean each print head.



Caution:

Never turn off the printer while the  power light is flashing. Doing so may damage the printer.

5. When the  power light stops flashing, click Print nozzle check pattern in the Head Cleaning dialog box and use the pattern to confirm that the heads are clean and to reset the cleaning cycle.



Nozzle check pattern:

The above sample is in black and white, but the actual check pattern prints in color.

In the check pattern, if you find that any segments are missing from the test lines, you may need to repeat the head cleaning and print the nozzle check pattern again.

If print quality hasn't improved after repeating this procedure four or five times, try other recommendations listed in this chapter. If the print quality still has not improved, contact your dealer.


For Macintosh users:

1. When you clean the black print head, make sure the  ink out light is off. When you clean the color print head, make sure the  ink out light is off.

Note:


If you try to clean the black print head while the black ink cartridge is low or empty, or try to clean the color print head while the color ink cartridge is low or empty, the print head cannot be cleaned until the ink cartridge is replaced.


2. Choose Utility from the Print dialog box.
3. Click the Head Cleaning button.
4. Follow the on-screen messages.

While the printer performs the cleaning cycle, the  power light flashes. It takes about two minutes to clean each print head.



Caution:

Never turn off the printer while  power light is flashing. Doing so may damage the printer.

5. When the  power light stops flashing, click the Confirmation button in the Head Cleaning dialog box to print a nozzle check pattern and to reset the cleaning cycle. Use the check pattern to confirm the heads are clean. See page 10-29 to see a sample of the nozzle check pattern.

In the check pattern, if you find that any segments are missing from the test lines, you may need to repeat the head cleaning and print the nozzle check pattern again. If print quality hasn't improved after repeating this procedure four or five times, try other recommendations listed in this chapter. If the print quality still has not improved, contact your dealer.

Aligning the Print Heads

If you notice a misalignment of vertical or horizontal lines, you may be able to solve these problems from your computer using the Print Head Alignment utility in the printer software.

If you are using DOS or you cannot align the print heads with this utility, see Appendix A.

Note:

Do not start the Print Head Alignment utility while printing is in progress; otherwise your printout may be marred.

For Windows users:

1. Make sure paper is loaded in the sheet feeder.



Caution:

Use paper at least 210 mm (8.27 inches) wide; for example, A4 size paper loaded short edge first. Otherwise, the print heads will spray ink directly onto the platen. This may cause any documents you print afterwards to be smeared.

2. Access the Utility menu as described in Chapter 4.
3. Click the Print Head Alignment button.
4. Follow the messages on your screen to align the print heads.

For Macintosh users:

1. Make sure paper is loaded in the sheet feeder.





Caution:

Use paper at least 210 mm (8.27 inches) wide; for example, A4 size paper loaded short edge first. Otherwise, the print heads will spray ink directly onto the platen. This may cause any documents you print afterwards to be smeared.

2. Choose Utility from the Print dialog box. You see the Utility dialog box.
3. Click the Print Head Alignment button.
4. Follow the messages on your screen to align the print heads.

Ink Cartridge Problems

If output quality does not improve even after cleaning and aligning the print heads, you may need to replace one or both of the ink cartridges.

To replace an ink cartridge before the  or  ink out light is flashing or on, follow these steps.






If the  or  ink out light is flashing or is on, replace the empty ink cartridge as described in “Replacing an Ink Cartridge” on page x-xx.




Caution:

Once you remove an ink cartridge, it becomes unusable and cannot be reinstalled even if ink remains.



1. Make sure the printer is on.

2. Lower the output tray at the front of the printer; then, holding the tab on the cover, open the printer cover. You see the  and  cleaning buttons.
3. Hold down both the  and  cleaning buttons for more than three seconds until the print heads moves slightly to the left, which is the black ink cartridge replacement position. The  power light flashes.

If you want to replace the color ink cartridge, press the  cleaning button again after the print heads have moved. The print heads move to the color ink cartridge replacement position.



Caution:

Do not move the print heads by hand. Always press the  cleaning or the  cleaning button to move them; otherwise you may damage the printer.

Note:

The printer automatically moves the print heads back to their home (far right) position after 60 seconds if you have not started the procedure.

4. Complete the ink cartridge replacement procedure as described from step 4 of “Replacing an Ink Cartridge” on page 9-5.

Contacting Customer Support

If your printer is not operating properly and you cannot solve your problem with the troubleshooting information in this guide and online help, contact EPSON customer support services for assistance.

We will be able to help you much more quickly if you are able to give the exact information indicated below.

Serial number of your printer:

(The serial number label is on the back of the printer.)

Printer model:

Brand and model of your computer:

Printer software version:

(Click About on the printer driver's Main menu.)

Version of Windows (95, 3.1, etc.) you are using now:

Version of software applications you normally use with your printer:

For United Kingdom and the Republic of Ireland users

If you purchased your printer in the UK or the Republic of Ireland, Epson (UK) Limited provides a range of customer services and technical support.

Note:

For customers in the Republic of Ireland, please use the correct dialing codes when dialing the UK telephone numbers listed in the following sections. For example the Enquiry Desk fax number, 01442 227271, should be dialed as 0044 1442 227271 from the Republic of Ireland.

Enquiry Desk

The enquiry desk team can be contacted by calling 0800 220546 in the UK or 1 800 409132 from the Republic of Ireland, by faxing 01442 227271, and via the Internet at info@epson.co.uk. They can provide the following information:

- ❑ Information and literature on new EPSON products (also available from Faxon Epson)
- ❑ Where to purchase genuine EPSON consumables, accessories and options

Customer Support

Our Customer Support team can provide the following services:

- ❑ Technical information on installing, configuring, and operating your EPSON products
- ❑ Arranging for faulty EPSON products to be repaired within the warranty period

For information on contacting our Customer Support team, please see the Service and Support Information booklet that came with your EPSON product.

If this booklet is not available, details can be found on Faxon Epson faxback service, EPtec Bulletin Board Service or on Epson's World Wide Web site. See below for details.

Faxon Epson

Contact Faxon Epson faxback Service for:

- ❑ Literature and specifications on the latest EPSON products
- ❑ Support information including troubleshooting tips, switch settings and driver information

To use Faxon Epson, call 01442 227332 using a touch-tone phone. You will be asked to follow a simple routine to register your document request and once you have entered your telephone and fax numbers, Faxon Epson will fax a copy of the document catalogue to your fax machine.

When you have found the documents that you need in the catalogue, call Faxon Epson again and enter the document ID numbers. The documents will be faxed to you automatically.

EPtec - Bulletin Board Service

Call the Epson Bulletin Board Service on 01442 227479 for the latest drivers and utilities. No membership is required. Make sure that your communications software is set to 8 data bits, 1 stop bit, no parity bit, ANSI terminal mode emulation and a modem speed of up to 28.8 Kbps. Downloading protocols supported include Xmodem, Ymodem, and Zmodem. See the documentation that came with your communications software and modem for more information.

When you first connect to the Bulletin Board Service, you will be asked for your name, company name, phone number, and a password (which you can invent yourself).

World Wide Web

If you can connect to the Internet and have a Web Browser, you can access Epson's World Wide Web site at <http://www.epson.com>. Here you will find information on the latest EPSON products, software drivers, and answers to frequently asked questions.

For Australian users

EPSON Australia wishes to provide you with a high level of Customer Service. As well as this *User's Guide*, we provide the following sources for obtaining information:

EPSON FAXBACK

EPSON FAXBACK will fax you the latest specifications and pricing for most EPSON products offered in Australia. There is also technical information including details of the latest software and drivers available. Phone (02) 9903 9075 and the system will guide you through a number of choices before faxing the information to your fax machine.

EPSON Bulletin Board System

This is where you can download the latest software and drivers. Visit the BBS to check out the latest versions. If you have a modem, phone (02) 9417 5090.

Internet URL <http://www.epson.com.au>

Access the EPSON Australia World Wide Web pages. Worth taking your modem here for the occasional surf! You can get the same information as offered on the EPSON FAXBACK and the EPSON Bulletin Board plus more.

Your Dealer

Don't forget that your dealer can often help identify and resolve problems. The dealer should always be the first call for advice on problems. They can often solve problems quickly and easily as well as give you advice on the next step to take.

EPSON Helpdesk

EPSON Helpdesk is provided as a final backup to make sure our clients have access to advice. Operators on the Helpdesk can aid you in diagnosing hardware and software problems. They can also advise you on the latest EPSON products and where the nearest dealer or service agent is located. Many types of queries are answered here.

Access to the Helpdesk is at no charge to purchasers of new products for the first 12 months of that product's life. After that period, a different phone number is used and charges are debited to your telephone account. The current charge rates are specified when you ring the chargeable support number. You are asked to signify your acceptance before any charges are incurred.

The Helpdesk numbers are:

first 12 months	(02) 9903 9040
after 12 months	1 902 263 192
fax number	(02) 9903 9189

We encourage you to have all the relevant information on hand when you ring. The more information you prepare, the faster we can help solve the problem. This information includes the *User's Guide* for your EPSON product, type of computer, operating system, application programs, and any other information you feel is required.

For Hong Kong and Singapore users

Contact the phone or fax number shown below for your area:

Hong Kong

Phone: 2585 4300

Fax: 2827 7083

Singapore

Phone: 3377911

Fax: 3341185

Internet home page

EPSON Hong Kong has established a local home page in both Chinese and English on the Internet to provide users with the following information:

- Product information
- Answers to Frequently Asked Questions (FAQs)
- Latest versions of EPSON printer drivers

Users can access our World Wide Web home page at:
<http://www.epson.com.hk>.

Electronic bulletin board system

An electronic bulletin board system (BBS) is also available to obtain printer information and the latest versions of printer drivers. You can log on to the following number for the BBS service:

BBS: (852) 2827-4244

Technical Support Hotline

You can also contact our technical staff at the following telephone and fax numbers:

Phone: (852) 2585-4399

Fax: (852) 2827-4383

For Philippines users

To obtain technical support as well as other after sales services, users are welcome to contact the EPSON Philippines Representative Office at the telephone and fax numbers below:

Phone: (632) 813-6552

Fax: (632) 813-6545

BBS: (632) 814-0595

Appendix A

Using the Printer with DOS

Installing the Printer Software for DOS Programs	A-2
Changing the Print Settings	A-2
Using the default settings	A-4
Changing the default settings	A-7
Selecting fonts	A-8
Cleaning the Print Heads	A-10
Aligning the Print Heads	A-11
Using the print head alignment utility	A-12
Using the printer's control panel buttons	A-13
Using Power-On Functions	A-14



Installing the Printer Software for DOS Programs

Most DOS software programs include software for EPSON ESC/P 2™ printers. You need to select the correct printer software to take advantage of your printer's advanced built-in scalable fonts and graphics handling.

Most DOS programs require you to select from a list of printers to install the printer software. If your printer is not included in the list, contact your software manufacturer to obtain updated software.

If your printer software is not available, pick the first printer available in the list below.

When printing black only:

LQ-870/1170
LQ-570 (+)/1070(+)
SQ-870/1070
LQ-850
LQ-500

When printing black and color:

EPSON Stylus PRO
EPSON Stylus COLOR 500
EPSON Stylus COLOR II
LQ-860
LQ-2550

Note:

The drivers for the printers listed above do not provide all EPSON Stylus COLOR 800 features, such as 720-dpi printing, 1440-dpi printing and MicroWeave.

DOS software varies greatly. See the printing section of your software manual for information on accessing the printer driver settings.

Changing the Print Settings

You can change many print settings that control a variety of functions such as print direction and loading position. Because these settings take effect each time you turn on the printer, they are also called default settings.

The factory default settings are designed to meet the needs of most users, so you may not need to change them. The table below lists the features you can select in the default-setting mode.

Settings	Options
Print direction	Auto, Bi-D, Uni-D
Font	Courier, Roman, Sans Serif, Prestige, Script, Roman T, Sans Serif H, Draft
Pitch	10 cpi, 12 cpi, 15 cpi, 17.1 cpi, 20 cpi, Proportional
I/F mode	Auto, Parallel, Serial, Option
Auto I/F wait time	10 seconds, 30 seconds
Software	ESC/P 2, IBM X24E
Auto CR (IBM mode only)	Off, On
AGM (IBM mode only)	Off, On
Character table	PC437, PC850, PC860, PC861, PC863, PC865, Abicomp, BRASCII, Roman 8, ISO Latin 1, Italic U.S.A., Italic France, Italic Germany, Italic U.K., Italic Denmark 1, Italic Sweden, Italic Italy, Italic Spain 1
Auto line feed	Off, On
Network I/F mode	Off, On
Loading position	8.5 mm, 3 mm, Others
Economy	Off, On
Parallel I/F transfer rate	Fast, Normal

For more details, see the next section, “Using the default settings.” To change a setting, see “Changing the default settings” on page A-7.

Note:

Most software controls the character table and auto line feed. If your software controls these features, you may never need to set them with the control panel.



Using the default settings

Print direction

Your printer has three direction settings: Auto, Bi-D, and Uni-D.

Note:

Most software controls this setting. If your software does, you may never need to set it with the control panel.

Auto causes the printer to switch automatically between bidirectional (for text data) and unidirectional (for graphics data).

Bi-D causes the print heads to print in both directions. This provides the fastest printing. If vertical or horizontal lines are not aligned, align the print heads as described on page A-11.

Uni-D causes the print heads to print in one direction only. This provides maximum alignment for both graphics and character printing.

Font

Use this setting to select the default font.

Pitch

With this setting, you can specify the default character pitch (font size).

I/F mode

Your EPSON printer has both a parallel and serial interface, allowing you to share the printer between two computers.

If you select Auto, the printer automatically selects the interface that is receiving data, and uses that interface until the end of the print job. (A print job ends when no data is received from the selected interface for the amount of time specified in the Auto I/F wait time setting described below.)

Set this option to Parallel if you want the printer to ignore data from the serial interface or to Serial if you want the printer to ignore data from the parallel interface.

Select Option if you have installed an optional interface card and want the printer to ignore data from the built-in parallel interface.

If you don't know what type of interface your computer requires, check your computer manual.

Auto I/F wait time

If you select Auto as the I/F mode option, you can set the interface timeout to 10 seconds or 30 seconds.

The printer does not accept data from another interface unless it receives no data from the current interface for the period set in Auto I/F wait time.

Software

Use this setting to specify the type of control codes you want to use to control the printer.

If you select ESC/P 2, the printer emulates an EPSON ESC/P 2 printer. If you select IBM X24E, the printer operates as an IBM Proprinter™ X24E. If possible, select EPSON ESC/P 2 in your application programs. This will allow you to use the most advanced font and graphics handling available.

Auto CR

When Auto CR is on, the auto carriage return option performs a carriage-return line-feed (CR LF) operation whenever the print position exceeds the right margin. If this is off, the printer does not print characters beyond the right margin, and does not perform a linewrap until it receives a CR command. This feature is available when you select IBM X24E emulation as the Software setting.

AGM (Alternate Graphics Mode)

When AGM is on, the printer can use high-resolution 24-pin graphics commands. The default is off. This feature is available when you select IBM X24E emulation as the Software setting.

A

Character table

Character tables contain the characters and symbols used in different languages. The printer prints text based on the selected character table. For the available character tables, see Appendix C.

Auto line feed

When the Auto line feed feature is on, each carriage return (CR) code is accompanied by a line feed (LF) code. If your printed text is unexpectedly double-spaced, set this feature to Off. If text lines print on top of each other, set it to On.

Network I/F mode

If your printer is connected to a single computer, leave this feature off. If you want to share the printer with another computer, turn this feature on.

When this feature is on, data may be present in the printer's buffer even though the printer is not printing. Always make sure the printer does not receive data before turning off the printer.

Loading position

If you want to print more lines on a page, set this feature to 3 mm. If you set the top margin with your software, that setting is added to the default-setting value.

Economy

When Economy mode is on, the printer uses less ink by printing fewer dots per character. Use this mode for rough drafts only.

Parallel I/F transfer rate

This setting specifies the I/F transfer rate. For most printing, leave this setting set to Fast. If you encounter problems, set it to Normal.

Changing the default settings

To change the printer's default settings, you use the control panel buttons; the control panel lights show your selections.


1. Make sure the printer is turned off and paper is loaded in the sheet feeder.




Note:

Use paper at least A4 (210 mm/8.27 inches) size or wider. Otherwise, the print heads will spray ink directly onto the platen, which could mar future printouts.


2. Hold down the  cleaning button and turn on the printer to enter the default-setting mode.

The printer loads a sheet of paper and prints a brief summary and instructions. It instructs you to select the language that you want messages printed in (English, French, German, Italian, or Spanish).

3. Press the  cleaning button until the following lights indicate the language of your choice:

Language			
English	●	●	●
French	○	●	●
German	◌̈	●	●
Italian	●	○	●
Spanish	○	○	●

○ = On, ● = Off, ◌̈ = Flashing

4. Press the  cleaning button to print the current default settings and the next instructions in the language you selected. The printed instructions include submenu tables that list all of the settings you can change and show you how the control panel lights appear for each selection. Use the instruction sheets to change the settings from the control panel.



5. After making your changes, exit the default-setting mode by turning off the printer.

Note:

- You may exit the default-setting mode any time by turning off the printer. Any changes you have made remain in effect until you change them again.
- If you want to check the current default settings, enter the default-setting mode again and print the current settings. The current settings are indicated with arrows.

Selecting fonts

Your printer has eight built-in character fonts including two EPSON fonts: EPSON Roman T and EPSON Sans Serif H. (Roman T is similar to the Times™ font; Sans Serif H is similar to Helvetica™)

To select a font, enter the default-setting mode. See “Changing the default settings” on page A-7.

Note:

Font selections you make with your software override your printer’s control panel selections. For best results, use your software to select fonts.

The table below shows the available fonts.

Fonts	Sample
EPSON Courier	
EPSON Roman T	
EPSON Sans Serif H	
EPSON Roman	
EPSON Sans Serif	
EPSON Prestige	
EPSON Script	
Draft	

Note:

- ❑ *Roman T and Sans Serif H fonts are available in proportional spacing only.*
- ❑ *Some of the character tables might not be able to print with EPSON Roman T and EPSON Sans Serif H fonts. In these cases, selected character tables are printed with EPSON Roman.*

Scalable fonts

The size of the Roman, Sans Serif, Roman T, and Sans Serif H fonts can be selected from 8 to 32 points in 2-point increments through your software or by sending an ESC/P 2™ command. See the documentation that came with your software for information on selecting the size of scalable fonts.

EPSON
Roman

EPSON
Roman T

scalable sample

EPSON
Sans Serif



EPSON
Sans Serif H






Cleaning the Print Heads







If print quality diminishes, use the printer's built-in print head cleaning cycle to ensure that the nozzles are delivering ink properly. You must clean the color and black print heads separately.

To avoid wasting ink, clean the print heads only if print quality declines.

1. Make sure the printer is on.
2. Make sure the output tray at the front of the printer is lowered; then open the printer cover. You see the  and  cleaning buttons.
3. Make sure the corresponding light for the print head you want to clean is off.


Note:

If the  or  ink out light is on or flashing, this operation will start the ink cartridge replacement procedure. If you do not want to replace an ink cartridge at this time, press the  load/eject button to return the print heads to their home position.

4. Press the  or  cleaning button for three seconds to clean the black or color print head. The printer starts cleaning the print head and the  power light begins flashing. If you want to clean the other print head, wait until the  power light stops flashing, then press the other cleaning button ( or ) for three seconds. It takes about two minutes to clean each print head.



Caution:

Never turn off the printer while the  power light is flashing. Doing so may damage the printer.

Note:

You cannot clean both black and color print heads at the same time.

5. Close the printer cover.

6. After the ☺ power light stops flashing, print a few lines to confirm that the head is clean and to reset the cleaning cycle.

If you entered the print head cleaning mode while the printer was printing a document, the printer feeds paper and resumes printing automatically.


If the print quality does not improve, repeat step 4, then print a few lines to check the output. If print quality hasn't improved after repeating this procedure four or five times, see Chapter 10, "Troubleshooting." If the print quality still has not improved after following the recommendations listed in Chapter 10, contact your dealer.

Aligning the Print Heads

When you find that the printed image is fuzzy, or the vertical or horizontal lines in your printout are not properly aligned, you may need to align the print heads with the EPSON Print Head Alignment Utility. This utility aligns the print heads to print images clearly. You may need to align the print heads when you transport the printer or move it to a different environment.

Using the print head alignment utility

The print head alignment utility includes both black and color alignment features. To install this utility on your hard drive, insert the EPSON Printer Software CD-ROM into your CD-ROM drive and then type `D:\SETUP` (If your CD-ROM drive uses a different drive letter or you are using the floppy version, substitute it for `D:\`) at the DOS prompt. Depending on the country, the CD-ROM may contain multiple-language versions of the printer software. If the procedure above produced an error, type `D:\` then specify your preferred language by typing English, Francais, German, Italian, Portugal, or Spanish, followed by `\SETUP`. Then press Enter. Follow the directions on the screen. After running the setup program, change to the drive and directory that contains the utility (or set the path to the directory). Then type `EPCALIB` and press Enter. The following window appears:



Make sure your printer is selected. Click Next, then follow the directions on the screen.

Note:

This utility is designed to be run in DOS with or without a mouse.





Using the printer's control panel buttons

If you cannot use the print head alignment utility program that came with your printer, then follow these steps to align the print heads.

1. Make sure that the printer is off and paper is loaded in the sheet feeder.

Note:

Use paper at least A4 (210 mm/8.27 inches) size or wider. Otherwise, the print heads will spray ink directly onto the platen, which could mar future printouts.

2. Open the printer cover. You see the  and  cleaning buttons.
3. Hold down the  load/eject button and the  cleaning button and turn on the printer to enter the print head alignment mode. Release the buttons.

The printer prints an instruction sheet in English, French, German, Italian, and Spanish that shows you how to align the print heads. Follow these instructions.

4. After aligning the print heads, exit the print head alignment mode by turning off the printer.

Using Power-On Functions


The functions below (in italics) are available if you hold down the corresponding control panel buttons while turning on the printer:

LQ self test =  load/eject button

Checks the paper length and prints a self-test at 360 dpi. See “Self testing” on page 10-4.

Draft self test =  cleaning button

Checks the paper length and performs self-test printing at 180 dpi. See “Self testing” on page 10-4.

Default setting =  cleaning button

Enters the default-setting mode. See “Changing the Print Settings” in this chapter.

Hex dump =  load/eject +  cleaning buttons

Prints the data sent from the computer in hexadecimal code. See “Hex dump mode” on page 10-6.

Print head alignment =  load/eject +  cleaning buttons

Enters the print head alignment mode. See “Aligning the Print Heads ” on page A-11 for details.

Appendix B

Tips for Color Printing

Basics of Color B-2
Image Resolution and Image Size B-5
Basics of Color Documents B-7



Basics of Color

This section describes the basic properties of color, the relationships between colors, and how to use color to improve the quality of your printed documents.

Properties of color

Color is composed of three properties: Hue, Saturation, and Brightness.

Hue The name of the color, such as red, blue, or violet. The circle that represents the relationship between all hues is called the hue circle.

Saturation The vividness of the color. This represents the amount of gray in proportion to the hue.

Brightness The relative lightness or darkness of the color.

The method for representing these properties is called the Munsell renotation color system. The hue circle and the Munsell renotation color system are useful to understand the properties of color. See also the *Color Guide*.

Synchronizing monitor colors and printer colors

Your printer produces images by printing tiny patterns of ink dots on paper. It uses the colors cyan (C), magenta (M), yellow (Y), and black (K) to create a blending effect that makes you think you are seeing millions of colors. This type of color, produced by pigments that absorb some colors of light and reflect others, is called subtractive.


Note:

In theory, pure cyan, magenta, and yellow should produce black, but actually they produce a muddy brown and must be combined with black ink to produce a true black (K).


Your monitor produces images by illuminating color phosphors on the screen with an electron gun. (A phosphor is a substance that gives off light when irradiated.) Each screen point (pixel) has three colored phosphors: red (R), green (G), and blue (B).

Since the printer and monitor produce color images differently, and also the available range of color produced by the monitor and printer are different, the image on the screen does not exactly match your printed output all of the time. If you want to adjust, or calibrate, the printed color to more closely match the on-screen color, you may have to experiment with the printer driver settings.

Additionally, color management software is available from a variety of software and monitor companies to help you match colors produced by your monitor and printer. See your image-editing software user's guide for information on color matching.



The range of colors that can be displayed:



Note:

When printing a scanned image, you may find it more difficult to match colors. Because scanners create the original image data using CMYK, the data format of your image will be changed twice.

Process of color printing

A printer produces color images by printing tiny patterns of ink dots using CMYK colors as mentioned in the previous section. Because most ink jet printers are not able to print different gradations of the three primary colors, they must use a halftoning method in order to represent millions of colors or the gradation of colors as follows:



Dithering and error diffusion are the most commonly used halftoning methods.

Dithering

Dithering uniformly aligns individual dots of different colored inks to create the appearance of neutral colors. This method is suitable for printing documents that contain large areas of solid color, such as bar charts and graphs.

Error diffusion

Error diffusion randomly places individual dots of different colors to create the appearance of neutral colors. By randomly placing dots, the printer can achieve excellent colors and subtle color gradation. This method is suited for printing documents that contain finely detailed graphics or photographic images.



Image Resolution and Image Size


The resolution of your original image affects the quality of your printouts. Generally, the higher the resolution, the better the print quality. However, keep in mind that the higher the resolution, the longer the wait for processing and printing a document.

Generally, the printed image size is in inverse proportion to the image resolution, as shown below. The larger the image size, the lower the image resolution. Conversely, the smaller the image size, the higher the image resolution.

Note:

Some applications have a function that can correct this relationship.





Since increasing the image size means decreasing the image resolution, you must take care that print quality or color tone is not degraded when working with images pasted into documents created with word processing software. To avoid print quality and color tone problems, change the size and the resolution of the image in your graphics application before pasting it into your document.

Basics of Color Documents

To help you use color to maximize your document's impact on its readers, determine the who, what, when, where, why, and how of color printing.

Know WHO your readers are and WHAT your purpose is

Your documents are intended to communicate information, opinions, or feelings to one or more people and also to get results. Therefore, first you need to think about who is going to see your work: customer, co-worker, or other; and what your purpose is: to advise, sell, propose, and so on.

For example:

A marketing proposal with generous quantities of bright, fluorescent colors might fail to impress a conservative accounting firm, yet win over a music video company.

Know WHEN to use color

While color can enhance any document, you need to decide when color helps expand understanding of your message and when it distracts the reader. Sometimes a serious business message is best delivered without additional colors. (Remember that white and black are colors, too.)

For example:

A job offer letter to a prospective employee works best in black and white, while a list of safety rules benefits from attention-getting color.

Decide WHERE color will most benefit your document

If you use color on every page or all over a page, you may lose not only the impact of color, but also the clarity and readability of your work. When used consistently and strategically, color breaks up the monotony of black-and-white text reading.

Note:

- Avoid placing too many color pictures, tables, or icons on a page.*
- Size your color images so that they do not overpower text or graphics.*
- Avoid using too much colored text. It is more difficult to read than black-on-white or white-on-black text.*

Know WHY you are using color


Color adds interest and clarity, and makes documents appear easier to understand. Just as you use fonts and graphics to create appeal and capture attention, color provides an additional visual interpretation of a document that influences the reader.

For example:


An overhead presentation of sales results by territory is far more interesting and memorable if you show the figures with colored charts and graphs.

Know How to select colors


- Use just one hue in the hue circle to make your document unified. Modify saturation or brightness to add interest.*



- Use contrasting hues to make your work more eye-catching.*



- Use of complementary colors in documents is generally not recommended.*



- Determine a rule for using color throughout the document.*

Note:

See the Color Guide for the hue circle.

Appendix C

Specifications

Technical Specifications	C-2
Printing	C-2
Paper	C-4
Ink cartridges	C-7
Mechanical	C-8
Electrical	C-9
Environmental	C-9
Safety approvals	C-10
Interface Specifications	C-10
Parallel interface	C-10
Serial interface	C-11
Initialization	C-12
Default settings	C-13
Command List	C-14
ESC/P 2 control codes	C-14
IBM X24E emulation control codes	C-15
Character Tables	C-16
International character sets	C-20
Characters available with ESC (^ command	C-21

Technical Specifications

Printing

Printing method: On-demand ink jet
Nozzle configuration: Monochrome (black) 128 nozzles
(32 × 4 staggered)
Color 64 nozzles × 3 (cyan, magenta, yellow)

Printable columns and printing speeds:

Character mode:

Character pitch (characters per inch)	Printing column	Draft speed	LQ printing speed
10	80	533 cps	400 cps
12	96	640 cps	480 cps
15	120	800 cps	600 cps
17 (10 condensed)	137	912 cps	684 cps
20 (12 condensed)	160	1067 cps	800 cps

cps stands for characters per second.

Raster graphics mode:

Print quality	Printable area	Available dots	CR speed
180 dpi × 180 dpi	8.27 inches	1488	26.7 ips
360 dpi × 360 dpi	8.27 inches	2976	20 ips
720 dpi × 720 dpi	8.27 inches	5952	20 ips
1440 dpi × 720 dpi	8.27 inches	5952	10 ips

ips stands for inches per second.

Resolution:	Maximum 1440 dpi × 720 dpi
Print direction:	Bidirectional with logic seeking for text and graphics. (Auto print direction can be set in the default-setting mode.)
Control code:	ESC/P 2 and expanded raster graphics code IBM X24E emulation code
Line spacing:	1/6 inch, 1/8 inch, or programmable in 1/360-inch increments
Paper feed speed:	100 milliseconds per 1/3-inch line
Input buffer:	32KB
Bitmap fonts:	

Font	10 cpi	12 cpi	15 cpi	Proportional
EPSON Roman	○	○	○	○
EPSON Sans Serif	○	○	○	○
EPSON Courier	○	○	○	—
EPSON Prestige	○	○	○	—
EPSON Script	○	○	○	—

Select other font/pitch combinations using ESC/P 2 commands.
See the Command List later in this appendix.

Scalable fonts:

Font	Minimum point size	Maximum point size	Increments
EPSON Roman	8	32	2
EPSON Sans Serif	8	32	2
EPSON Roman T	8	32	2
EPSON Sans Serif H	8	32	2

Each font has four variations: normal, bold, italic, and bold italic.

Character tables:	1 italic and 10 graphics character tables
Character sets:	14 international character sets and 1 legal character set

Paper

Note:

Since the quality of any particular brand or type of paper may be changed by the manufacturer at any time, EPSON cannot attest to the quality of any non-EPSON brand or type of paper. Always test samples of paper stock before purchasing large quantities or printing large jobs.

Single sheets:

Size	A4 (210 mm × 297 mm) A5 (148 mm × 210 mm) B5 (182 mm × 257 mm) Letter (216 mm × 279 mm) Legal (216 mm × 356 mm) Half Letter (139.7 mm × 215.9 mm) Executive (184.2 mm × 266.7 mm)
Paper types	Plain bond paper, special papers distributed by EPSON
Thickness	0.08 mm to 0.11 mm (0.003 to 0.004 inch)
Weight	64 g/m ² (17 lb) to 90 g/m ² (24 lb)

Transparencies, Glossy film, Glossy paper:

Size	A4 (210 mm × 297 mm) Letter (216 mm × 279 mm) A6 (105 mm × 148 mm)* *Glossy film only
Paper types	Special papers distributed by EPSON

Self Adhesive sheets:

Size	A4 (210 mm × 297 mm)
Paper types	Special paper distributed by EPSON

Photo paper

Size	4 × 6" (102 mm × 152 mm)
Paper types	Special papers distributed by EPSON

Envelopes:

Size	No. 10 (240 mm × 104 mm) DL (220 mm × 110 mm) C6 (114 mm × 162 mm)
Paper types	Plain bond paper, air mail
Thickness	0.16 mm to 0.43 mm (0.006 to 0.017 inch)
Weight	45 g/m ² (12 lb) to 75 g/m ² (20 lb)

Index cards:

Size	A6 (105 mm × 148 mm) 5 × 8 inches (127 mm × 203 mm) 10 × 8 inches (254 mm × 203 mm)
Paper types	Special papers distributed by EPSON
Thickness	0.23 mm (0.0091 inch)
Weight	188 g/m ²

Note:


- Poor quality paper may reduce print quality and cause paper jams and other problems. If you encounter problems, switch to a higher grade of paper.*
- Do not load curled or folded paper.*
- Ink jet paper, envelopes, glossy film, glossy paper, and transparencies are only usable under normal conditions:*

Temperature	15 to 25°C (59 to 77°F)
Humidity	40 to 60% RH
- EPSON Photo Quality Glossy Paper and Photo Quality Self Adhesive Sheets should be stored under the following conditions:*


Temperature	15 to 30°C (59 to 86°F)
Humidity	20 to 60% RH

Printable area:

Single sheets/index cards



Envelopes



A: The minimum top margin is 3.0 mm (0.12 inch).

When loading multiple sheets of EPSON Photo Quality Film, the minimum top margin is 30 mm (1.2 inches).

B: The minimum left margin is 3.0 mm (0.12 inch).

The minimum right margin for single sheet paper is 3.0 mm (0.12 inch) except for letter and legal size paper. The minimum right margin for letter and legal size paper is 9.0 mm (0.35 inch).

The minimum right margin for envelopes is as follows:
7 mm (0.28 inch) for DL envelopes.
28 mm (1.10 inches) for No. 10 envelopes.
3 mm (0.12 inch) for C6 envelopes.

C: The minimum bottom margin is 14.0 mm (0.54 inch).

Note:

Always load paper into the sheet feeder short edge first. However, envelopes should be loaded long edge first.

Ink cartridges

Black ink cartridge (S020108):

Color	Black
Print capacity*	900 pages/A4 (ISO/IEC 10561 Letter Pattern at 360 dpi)
Cartridge life	2 years from production date if unopened; 6 months if opened at 25°C (77°F)
Temperature	Storage: -20 to 40°C (-4 to 104°F) 1 month at 40°C (104°F) Transit: -30 to 60°C (-22 to 140°F) 1 month at 40°C (104°F) 120 hours at 60°C (140°F) Freezing:** -16°C (3.2°F)
Dimensions	27.8 mm (W) × 52.7 mm (D) × 38.5 mm (H)

Color ink cartridge (S020089):

Colors	Cyan, Magenta, and Yellow
Print capacity*	300 pages (A4, 360 dpi, 5% duty each color)
Cartridge life	2 years from production date if unopened; 6 months if opened at 25°C (77°F)
Temperature	Storage: -20 to 40°C (-4 to 104°F) 1 month at 40°C (104°F) Transit: -30 to 60°C (-22 to 140°F) 1 month at 40°C (104°F) 120 hours at 60°C (140°F) Freezing:** -18°C (-0.4°F)
Dimensions	42.9 mm (W) × 52.7 mm (D) × 38.5 mm (H)

* The print capacity may vary, depending on how often you use the print head cleaning function.

** It thaws and is usable after approximately 3 hours at 25°C (77°F).



Caution:

- EPSON recommends the use of genuine EPSON ink cartridges. Other products not manufactured by EPSON may cause damage to your printer not covered by EPSON's warranties.
- Do not use an ink cartridge if the date on the package has expired.

Mechanical

Paper feed method:	Friction
Paper path:	Sheet feeder, rear entry
Sheet feeder capacity:	100 sheets at 64 g/m ² (17 lb) paper
Total print volume:	75,000 pages (A4, Text)
Dimensions:	Storage Width: 475 mm (18.7 inches) Depth: 274 mm (10.7 inches) Height: 177 mm (7.4 inches) Printing (standard) Width: 475 mm (18.7 inches) Depth: 610 mm (24.0 inches) Height: 315 mm (12.4 inches) Printing (on transparencies) Width: 475 mm (18.7 inches) Depth: 692 mm (27.2 inches) Height: 202 mm (7.95 inches)
Weight:	6.5 kg (14.3 pounds) without the ink cartridges

Electrical

C

	120V Model	220–240V Model
Input voltage range	103.5 to 132V	198 to 264V
Rated frequency range	50 to 60 Hz	
Input frequency range	49.5 to 60.5 Hz	
Rated current	0.4A	0.2A
Power consumption	Approx. 18W (ISO10561 Letter Pattern)	

This product is also designed for IT power system with phase to phase voltage 220-240V.

Note:

Check the label on the back of the printer for the voltage of your printer.

Environmental

Temperature:

Operation: 10 to 35°C (50 to 95°F)
Storage: ^{*}-20 to 60°C (-4 to 140°F)
1 month at 40°C (104°F)
120 hours at 60°C (140°F)

Humidity:

Operation: 20 to 80% RH
Storage: ^{**}5 to 85% RH

* Stored in shipping container

**Without condensation

Safety approvals

Safety standards:

U.S. model UL 1950 with D3, CSA C22.2 No.950 with D3

European model EN60950 (VDE and NEMKO)

EMC:

U.S. model FCC part 15 subpart B class B, CSA C108.8 class B

European model EN 55022 (CISPR Pub. 22) class B
EN 50082-1
EN 61000-3-2
EN 61000-3-3

Australian model AS/NZS 3548 class B

Interface Specifications

Your printer is equipped with an 8-bit parallel interface and a serial interface.

Parallel interface

The built-in parallel interface has the following characteristics:

Foward channel

Data format: 8-bit parallel, IEEE-1284 compatibility mode

Synchronization: $\overline{\text{STROBE}}$ pulse

Handshake timing: BUSY and $\overline{\text{ACKNLG}}$ signals

Signal level: TTL compatible

Connector: 57-30360 Amphenol connector or equivalent

Reverse channel

Transmission mode:	IEEE-1284 Nibble mode
Connector:	57-30360 Amphenol Connector or equivalent
Synchronization:	Refer to the IEEE-1284 specification
Handshaking:	Refer to the IEEE-1284 specification
Signal level:	IEEE-1284 Level 1 device
Data transmission timing:	Refer to the IEEE-1284 specification

Serial interface

The printer's built-in serial interface is based on the RS-423 standard. This interface has the following characteristics:

Standard:	Based on RS-423
Synchronization:	Synchronous
Bit rate:	Approx. 1.8 Mbps
Handshaking:	X-ON/X-OFF DTR protocol
Word format:	
Data bit	8 bits
Parity bit	None
Start bit	1 bit
Stop bit	1 bit
Connector:	8-pin mini-circular connector
Recommended cable:	Apple System Peripheral-8 cable (Part number M0197)

Optional interface

The available interfaces are listed in Chapter 8. Please see the specifications in the user's guide packed with the optional interface card.

Initialization

The printer can be initialized (returned to a fixed set of conditions) in these ways:

Hardware initialization	<ul style="list-style-type: none">* The printer is turned on.* The printer receives an INIT signal from the parallel interface.
Software initialization	<ul style="list-style-type: none">* Software sends the ESC @ (initialize the printer) command. The last panel settings are kept.

Hardware initialization

When the printer is turned on, the printer mechanism is initialized and the input data buffer, print buffer, and user-defined characters are cleared. Printer settings are returned to their default values as shown in the table below. However, if the printer is turned on within ten seconds after turning it off, the printer mechanism is not initialized.

Software initialization

Clears the print buffer and returns printer settings to the default values shown below. However, software initialization does not initialize the printer mechanism or clear the data buffer and user-defined characters.

Default settings

The table below shows the default settings that take effect when the printer is initialized.

Item	Default setting
Top-of-form position	Current paper position
Page length	Single sheets: 22 inches
Left and right margins	Cancelled
Line spacing	1/6-inch line spacing
Character pitch	Last font selected using default-setting mode
Vertical tab position	Cleared
Horizontal tab positions	Every eight characters
Font selection	Last font selected using default-setting mode
Special printing effects	Cancelled (except condensed and economy printing)
User-defined character set	Hardware/control panel initialization: cleared Software initialization: deselected only

Command List

This section lists the available printer commands by topic. Your printer works with the following commands.

ESC/P 2 control codes

Selecting EPSON ESC/P 2 printer in your software allows you to use the most advanced font and graphics handling available. See the *ESC/P Reference Manual* for details.

General operation:

ESC @, ESC U, ESC EM

Paper feeding:

CR, FF, LF, ESC 0, ESC 2, ESC 3, ESC +

Page format:

ESC (C, ESC C, ESC C 0, ESC Q, ESC I, ESC (c, ESC N, ESC O

Print position motion:

ESC \$, ESC \, ESC (V, ESC (v, ESC D, HT, ESC B, ESC J, VT

Font selection:

ESC k, ESC x, ESC X, ESC P, ESC M, ESC g, ESC p, ESC 4, ESC 5, ESC E, ESC F, ESC !

Font enhancement:

ESC W, DC 4, SO, DC2, SI, ESC w, ESC G, ESC H, ESC T, ESC S, ESC -, ESC (-, ESC q

Spacing:

ESC Space, ESC c, ESC (U

Character handling:

ESC t, ESC (t, ESC R, ESC %, ESC &, ESC :, ESC 6, ESC 7, ESC (^

Bit image:

ESC *

Graphics:

ESC (G, ESC ., ESC (i, ESC (e, ESC (\, ESC (s

Color:

ESC r, ESC (r

Printing mode:

ESC (K

IBM X24E emulation control codes

This printer emulates the IBM Proprinter with the following commands. For detailed information, see IBM's X24E reference manual.

General operation:

NUL, DC3, ESC j, BEL, CAN, DC1, ESC Q, ESC [K, ESC U

Paper feeding:

FF, LF, ESC 5, ESC A, ESC A (AGM*), ESC 0, ESC 1, ESC 2, ESC 3, ESC 3 (AGM*), CR

Page format:

ESC C, ESC X, ESC N, ESC O, ESC 4

Print position motion:

ESC d, ESC R, ESC D, HT, ESC B, VT, ESC J, ESC J (AGM*)

Font selection:

DC2, ESC P, ESC :, ESC E, ESC F, ESC I

Font enhancement:

DC4, SO, ESC SO, ESC W, ESC [@, SI, ESC SI, ESC G, ESC H, ESC T, ESC S, ESC -, ESC _

Spacing:

BS, SP, ESC [\

Character handling:

ESC 6, ESC 7, ESC [T, ESC ^, ESC \

Bit image:

ESC K, ESC L, ESC Y, ESC Z, ESC [g, ESC * (AGM*)

* Alternate Graphics Mode

Character Tables

These character tables are selected with the default-setting mode or by using software commands.

All tables except the italic character table are the same as the PC437 table for hex codes 00 through 7F, so only the PC437 table is shown completely. The rest of the tables show only the characters for hex codes 80 through FF.

PC437 (U.S./Standard Europe)

PC850 (Multilingual)

PC860 (Portuguese)

C

PC861 (Icelandic)

PC863 (Canadian-French)

PC865 (Nordic)

Abicomp

BRASCI

Roman 8

Italic

No characters are available for hex code 15 in the italic character table.

International character sets

You can select one of the following international character sets with the default-setting mode or the ESC R command. For example, when you select “Italic France,” the characters in the “France” row on the table below are used in the italic character table.

The following eight international character sets can be selected with the default-setting mode or with the ESC R command.

The following seven additional sets can be selected only with the ESC R command.

Characters available with ESC (^ command

To print the characters in the table below, use the ESC (^ command.

A black square containing a white capital letter 'C' in the top right corner of the page.

Glossary

The following definitions apply specifically to printers.

AGM (Alternate Graphics Mode)

An option that improves the quality of your printout when using the printer in IBM X24E emulation mode.

application

A software program that helps you carry out a particular task, such as word processing or financial planning.

ASCII

American Standard Code for Information Interchange. A standardized coding system for assigning numerical codes to letters and symbols.

auto line feed

When this feature is selected in the default-setting mode, each carriage-return code (CR) is automatically followed by a line-feed (LF) code.

banding

The horizontal lines that sometimes appear when printing graphics. This occurs when the print head carriage return is misaligned. See also *MicroWeave*.

bidirectional printing

Printing in which the print heads print in both directions. This increases the speed of printing.

bit

A binary digit (0 or 1), which is the smallest unit of information used by a printer or computer.

brightness

The lightness or darkness of an image.

buffer

The portion of the printer's memory used to store data before printing it.

byte

A unit of information consisting of eight bits.

characters per inch (cpi)

A measure of the size of text characters, sometimes referred to as pitch.

character table

A collection of letters, numbers, and symbols that provides you with the characters used in a particular language.

CMYK

Cyan (blue-green), magenta, yellow, and black. These colored inks are used to create the subtractive system array of printed colors.

ColorSync

Macintosh software that is designed to help you get WYSIWIG (what you see is what you get) color output. This software prints colors as you see them on your screen.

control code

Special codes used to control printer functions, such as performing a carriage return or line feed.

cpi (characters per inch)

A measure of the size of text characters, sometimes referred to as pitch.

default

A value or setting that takes effect when the equipment is turned on, reset, or initialized.

default-setting mode

A feature that allows experienced users to make special settings that they may not be able to make in their software or the driver.

dithering

A halftoning method in which dots are arranged in an orderly pattern. Dithering works best for printing images with solid colors, such as charts and graphs. See also *Halftoning*.

dot matrix

A method of printing in which each letter or symbol is formed by a pattern (matrix) of individual dots.

dpi

Dots per inch. The dpi measures the resolution. See also *resolution*.

driver

A software program that sends instructions to a computer peripheral to tell it what to do. For example, your printer driver accepts print data from your word processing application and sends instructions to the printer on how to print this data.

economy printing

Printing in which images are printed with fewer dots to save ink.

emulation

Emulation means using the control codes of another kind of printer. Most users will never need to make this setting but some experienced users may find this helpful.

Error Diffusion

This halftoning setting smooths out edges by randomly placing dots of varying colors. This has the opposite effect of the Finest Detail setting.

ESC/P

Abbreviation for Epson Standard Code for Printers. This system of commands gives you control of your printer from your computer. It is standard for all EPSON printers and supported by most application programs for personal computers.

ESC/P 2

The enhanced version of the ESC/P printer command language. Commands in this language produce laser-like features, such as scalable fonts and enhanced graphics printing.

Finest Detail

This printer driver setting automatically makes your printed images sharper and clearer. This has the opposite effect of the Error Diffusion setting. Be aware that this may increase the time required for printing.

font

A style of type designated by a family name.

grayscale

A scale of shades of gray from black to white. Grayscale is used to represent colors when printing with black ink only.

halftones

Patterns of black or colored dots used to reproduce an image.

halftoning

A method of using dot patterns to represent an image. Halftoning makes it possible to produce varying shades of gray using only black dots, or a nearly infinite array of colors using only a few colors of dots.

hex dump

A troubleshooting feature that helps advanced users find the cause of communication problems between the printer and the computer. When the printer is in hex dump mode, it prints each code it receives in hexadecimal notation and ASCII characters. Also called data dump.

high speed printing

Printing in which images are printed in both directions. This provides faster printing. This is also called bidirectional printing.

initialization

Returns the printer to its defaults (fixed set of conditions). This happens every time you turn on the printer or reset the printer.

ink jet

A method of printing in which each letter or symbol is formed by precisely spraying ink onto paper.

interface

The connection between the computer and a peripheral such as a printer. Generally, printers have two interfaces, parallel and serial. A parallel interface transmits data one byte, or eight bits, at a time. A serial interface transmits data one bit at a time.

italic

A typestyle in which the characters slant. *This sentence is italicized.*

line feed

A control code that advances the paper one line space.

loading position

The position to which the paper is automatically loaded.

IPS

Inches per second. This scale is used to measure the print head speed.

media

Materials upon which data is printed, such as envelopes, plain paper, special paper, and transparency film.

MicroWeave

Printing in which images are printed in finer increments to reduce the possibility of banding and to produce laser-like images. See also *banding*.

monochrome

This means printing with only one color of ink, which is generally black ink.

parallel interface

See *interface*.

power-on functions

These are special functions, like a self test, that you can do by holding down a control panel button while turning on the printer.

printable area

The area of a page on which the printer can print. It is smaller than the physical size of the page due to margins.

printer driver

A software program that sends commands for using the features of a particular printer. Often shortened to “driver.” See also *driver*.

print head alignment mode

This feature allows you to align the print heads if you can't use the print head alignment utility. See also *print head alignment*.

print head alignment

A maintenance procedure you should perform when the black and color inks on your printout are misaligned or the printout seems fuzzy.

print server

The print server acts as a post office for all print jobs sent over a network. It receives the jobs and then distributes them to the assigned printer. It also holds extra print jobs while the printer is busy. See also *print queue*.

print queue

If your printer is connected to a network, print jobs that are sent to the printer while it is busy are stored in a waiting line, or print queue, until they can be printed.

proportional printing

Printing in which the width of the character varies from character to character. For example, a capital W receives much more space than a lowercase i. The result looks more like a typeset book than a typewritten draft.

RAM

Random Access Memory. The portion of the printer's memory used as a buffer and for storing user-defined characters. All data stored in RAM is lost when the printer is turned off.

reset

To return a printer to its defaults either by sending a command, an INIT signal, or by turning the printer off and then back on.

resolution

The number of dots per inch used to represent an image.

ROM

Read Only Memory. A portion of memory that can only be read and cannot be used for data storage. ROM retains its contents when you turn off the printer.

RGB

Red, green, and blue. These colors, in phosphors irradiated by the computer monitor's electron gun, are used to create the additive array of screen colors.

sans serif

A type of font that does not have serifs, or lines crossing the ends of characters to enhance readability. The entries in the index are printed in a sans serif font, but the explanations are printed in a font with serifs.

scalable fonts

Fonts that can be enlarged or shrunk. Non-scalable fonts are called bitmap fonts and they can't change in size.

Screen Pattern

This setting prints shaded areas as they appear on screen, instead of printing them as halftones.

self test

A method for checking the operation of the printer. When you run the self test, the printer prints the characters stored in its ROM.

serial interface

See *interface*.

spool

The process by which the printer driver converts the print data into codes that your printer understands. This data is then sent to the printer directly or to the print server.

spool manager

A software program that converts print data into codes that your printer understands. See also *spool*.

status monitor

A software program that allows you to check the printer's status, such as the amount of ink remaining before printing.

subtractive colors

Colors produced by pigments that absorb some colors of light and reflect others. See also *CMYK*.

unidirectional printing

Printing in which the print head prints in one direction only. Unidirectional printing is useful for printing graphics because it allows more precise vertical alignment than bidirectional printing.

user-defined characters

Characters that are defined and stored in the printer by the user. Also called downloaded characters.

WYSIWIG

What-you-see-is-what-you-get. This term is used to describe printout that looks exactly like it appears on screen.

Index

A

- Adjust lever, 1-2, 7-6-7
- Advanced setting
 - Macintosh, 6-6, 6-8
 - Windows, 4-6, 4-8. *See also online help*
- Alignment, print head, 10-31-32, A-12-13. *See also Utilities*
- AppleTalk*, 2-30
- Automatic setting
 - Macintosh, 6-2-3
 - Windows, 4-2, 4-5

B

- Baud rate, 8-5
- Bidirectional printing, A-4. *See also High Speed setting*
- Brightness, B-2
- Brightness setting
 - Macintosh, 6-12
 - Windows. *See online help*
- Buttons, 1-3
 - †† black print head cleaning, 1-3, 9-3, A-10-11
 - †† color print head cleaning, 1-3, 9-3, A-10-11
 - ⏏ load/eject, 1-3, 9-7
 - ⏻ power, 1-3, 9-7

C

- Cables. *See Interface cables*
- Cartridges. *See Ink cartridges*
- Character tables, C-16-21
- Chooser*, selecting printer with, 2-27-31
- Cleaning
 - printer, 9-9
 - print heads, 10-28-30, A-10-11
- Cleaning sheets, 7-4
- Coarse Dithering setting
 - Macintosh, 6-17-18
 - Windows. *See online help*
 - See also Halftoning settings*
- Coated paper, 7-3. *See also Special paper*
- Color, tips on using, B-2-8
- Color Adjustment settings
 - Macintosh, 6-10-11
 - Windows. *See online help*
- Colorimetric setting*, 6-14
- Color slide bars
 - Macintosh, 6-12
 - Windows. *See online help*
- ColorSync setting*, 6-7, 6-13
- Command list, C-14
- Computer requirements, 1-4-5
- Connecting the printer
 - to a Macintosh, 2-21-22
 - to a PC, 2-12
- Consumable products, 1-7-8
- Contrast setting
 - Macintosh, 6-12
 - Windows. *See online help*
- Control panel, 1-2, A-13-14

*Macintosh only

†Windows only

- Current Settings display
 - Macintosh, 6-6
 - Windows, 4-6
- Customer support, 10-34-40
- Customizing paper size
 - Macintosh, 6-19
 - Windows, 3-7. *See also online help*
- Customizing print settings
 - Macintosh, 6-8-18
 - Windows, 4-8-9
- Cyan, Magenta, Yellow setting
 - Macintosh, 6-12
 - Windows. *See online help*

D

- Default settings, A-4-9
- Despooler[†], 4-15-16. *See also online help*
- Dithering, B-4. *See also* Halftoning settings
- DOS programs, A-2
- Driver. *See* Printer driver

E

- Economy setting
 - Macintosh, 6-7, 6-15
 - Windows, 4-7. *See also online help*
 - See also* Print Quality settings
- Edge guides, 1-2, 3-3-4, 5-3-4
- Envelopes
 - loading, 7-7
 - printable area, C-6
 - specifications, C-5
- EPSON Despooler[†], 4-15-16

- EPSON Monitor2*, 6-25
- Epson Namer*, 2-24, 2-26
- EPSON special media, 1-8. *See also* Special paper
- EPSON Spool Manager[†], 4-15
- EPSON Status Monitor
 - Windows, 4-13
 - Macintosh, 6-22
- EPSON Stylus Printer Driver
 - Package*, 2-24-25
- Error diffusion, B-4
- Error Diffusion setting
 - Macintosh, 6-17
 - Windows. *See online help*
- Error indicators, 10-2-3
- ESC/P 2 control codes, C-14

F

- Fine-720 dpi setting
 - Macintosh, 6-15
 - Windows. *See online help*
 - See also* Print Quality settings
- Fine Dithering setting
 - Macintosh, 6-17-18
 - Windows. *See online help*
 - See also* Halftoning settings
- Finest Detail setting
 - Macintosh, 6-17
 - Windows. *See online help*
- Flip Horizontal*, 6-16
- Fonts, built-in, A-8-9

G

- Glossy film, 7-3, 7-5. *See also* Special paper
- Glossy paper, 7-3, 7-5. *See also* Special paper

*Macintosh only

†Windows only

H

- Head. *See* Print head
- Head Cleaning utility. *See* Utilities
- Half-toning settings
 - Macintosh, 6-17-18
 - Windows. *See online help*
- Handshake timing, 8-5
- Help, online, 2-13, 4-17
- Hex dump mode, 10-6
- High Speed setting
 - Macintosh, 6-16
 - Windows. *See online help*
- Hue, B-2

I

- IBM X24 emulation control codes, C-14
- ICM setting[†], 4-7. *See also online help*
- Image resolution and size, B-5
- Index cards, 1-8, 7-5
 - printable area, C-6
 - specifications, C-5
 - See also* Special paper
- Ink cartridges, 1-7
 - installing, 2-6-11
 - printing with empty color cartridge, 9-8
 - problems with, 10-32-33
 - replacing, 9-2-7
 - specifications, C-7-8
- Ink jet paper, 1-8, 7-5. *See also* Special paper
- Ink setting
 - Macintosh, 6-17
 - Windows. *See online help*
- Ink low, 10-3
- Ink out, 10-3

Installing

- DOS programs, A-2
- ink cartridges, 2-6-11
- interface cards, 8-3-4
- paper support, 2-3
- Macintosh printer software, 2-23-24
- Windows printer software, 2-13-20

Interface

- cards, 1-6, 2-22, 8-2-5
- cables, 1-7
- specifications, C-10-11
- serial, 2-21, 2-28, 8-5

L

Lights, 1-3

- ⬛ black ink out, 1-3, 9-2-3
- 🖨️ color ink out, 1-3, 9-2-3
- 📄 paper out, 1-3
- 🔌 power, 1-3

Loading paper. *See* Paper

M

- Main menu[†], 4-3-4. *See also online help*
- Maintenance, Chapter 9
- Matching, color, B-2-4
 - Macintosh, 6-10-14
 - Windows, 4-7. *See also online help*
- Media Type settings
 - Macintosh, 6-3, 6-16
 - Windows, 4-10-11. *See also online help*

*Macintosh only

†Windows only

MicroWeave setting
 Macintosh, 6-16
 Windows. *See online help*

Mode settings
 Macintosh, 6-11
 Windows. *See online help*

More Settings dialog box
 Macintosh, 6-8
 Windows, 4-8. *See also online help*

N

Network printing
 Macintosh, 2-30
 Windows 95, 2-17

No Halftoning setting
 Macintosh, 6-17
 Windows. *See online help*
 See also Halftoning settings

Normal-360 dpi setting
 Macintosh, 6-15
 Windows. *See online help*
 See also Print Quality settings

Nozzle Check utility
 Windows, 4-14
 Macintosh, 6-23

O

Online help[†], 2-13, 4-17

Optional interface cards, 2-22, 8-2-5

Options, 1-6

Orientation setting
 Macintosh, 6-19
 Windows. *See online help*

Output tray, 1-2, 3-2, 5-2

P

Page Setup dialog box*, 5-5, 6-18

Paper
 jam, 10-3
 out, 10-2
 specifications, C-4-6
 support, 2-3
 See also Special paper

Paper, matching with Media Type setting
 Macintosh, 6-3-5
 Windows, 4-10-11

Paper loading
 Macintosh, 5-2-4
 Windows, 3-2-4
 See also Special Paper

Paper menu[†], 3-6-7, 4-3-4. *See also online help*

Paper Size settings
 Macintosh, 6-18-19
 Windows, 3-7. *See also online help*

Perceptual setting*, 6-14

Photo quality paper, 1-8, 7-5. *See also Special paper*

Photo setting
 Macintosh, 6-6
 Windows, 4-7. *See also online help*

Power Macintosh Extension Module*, 2-26

Power-on functions, A-14

Predefined settings
 Macintosh, 6-6-7
 Windows, 4-6-7. *See also online help*

*Macintosh only

[†]Windows only

- Print
 - direction, A-4. *See also* High Speed setting
 - quality, 10-18–25, 10-26–27
 - speed, 10-26–27
 - Printable Area setting
 - Macintosh, 6-19
 - Windows. *See online help*
 - Printable area specifications, C-6
 - Print dialog box*, 5-6, 6-3
 - Printer
 - cleaning, 9-9
 - parts, 1-2
 - stand, 2-4
 - transporting, 9-10
 - unpacking, 2-2
 - Printer driver
 - DOS, A-2
 - Macintosh, 2-25, 6-2–20. *See also* Printer software for Macintosh
 - Windows, 2-13, 4-2–11. *See also online help and* Printer software for Windows
 - Printer software for Macintosh
 - accessing, 5-5, 6-3
 - Automatic setting, 6-2–5
 - customized settings, 6-2, 6-8–10
 - installing, 2-23–24
 - predefined settings, 6-3, 6-6–7
 - Printer software for Windows
 - accessing, 3-5, 4-2–4
 - Automatic setting, 4-2, 4-5
 - customized settings, 4-2, 4-8–9
 - installing, 2-13–20
 - predefined settings, 4-2, 4-6–7
 - See also online help*
 - Printer utilities. *See* Utilities
 - Print head
 - alignment, 10-31–32, A-12–13
 - cleaning, 10-28–30, A-10–11
 - Printing, basic steps
 - Macintosh, 5-5–6
 - Windows, 3-5–7
 - Printing problems. *See* Troubleshooting
 - Print Quality settings
 - Macintosh, 6-15
 - Windows. *See online help*
 - Print settings
 - DOS, A-2–9
 - Macintosh, 6-2–20. *See also* Printer software for Macintosh
 - Windows, 4-2–11. *See also online help and* Printer software for Windows
 - Profile setting*, 6-13
- Q**
- Quality vs. Speed slide bar
 - Macintosh, 6-3
 - Windows, 4-5. *See also online help*
- R**
- Reduce or Enlarge setting*, 6-19
 - Rendering Intent setting*, 6-14
 - Replacing an ink cartridge. *See* Ink cartridges
 - Resolution
 - image, B-5–6
 - printing, C-3
 - See also* Print Quality settings

*Macintosh only

†Windows only

S

- Safety
 - approvals, C-10
 - instructions, Chapter 1
- Saturation, B-2
- Saturation setting
 - Macintosh, 6-12, 6-14
 - Windows. *See online help*
- Self adhesive sheets, 1-8, 7-5
- Self testing, 10-4-5
- Special media, 1-8. *See also* Special paper
- Special paper, 1-8, 7-2-3
 - cleaning sheets, 7-4
 - loading, 7-4-8
- Specifications, C-2-12
 - default settings, C-13
 - electrical, C-9
 - environmental, C-9
 - ink cartridges, C-7-8
 - initialization, C-12
 - interface, C-10-11
 - mechanical, C-8
 - paper, C-4-6
 - printable area, C-6
 - printing, C-2-3
 - safety approvals, C-10
- Spool Manager[†], 4-15
- Status Monitor
 - Macintosh, 6-22-23
 - Windows, 4-13
- SuperFine-1440 dpi setting
 - Macintosh, 6-15
 - Windows. *See online help*
 - See also* Print Quality settings
- System requirements, 1-4-5

T

- Text/Graph setting
 - Macintosh, 6-7
 - Windows, 4-7. *See also online help*
- Transporting the printer, 9-10
- Transparencies, 1-8, 7-3, 7-5, 7-8
- Troubleshooting, Chapter 6
 - ink cartridges, 10-32-33
 - operation, 10-8-14
 - paper handling, 10-15-17
 - power supply, 10-7-8
 - printing quality, 10-18-25
 - printer utilities, 10-25-26

U

- Unpacking the printer, 2-2
- User Defined Paper Size dialog box[†].
 - See online help*
- Utilities
 - Macintosh, 6-21-26
 - Windows, 4-12-14
- Utility menu[†], 4-3-4, 4-12. *See also online help*

V

- Video/Digital Camera setting
 - Macintosh, 6-7, 6-12
 - Windows, 4-7. *See also online help*

*Macintosh only

[†]Windows only

EPSON OVERSEAS MARKETING LOCATIONS

EPSON AMERICA, INC.

20770 Madrona Ave.
P.O. Box 2842
Torrance, CA 90509-2842
Phone: (800) 922-8911
Fax: (310) 782-5220

EPSON UK LTD.

Campus 100, Maylands Avenue,
Hemel Hempstead, Herts,
HP2 7TJ, U.K.
Phone: (+44) 01442 61144
Fax: (+44) 01442 227227

EPSON DEUTSCHLAND GmbH

Zülpicher Straße 6,
40549 Düsseldorf Germany
Phone: (0211) 56030
Telex: 8584786

EPSON FRANCE S.A.

68 bis, rue Marjolin
92300, Levallois-Perret, France
Phone: 33.1.40.87.37.37
Telex: 610657

EPSON AUSTRALIA PTY. LTD.

70 GIBBES STREET, CHATSWOOD 2067 NSW.
Phone: 2-9903-9000
Fax: 2-9903-9177

EPSON SINGAPORE PTE. LTD.

No. 1 Temasek Avenue #36-00
Millenia Tower, Singapore 039192
Phone: (065) 33 77 911
Fax: (065) 33 41 185

EPSON HONG KONG LTD.

Rooms 4706-10, 47/F,
China Resources Bldg.,
26 Harbour Road, Wanchai, Hong Kong
Phone: 2585-4300
Fax: 2827-7083

EPSON TAIWAN TECHNOLOGY & TRADING LTD.

10F, No. 287 Nanking E. Road, Sec. 3,
Taipei, Taiwan, R.O.C.
Phone: (02) 717-7360
Fax: (02) 712-9164

EPSON ITALIA S.p.A.

V.le F.lli Casiraghi 427
20099 Sesto S.Giovanni
MI, Italy
Phone: 2-262331
Fax: 2-2440750

EPSON IBERICA S.A.

Av. de Roma, 18-26
08290 Cerdanyola del Valles
Barcelona, Spain
Phone: 582. 15.00
Fax: 582. 15.55

**SEIKO EPSON CORPORATION
(Hirooka Office)**

80 Harashinden, Hirooka
Shiojiri-shi, Nagano-ken
399-07 Japan

EPSON PORTUGAL, S.A.

R. do Progresso, 471, 1º Perafita
4460 Matosinhos, Portugal
Phone: (02) 996 14 02
Fax: (02) 996 14 11

EPSON

Ink Jet Printer

EPSON Stylus™ COLOR 800

User's Guide

