

The background of the left page is a blue-tinted image of a projector's internal lens assembly. The Epson logo is at the top left, followed by the 'MP PROJECTOR' logo. The model numbers 'EMP-9300' and 'EMP-8300' are prominently displayed in the center, with 'User's Guide' below them. At the bottom, there is a vertical list of language options in white boxes.

EPSON®

MP PROJECTOR

EMP-9300

EMP-8300

User's Guide

Français

Deutsch

Italiano

Español

中文(繁體)

中文(简体)

Features of the Projector

Before Using the Projector

This chapter describes how to use the remote control and how to set up the projector and connect it to a computer and to video equipment.

Basic Operations

This chapter describes basic operations such as turning the projector on and off and adjusting the projected images.

Advanced Operations

This chapter describes useful functions for enhancing projection and how to use the configuration menus.

Troubleshooting

This chapter describes what to do if there is a problem with the projector.

Appendices

This chapter describes procedures for cleaning the projector, and other useful information.

Notations Used in This User's Guide

Understanding This User's Guide

Saving the User's Guide as a PDF File on a Computer

Part Names and Functions

Using the Configuration Menu Functions

Optional Accessories and Consumables

Glossary

Index