



The Epson logo is displayed in a bold, black, sans-serif font.The logo for Epson's Ultimate Edge projector line, featuring the word "PROJECTOR" in a large, bold, black font, with "ULTIMATE EDGE" in a smaller font above it.The model numbers "EMP-740" and "EMP-732" are displayed in a large, bold, white font.The text "User's Guide" is displayed in a large, bold, white font.A white rectangular button with the Japanese text "日本語" (Nihongo) in black.A white rectangular button with the French text "Français" in black.A white rectangular button with the German text "Deutsch" in black.A white rectangular button with the Italian text "Italiano" in black.A white rectangular button with the Spanish text "Español" in black.A white rectangular button with the Chinese text "中文(繁體)" (Traditional Chinese) in black.A white rectangular button with the Chinese text "中文(简体)" (Simplified Chinese) in black.

Projector Features

Before Using the Projector

This chapter describes how to use the remote control and how to set up the projector and connect it to a computer and to video equipment.

Basic Operations

This chapter describes basic operations such as turning the projector on and off and adjusting the projected images.

Advanced Operations

This chapter describes useful functions for enhancing projection and how to use the configuration menus.

Troubleshooting

This chapter describes what to do if there is a problem with the projector.

Appendices

This chapter describes procedures for cleaning the projector, and other useful information.

*This manual contains information for the EMP-745, the EMP-740, the EMP-737 and the EMP-732. The illustrations given in the manual depict the EMP-745 and the EMP-737 unless otherwise noted.

Notations Used in This Guide

Understanding This Guide

Saving This Guide on a Computer

Part Names and Functions

Using the Configuration Menu Functions

Optional Accessories and Consumables

Glossary

Index