

A

A/V cable	24, 27
A/V Mute	50
Abs. Color Temp.	57, 59
Air exhaust vent	7
Air filter	10
Air intake vent	10
Aspect ratio	51
[Audio] port	9, 27
Auto Keystone	62
Auto Setup	44, 60

B

Background Color	64
Blackboard	47, 56, 58
Brightness	56, 58
Brightness Control	62
Buzzer for notice of termination	38

C

Card slot	17
Cleaning the Air Filter	99
Cleaning the Lens	99
Cleaning the Projector Surface	99
Color Intensity	58
Color Mode	47, 56, 58
Component video	25
Composite video	24

Computer cable	21, 26
Computer Input	60, 61
[Computer/Component Video] port	9
Connecting to a Computer	20
Connecting to a Video Source	24
Contrast	56, 58
Control Panel	8
Cool-down	77
Cross	52

D

Direct Power ON	65
Display	64
Dynamic	47, 56, 58

E

Eligible computers	20
ESC/VP21	113
"Extended" Menu	64
E-Zoom	52

F

Focus	40
Focus ring	7
Foot adjustment	42
Freeze	51
Front adjustable foot	7

G

Glossary	109
----------------	-----

H

HDTV	115
Help function	73
High	62

I

"Image" Menu	56
Image size	16, 40
Indicators	7, 75
"Info" Menu	67
Input Signal	67
Inserting the Batteries	12

K

Keystone	41, 62
----------------	--------

L

Lamp cover	10
Lamp Hours	67
Lamp indicator	7, 75
Lamp replacement period	100
Lamp-Hours Reset	68, 103
Language	66
Lens cover	7



Living Room 47, 56, 58
 Low 62

M

Main menu 55
 Manually Correcting Keystone Distortion 43
 Menu 55
 Message 64
 Mini D-Sub 15-pin port 21
 Mouse pointer 23

N

Numeric buttons 11

O

Operating distance (Remote control) 14
 Operating range (Remote control) 14
 Operating temperature 116
 Operation 65
 Operation Lock 62
 Optional accessories 108
 Overheating 76

P

Part Names and Functions 7
 Password Protect 31
 Password Protect stickers 32
 PC card 17

Pointer 53
 Pointer Shape 62
 Port 9, 37
 Position 44, 60, 61
 Power cable 35
 Power indicator 7, 75
 Power inlet 9
 Power ON Protect 31
 Presentation 47, 56, 58
 Problem Solving 75
 Projecting Images 36
 Projection 65
 Projection angle 41
 Projection distance 16

R

Rear adjustable foot 42
 Refresh Rate 67
 Remote control 11, 12, 13, 22
 Remote control light-emitting area 11
 Remote control light-receiving area 7, 9
 Replacing the Air Filter 104
 Replacing the Lamp 101
 Request code 31
 Reset All 68
 "Reset" Menu 68
 Resized display 115
 Resolution 67, 115
 RGB Video 26

S

Screen size 16
 Security lock 7
 "Setting" Menu 62
 Setting Up the Projector 15
 Sharpness 56, 58
 "Signal" Menu 60
 Sleep Mode 65
 Source 67
 Speaker 9, 27, 28
 Specifications 116
 Squeeze mode 51
 sRGB 47, 56, 58
 Standby Mode 66
 Startup Screen 64
 Stereo mini jack audio cable 27
 Storage temperature 116
 Sub-menu 55
 Supported Monitor Displays 115
 Suspension bracket fixing point 10, 118
 S-Video 25, 58, 61, 67
 [S-Video] port 9
 Sync 44, 60
 Sync. Info 67

T

Temp indicator 7, 75
 Theatre 47, 56, 58



Tint	58
Tracking	44, 45, 60
Translucent screen	15
Turning the Projector Off	38

U

USB cable	22, 29
USB connection	114
USB mouse	22
[USB TypeA] port	9
[USB TypeB] port	9
User's Logo	50, 105
User's Logo Protect	32
Using the Configuration Menu Functions	55

V

Video	67
Video Signal	61, 67
[Video] port	9
Volume	48

W

Wide-screen Projection	51
Wireless LAN card	17
Wireless Mouse Function	22

Z

Zoom ring	7
-----------------	---

