

Как да разглеждате това ръководство

Можете да извършвате следните задачи, като кликвате върху бутоните.



Показва прозореца за печат.



Търси текст.



Показва или скрива показалците.



Пренавя към друга страница от документа (първа/предишна/следваща/последна).



Кликнете, за да се преместите напред или назад към последно показваната страница.


Така можете да се върнете на страницата, която сте гледали, ако прескочите на друга страница - например някоя справочна страница.



Кликнете този бутон, ако текстът или илюстрациите са твърде малки и не се виждат добре.

Преместете курсора върху мястото, което искате да видите, след което кликнете с левия бутон на мишката, за да увеличите тази част от документа.

Ако задържите клавиша [Ctrl], докато кликате с левия бутон на мишката, размерът за гледане на документа ще бъде намален.



Bookmarks

- Operation Buttons
- Configuration Menu
- Using the Configuration Menu
- List of Functions
 - "Image" Menu
 - "Signal" Menu
 - "Settings" Menu
 - "Extended" Menu
 - "Info" Menu
 - "Reset" Menu
- Troubleshooting
 - Using the Help
 - Problems Solving
 - Reading the Information
 - When the Indicators
- Appendices
 - Installation
 - Setting Up the Projector
 - Maintenance
 - Cleaning
 - Replacing Components
 - Replacing Projector Lamp
 - Optional Accessories
 - Screen Size and Projection Distance
 - Glossary
 - List of ESC/VP21 Commands
 - Command List
 - Cable Layouts
 - USB Connection
 - List of Supported Projectors

77

Problem Solving

Images are fuzzy or out of focus.

Check	Remedy
Has the focus been adjusted correctly?	Turn the focus ring on the projector to adjust the focus. p.37
Is the lens cover still attached?	Remove the lens cover. p.32
Is the projector at the correct distance?	The recommended projection distance range is 89–1050 cm (2.9–34.4 ft.). Set the projector up so that it is within this range. p.15
Is the keystone adjustment value too large?	Decrease the projection angle to reduce the amount of keystone correction. p.40
Has condensation formed on the lens?	If the projector is suddenly taken from a cold environment to a warm environment or if sudden ambient temperature changes occur, condensation may form on the surface of the lens, and this may cause the images to appear fuzzy. Set the projector up in the room approximately one hour before it is to be used. If condensation forms on the lens, turn the power off and wait for the condensation to disappear.

Interference or distortion appear in images.

Check	Remedy
Are the image signal format settings correct?	If signals from the [Computer1/Component Video1] port or the [Computer2/Component Video2] port are being projected, use the "Input Signal" menu command to set the signal format that matches the signal that is being projected from the connected equipment. "Image" – "Input Signal" p.52, p.55 If a composite video or S-Video source is connected to the projector, use the "Video Signal" menu command to select the signal format. "Image" – "Video Signal" p.56
Are the cables connected correctly?	Check that all of the cables required for projection are securely connected. p.16-p.24
Is an extension cable being used?	If an extension cable is used, electrical interference may affect the signals. Use the accessory cables and check if this helps.
Has the correct resolution been selected? Only when projecting computer images	Set the computer so that the signals that are output are compatible with this projector. "List of Supported Monitor Displays" p.100 Computer documentation
Have the "Sync." and "Tracking" settings been adjusted correctly? Computer and RGB video signals only	Press the [Auto] button on the remote control to carry out automatic adjustment. If the images have not been adjusted correctly after using automatic adjustment, you can make the adjustments using the "Sync." and "Tracking" menus. p.42, p.43

[Показалци]

Кликнете върху заглавието на даден раздел, за да прескочите на първата страница от въпросния раздел.

Прескача на страница, която съдържа свързана тема или подробно обяснение. Когато текстът е син, кликнете върху него, за да отворите справочната страница или ръководство.



Показва страницата в реалния ѝ размер.



Показва страницата на цял екран.



Показва страницата така, че ширината ѝ съвпада с ширината на прозореца.

Кликнете, за да прескочите към НАЙ-ГОРНАТА страница.