


Firmware Upgrade


The instructions below will guide you through the process of updating your product's firmware

For Window OS


1, Double click on the downloaded firmware icon to begin the install process. The below screen will appear, click next to continue




2, Click on the "I agree" followed by clicking on Next.



3, Read the instructions carefully and follow any actions as directed, click Next to continue.



4, Select the connection method and click next to begin the install process, the next steps are automated and require no user intervention



5, Click finish once the screen below appears and confirms the procedure is complete.

Epson Firmware Updater

1 2 3 4 5 6 7 8 9

Overall Progress: 1/ 1
Current Progress: 100 %

Firmware File: FWC365TL.efu

Software	Version	Vendor Name
Firmware	1C. 1C.AW22A7	

Update Printer List:

Status	Model Name
Update successful	Epson Stylus Photo PX720WD

Detailed Information:

The firmware has been downloaded to your printer.
Wait for the printer to turn off automatically.

Finish