

Safety Instructions

- Safety Instructions 2
- Notes on Handling and Storage..... 11



Support and Service Guide

- Utility Software 14
- Problem Check Sheets 15
- Epson Projector Contact List 17

Safety Instructions

All safety and operating instructions should be read before using the projector. After you have read all instructions, save this information for later reference. To prevent personal injury or damage to property, the following symbols are used to show dangerous operation or handling. Make sure you understand them properly when reading the guide.

Explanation of symbols

 Warning	This symbol indicates information that, if ignored, could possibly result in serious personal injury or even death due to incorrect handling.
 Caution	This symbol indicates information that, if ignored, could possibly result in personal injury or physical damage due to incorrect handling.

Symbols indicating an action that must not be done



Do not do



Do not
disassemble



Do not
touch



Do not
wet



Do not use in
wet areas



Do not place
on an
unstable
surface

Symbols indicating an action that should be done



Instructions



Disconnect
the plug from
the outlet

Warning

Unplug the projector from the outlet and refer all repairs to qualified service personnel under the following conditions:

- If smoke, strange odors or strange noises come from the projector.
- If liquid or foreign objects get inside the projector.
- If the projector has been dropped or the housing has been damaged.

Continuing to use under these conditions may result in fire or electric shock.

Do not try to repair this projector yourself. Refer all repairs to qualified service personnel.

Place the projector near an outlet where the plug can be easily unplugged.



Disconnect
the plug from
the outlet

Never open any covers on the projector except as specifically explained in the User's Guide. Never attempt to disassemble or modify the projector (including consumables). Refer all repairs to qualified service personnel.

Electrical voltages inside the projector can cause severe injury.



Do not
disassemble

If you are installing the projector on the ceiling, this projector should be installed by qualified technicians using only approved mounting equipment.

If installation work is not carried out correctly, the projector could fall down. This may result in injury or accidents. Contact your dealer to carry out the installation work.



Instructions

If you use a ceiling mount and apply adhesives to the mount to prevent the screws from loosening, or if you use lubricants or oils on the projector, the projector housing may crack and the projector may fall from its ceiling mount. This could cause serious injury to anyone under the mount and could damage the projector. When installing or adjusting a ceiling mount, do not use adhesives to prevent the screws from loosening and do not use oils or lubricants.



Do not do

Do not use the projector where it may be exposed to rain, water, or excessive humidity.



Do not use in
wet areas

Warning

Use the type of power source indicated on the projector. Use of a different power source may result in fire or electric shock. If you are not sure of the power available, consult your dealer or power company.



Do not do

Check the specifications of the power cable. Using an inappropriate power cable could result in fire or electric shock.

The power cable supplied with the projector is intended to comply with power supply requirements for the country of purchase. If you use the projector in the country where it was purchased, only use the power cable that came with the projector. If you use the projector in a country other than where it was purchased, use the correct power cable for that country.



Instructions

Take the following precautions when handling the plug.

Failure to comply with these precautions could result in fire or electric shock.

- Do not overload wall outlets, extension cables, or power strips.
- Do not insert the plug into a dusty outlet.
- Insert the plug firmly into the outlet.
- Do not hold the plug with wet hands.
- Do not pull the power cable when disconnecting the plug; always be sure to hold the plug when disconnecting it.



Instructions

Do not use the power cable that is damaged. Fire or electric shock may result.

- Do not modify the power cable.
- Do not place heavy objects on top of the power cable.
- Do not bend, twist or pull the power cable excessively.
- Keep the power cable away from hot electrical appliances.

Contact your dealer if the cable becomes damaged.



Do not do

Cables should be wired so that they cannot trip people up and so on.

This could cause people to fall and be injured.



Instructions

Warning

Do not touch the plug during an electrical storm. Otherwise, you may receive an electric shock.



Do not touch

Do not place any containers of liquid on top of the unit.
Spilling liquid of any kind into the projector may result in fire or electric shock.



Do not
wet

Do not look into the lens when the projector is on. The bright light can damage your eyes. Also, do not look into the lens using optical devices such as loupes or telescopes.



Do not do

Do not insert or drop metal, flammable, or foreign objects into the projector's vents or openings nor leave them nearby.
Doing so may result in fire, electric shock, or burns.



Do not do

A mercury lamp with high internal pressure is used as the projector's light source. If the lamp is subjected to vibrations, shocks, or if it is used for an overly extended length of time, the lamp may break or it may not turn on. If the lamp explodes, gases may escape and small fragments of glass may be scattered which could cause an injury. Be sure to observe the instructions below.



Instructions

- Do not disassemble or damage the lamp or subject it to any impacts.
- Do not bring your face close to the projector while it is in use.
- Particular care should be taken when the projector is installed to a ceiling, as small pieces of glass may fall down when the lamp cover is removed. When cleaning the projector or replacing the lamp yourself, be very careful not to allow such pieces of glass to get into the eyes or mouth.

If the lamp breaks, ventilate the area immediately, and contact a doctor if any fragments of broken glass are inhaled or get into the eyes or mouth. In addition, consult your local regulations regarding proper disposal and do not place in the trash.

Warning

Do not leave the projector or the remote control with batteries inside a vehicle with the windows closed, in places where they will be exposed to direct sunlight, or in other places that may become extremely hot.

Thermal deformation or technical malfunction may occur, which could result in fire.



Do not do

Do not use sprays containing a flammable gas to remove dirt or dust which is adhering to parts such as the lens or filter of the projector.

Because the lamp inside the projector becomes very hot during use, the gases may ignite and result in a fire.



Do not do

Do not use the projector in places where flammable gases or explosive gases may be present in the atmosphere.

Because the lamp inside the projector becomes very hot during use, the gases may ignite and result in a fire.



Do not do

Do not place any objects that are easily flammable in front of the projector's lens, otherwise a fire may occur.



Do not do

Do not look into the vents.

If the lamp explodes, gases may escape and small fragments of glass may be scattered which could cause an injury.

Contact a doctor if any fragments of broken glass are inhaled or get into the eyes or mouth.



Do not do

During projection, do not block the light from the projector with the lens cover (removable) or a book and so on.

If the light from the projector is blocked, the area on which the light shines becomes hot which could cause it to melt, burn, or start a fire. Also, the lens may get hot due to the reflected light which could cause the projector to malfunction. To stop projection, use the A/V Mute function, or turn off the projector.



Do not do



Caution

Do not use the projector in places where there is a lot of humidity or dust, near cooking or heating appliances, or in places where it may come into contact with smoke or steam.

Do not use or store this projector outdoors for an extended length of time.

Fire or electric shock may result.



Do not do

Do not block the slots and opening in the projector case. They provide ventilation and prevent the projector from overheating.

- If setting up the projector near a wall, leave a space of at least 50 cm between the wall and the air exhaust vent.
- Do not place the projector in the following locations.
 - Badly ventilated or narrow places, such as inside a closet or in a book case.
 - On a rug, bedding, blanket, and so on.
 - Do not cover the projector with a blanket, curtain, or tablecloth.
 - Badly ventilated locations such as inside an AV rack or cabinet.
 - Locations subject to high temperatures, such as near heating equipment.



Do not do

Do not place the projector on an unstable cart, stand, or table. The projector may fall down or tip over, and injury may result.



Do not place
on an
unstable
surface

Do not stand on the projector or place heavy objects on it. You may fall over resulting in injury or the projector may become damaged.



Do not do

Caution

Do not place anything that can become warped or damaged by heat near the exhaust vents. Do not bring your hands or face close to the vents while projection is in progress.

Because of hot air coming out from the air exhaust vents, you could get burnt or it could be a cause of warping or other damage to property.



Do not do

Never try to remove the lamp immediately after use because it will be extremely hot. Before removing the lamp, turn off the power and wait the duration specified in the User's Guide to allow the lamp to cool completely.

The heat may cause burns or other injuries.



Do not do

Do not place the source of an open flame, such as a lit candle, on or near the projector.



Do not do

Unplug the projector when it will not be used for extended periods. The insulation may deteriorate, which may result in fire.



Disconnect
the plug from
the outlet

Be sure to check that the power is turned off, the plug is disconnected from the outlet and all cables are disconnected before moving the projector.

Fire or electric shock may result.



Disconnect
the plug from
the outlet

Unplug the projector from the outlet before cleaning.

This avoids electric shock during cleaning.



Disconnect
the plug from
the outlet

Caution

Use a dry cloth (or, for stubborn dirt or stains, a moist cloth that has been wrung dry) for cleaning. Do not use liquid, aerosol cleaners, or solvents such as alcohol, thinner or benzene.

Water infiltration or deterioration and breakage of the projector housing could result in electric shock.



Instructions

Incorrect battery usage may cause leakage of battery fluid and battery rupture, which could result in fire, injury or corrosion of the projector. When replacing batteries, take the following precautions.

- Insert batteries so that the polarities (+ and -) are correct.
- Do not use batteries of different types or mix old and new batteries.
- Do not use any batteries other than those specified in the *User's Guide*.
- If the batteries leak, wipe away battery fluid with a soft cloth. If fluid gets on your hands, wash them immediately.
- Replace the batteries as soon as they run out.
- Remove the batteries if you will not be using the projector for a long period of time.
- Do not expose batteries to heat or flame and do not put them in water.
- Dispose of used batteries according to local regulations.
- Keep these batteries out of the reach of children. Batteries are choking hazards and are very dangerous if swallowed.



Instructions

Follow the maintenance schedule for this projector. If the interior of the projector has not been cleaned for a long time, dust may build up, which could cause fire or electric shock.

Replace your air filter periodically as needed.

Contact your dealer to clean the interior of the projector as needed.



Instructions

Do not use the projector in places where corrosive gas, such as sulfurous gas from hot springs, may be present.

Malfunction may result.



Do not do

Do not start the projector while the volume is too high. (only models with built-in speaker)

Loud sounds may cause loss of hearing. Always lower the volume before turning off the projector. Gradually increase the volume after turning on the projector.



Instructions



Caution

Avoid standing in front of the projector so you do not block the projected images and the bright light does not shine in your eyes.
Looking into the projector's light can damage your eyesight.




Instructions

Be sure to observe the following precautions to avoid malfunctions, operating errors or damage to the projector.

Notes on Handling and Storage

- Do not use or store the projector in places where it might be subjected to high and low extremes of temperature. Furthermore, avoid places where the temperature may change suddenly.
- Be sure to observe the operating temperatures and storage temperatures given in the User's Guide when using and storing the projector.
- Do not set up the projector in places where it might be subjected to vibration or shock.
- Do not set up the projector near high-voltage electrical wires or sources of magnetic fields.
These may interfere with correct operation.
- Do not operate the projector under any of the following conditions. If this is not observed, problems with operation or accidents may result.



While the projector is tilted one side.

- Do not touch the lens with bare hands.
- Always attach the lens cover to the lens when not using the projector, to prevent the lens from becoming dirty or damaged.
- Remove the batteries from the remote control before storage.
If the batteries are left in the remote control for long periods, they may leak.
- Do not use or store the projector in places where smoke from oil or cigarettes may be present, as it can adversely affect the quality of the projected images.
- Contact your dealer to clean the interior of the projector. If the interior of the projector has not been cleaned for a long time, dust may build up, which could cause fire or electric shock.
- Epson takes no responsibility for loss or damage caused by damage to the projector or lamp failures outside service warranty conditions.

- When a still image is displayed for a long period of time, image retention may occur on the screen. Do not display images in the exact same position for long periods.

Projection Lamp

A mercury lamp with high internal pressure is used as the projector's light source. The characteristics of the mercury lamp are:

- The intensity of the lamp decreases with use.
- When it is time for replacement, the lamp will no longer light or may break with a loud noise.
- The interval of lamp replacement may vary greatly depending on the individual lamp characteristics and the operating environment. You should always have a spare lamp ready in case it is needed.
- Do not turn the projector on immediately after turning it off. Turning the projector on and off frequently may shorten the life of the lamp.
- Once the lamp replacement period has elapsed, the possibility of the lamp breakage becomes greater. When the lamp replacement message appears, replace the lamp with a new one as soon as possible.

LCD Panel

The LCD panel is manufactured using extremely high-precision technology. However, black dots may appear on the panel, or some red, blue or green dots may light up extremely brightly at times. Furthermore, sometimes striped color irregularities or brightness irregularities may also appear. They are caused by the characteristics of the LCD panel, and are not a sign of a malfunction.

Notes on Carrying the Projector

- Turn off the projector power and then disconnect the power cable from the outlet.
Furthermore, check that all other cables have been disconnected.
- Attach the lens cover to the lens.
- Retract the adjustable foot.
- If your model of projector has a handle, hold the projector by the handle when carrying it.

When transporting the projector to the manufacturer for repairs

The internal projector components consist of many glass parts and high-precision parts. When transporting the projector, take the following measures to protect the projector from any damage that might result from shock.

Enclose the projector securely in buffer material to protect it from shock, and place it into a strong cardboard container. Be sure to notify the carrier company that the contents are fragile.

Power cables for Overseas Use

The power cable that is supplied with this projector conforms to electrical safety regulations. Do not use a power cable other than the one supplied with the projector.

If using the projector overseas, check the power supply voltage, outlet shape and electrical rating of the projector that conform to the local standards, and purchase a proper power cable in the country.

Contact an authorized Epson dealer in one of the countries listed on page 17 for details on obtaining a proper power cable.

General power cable specifications

The following conditions must be observed regardless of the country of use.

- The power cable must have the approval marks from the standards authority of the country where the projector is to be used.
- The plug must be of the same shape as the outlets in the country of use.

Examples of standards authorities or certification marks for different countries

Country name	Standards authority or certification mark	Country name	Standards authority or certification mark
United States of America	UL	Norway	NEMKO
Canada	CSA	Finland	FIMKO
United Kingdom	BSI	France	LCIE
Italy	IMQ	Netherlands	KEMA
Australia	SAA	Belgium	CEBEC
Austria	OVE	Japan	PSE
Switzerland	SEV	Korea	EK
Sweden	SEMKO	China	CCC
Denmark	DEMKO	Singapore	PSB
Germany	VDE		

Utility Software

The software contained in the software CD-ROM that is supplied with the projector can also be downloaded from the Epson web site (<http://www.epson.com>). If the software is updated, the latest versions of the software will also be available from this web site.

Please check the Epson web site (<http://www.epson.com>) for the latest software upgrades.

If your projector develops a problem, make a copy of these check sheets and use them to explain the problem symptoms more clearly when calling for service.

Problems

- ☐ Power does not turn on
- ☐ Nothing appears on the screen
- ☐ A message appears
 - ☐ No image signal is being input
 - ☐ These signals cannot be handled by this projector.
- ☐ Blue screen (blue background)
- ☐ Black screen (black background)
- ☐ Projected images
- ☐ User's logo (no message appears)

Image is truncated or small

- ☐ Only part of the image is displayed
- ☐ Image is smaller than size of screen
- ☐ Image has keystone distortion
- ☐ Several pixels are missing

Image quality is poor

- ☐ Image is blurry and out of focus
- ☐ Image contains striped patterns
- ☐ Image flickers
- ☐ Characters appear to be missing

Audio (only models with built-in speaker)

- ☐ No sound is heard
- ☐ Volume is low
- ☐ Sound is distorted
- ☐ Wrong sound is heard
- ☐ Has the connected equipment been set to output audio?
- ☐ Does the sound come out when external speakers are connected? (if equipped with an Audio Out port)

Color is poor or too dark

- ☐ Too dark
- ☐ Color is poor or too dark (video)
- ☐ Color is poor or too dark (computer)
- ☐ Color different from TV/CRT

Menus

- ☐ Menus appear
 - Setting ☐ Sleep Mode : ON
- ☐ About (Video)
 - Lamp h
 - Video Signal ☐ AUTO
 - ☐ NTSC
 - ☐ Other
- ☐ About (Computer)
 - Lamp h
 - Frequency H Hz
 - V Hz
 - SYNC Polarity H ☐ Positive
 - ☐ Negative
 - V ☐ Positive
 - ☐ Negative
 - SYNC Mode ☐ Separate
 - ☐ Composite
 - ☐ Sync on Green
 - Resolution ×
 - Refresh Rate Hz

Menus





- ☐ Menus appear
 - ☐ Audio
 - Audio input ()
 - Volume ()

Write symptoms here:

[illegible]

EMP-
EH-
EB-
Serial number

Purchase date: / /
Indicators
(Write down colors and status of
each indicator)

	Indicator	<input type="checkbox"/>
	Indicator	<input type="checkbox"/>
	Indicator	<input type="checkbox"/>
	Indicator	<input type="checkbox"/>

Power cable

- ☐ Is the cable securely connected?
- ☐ Power switch ON (depends on model)

☐ Connector
☐ Is the connector securely connected?

Connectors

- ☐ Is the connector securely connected?
- ☐ What is the name of the port used for connection?

Computer settings
(Display properties)

☐ LCD display

Resolution
(×)

Refresh rate
(Hz)

☐ Computer
 Win/Mac/EWS
 Manufacturer ()
 Model ()
 Laptop/Desktop/Integrated
 Panel resolution (×)
 Video mode ()

☐ Video equipment
VCR/DVD/Camera
Manufacturer ()
Model ()

Connection cable

☐ Genuine

☐ Extension m

Part No. ()

☐ Distributor/amplifier

Part No. ()

☐ Switch

Part No. ()

When does the problem occur? ☐ Before use ☐ Immediately after starting to use ☐ During use
e.g. always when is done
☐ Other ()

Frequency of problem ☐ Always ☐ Sometimes (..... times during)
e.g. always when is done
☐ Other (.....)

Epson Projector Contact List



This address list is current as of March 2016.

A more up-to-date contact address can be obtained from the corresponding website listed here. If you do not find what you need on any of these pages, please visit the main Epson home page at www.epson.com.

< EUROPE, MIDDLE EAST & AFRICA >

ALBANIA :

ITD Sh.p.k.
<http://www.itd-al.com>

AUSTRIA :

Epson Deutschland GmbH
<http://www.epson.at>

BELGIUM :

**Epson Europe B.V.
Branch office Belgium**
<http://www.epson.be>

BOSNIA AND HERZEGOVINA :

NET d.o.o. Computer Engineering
<http://www.net.com.ba>

BULGARIA :

Epson Service Center Bulgaria
<http://www.kolbis.com>

CROATIA :

MR servis d.o.o.
<http://www.mrservis.hr>

CYPRUS :

Mechatronic Ltd.
<http://www.mechatronic.com.cy>

CZECH REPUBLIC :

**Epson Europe B.V.
Branch Office Czech Republic**
<http://www.epson.cz>

DENMARK :

Epson Denmark
<http://www.epson.dk>

ESTONIA :

Epson Service Center Estonia
<http://www.epson.ee>

FINLAND :

Epson Finland
<http://www.epson.fi>

FRANCE & DOM-TOM TERRITORY :

Epson France S.A.
<http://www.epson.fr>

GERMANY :

Epson Deutschland GmbH
<http://www.epson.de>

GREECE :

Oktabit S.A.
<http://www.oktabit.gr>

HUNGARY :

**Epson Europe B.V.
Branch Office Hungary**
<http://www.epson.hu>

IRELAND :

Epson (UK) Ltd.
<http://www.epson.ie>

ISRAEL :

Epson Israel
<http://www.epson.co.il>

ITALY :

Epson Italia s.p.a.
<http://www.epson.it>

KAZAKHSTAN :

Epson Kazakhstan Rep. Office
<http://www.epson.kz>

LATVIA :

Epson Service Center Latvia
<http://www.epson.lv>

LITHUANIA :

Epson Service Center Lithuania
<http://www.epson.lt>

LUXEMBURG :

**Epson Europe B.V.
Branch office Belgium**
<http://www.epson.be>

MACEDONIA :

Digit Computer Engineering
<http://www.digit.com.mk>

NETHERLANDS :

**Epson Europe B.V.
Benelux sales office**
<http://www.epson.nl>

NORWAY :

Epson Norway
<http://www.epson.no>

POLAND :

**Epson Europe B.V.
Branch Office Poland**
<http://www.epson.pl>

PORTUGAL :

**Epson Ibérica S.A.U.
Branch Office Portugal**
<http://www.epson.pt>

ROMANIA :

**Epson Europe B.V.
Branch Office Romania**
<http://www.epson.ro>

RUSSIA :**Epson CIS**<http://www.epson.ru>**UKRAINE :****Epson Kiev Rep. Office**<http://www.epson.ua>**SERBIA :****AVG d.o.o. Beograd**<http://www.a-v-g.rs>**SLOVAKIA :****Epson Europe B.V.****Branch Office****Czech Republic**<http://www.epson.sk>**SLOVENIA :****Birotehnna d.o.o.**<http://www.birotehnna.si>**SPAIN :****Epson Ibérica, S.A.U.**<http://www.epson.es>**SWEDEN :****Epson Sweden**<http://www.epson.se>**SWITZERLAND :****Epson Deutschland****GmbH****Branch office Switzerland**<http://www.epson.ch>**TURKEY :****Tecpro Bilgi Teknolojileri****Tic. ve San. Ltd. Sti.**<http://www.tecpro.com.tr>**UK :****Epson (UK) Ltd.**<http://www.epson.co.uk>**AFRICA :**<http://www.epson.co.za>

or

<http://www.epson.fr>**SOUTH AFRICA :****Epson South Africa**<http://www.epson.co.za>**MIDDLE EAST :****Epson (Middle East)**<http://www.epson.ae>**< NORTH, CENTRAL AMERICA & CARIBBEAN ISLANDS >****CANADA :****Epson Canada, Ltd.**<http://www.epson.ca>**COSTA RICA :****Epson Costa Rica, S.A.**<http://www.epson.co.cr>**MEXICO :****Epson Mexico, S.A. de****C.V.**<http://www.epson.com.mx>**ECUADOR :****Epson Ecuador**<http://www.epson.com.ec>**U. S. A. :****Epson America, Inc.**<http://www.epson.com>**< SOUTH AMERICA >****ARGENTINA :****Epson Argentina S.R.L.**<http://www.epson.com.ar>**BRAZIL :****Epson do Brasil**<http://www.epson.com.br>**CHILE :****Epson Chile S.A.**<http://www.epson.cl>**COLOMBIA :****Epson Colombia Ltd.**<http://www.epson.com.co>**PERU :****Epson Peru S.A.**<http://www.epson.com.pe>**VENEZUELA :****Epson Venezuela S.A.**<http://www.epson.com.ve>

< ASIA & OCEANIA >

AUSTRALIA :

Epson Australia Pty. Ltd.
<http://www.epson.com.au>

CHINA :

Epson (China) Co., Ltd.
<http://www.epson.com.cn>

HONG KONG :

Epson Hong Kong Ltd.
<http://www.epson.com.hk>

INDIA :

Epson India Pvt., Ltd.
<http://www.epson.co.in>

INDONESIA :

PT. Epson Indonesia
<http://www.epson.co.id>

JAPAN :

Seiko Epson Co.
Toyoshina Plant
<http://www.epson.jp>

KOREA :

Epson Korea Co., Ltd.
<http://www.epson.co.kr>

MALAYSIA :

Epson Malaysia Sdn. Bhd.
<http://www.epson.com.my>

NEW ZEALAND :

Epson New Zealand
<http://www.epson.co.nz>

PHILIPPINES :

Epson Philippines Co.
<http://www.epson.com.ph>

SINGAPORE :

Epson Singapore Pte. Ltd.
<http://www.epson.com.sg>

TAIWAN :

Epson Taiwan
Technology & Trading Ltd.
<http://www.epson.com.tw>

THAILAND :

Epson (Thailand) Co.,Ltd.
<http://www.epson.co.th>