

The EPSON logo is displayed in a bold, sans-serif font.The Epson Projector logo features a stylized 'M' shape with the words 'ULTIA EDIA' and 'PROJECTOR' integrated into it.The model number 'EMP-52' is shown in a large, bold, white font.The title 'User's Guide' is written in a large, bold, white font.A button with the text 'Français' in a black, sans-serif font.A button with the text 'Deutsch' in a black, sans-serif font.A button with the text 'Italiano' in a black, sans-serif font.A button with the text 'Español' in a black, sans-serif font.A button with the text '中文(繁體)' in a black, sans-serif font.A button with the text '中文(简体)' in a black, sans-serif font.

Features of the Projector

Before Using the Projector

This section describes how to use the remote control and how to set up the projector and connect it to a computer and to video equipment.

Basic Operations

This section describes basic operations such as turning the projector on and off and adjusting the projected images.

Advanced Operations

This section describes useful functions for enhancing projection and how to use the configuration menus.

Troubleshooting

This section describes what to do if there is a problem with the projector.

Appendices

This section describes procedures for cleaning the projector, and other useful information.

Notations Used in This User's Guide

Understanding This User's Guide

Saving the User's Guide as a PDF File on a Computer

Unpacking the Projector

Part Names and Functions

Using the Configuration Menu Functions

Optional Accessories

Glossary

Index