

Index

"Uxx" refers to a page number of the EMP-735 User's Guide.

"Exx" refers to a page number of the EasyMP Operation Guide.

General Terms

13w3 port	U16
2RCA(L-R) stereo mini jack	
audio cable	U17, U23
5BNC port	U15

A

About Menu	U55
Advance	E17
Advanced Menu	U53
Air exhaust vent	U5
Air intake vent	U5
Analogue-RGB	U44, U55
Animation	E8, E15
Aspect ratio	U41
Audio Menu	U49
Audio-In port	U7
Auto Keystone	U31, U50
Auto Setup	U34, U45
Autorun	E11
A/V Mute	U39, U50, E27, E40

B

Background Color	E6
Battery holder	U86
BGM	E6
Brightness	U45, U46

C

CardPlayer	E20
Ceiling	U11, U53
Cell	E8
Cleaning the Air Filter	U85
Cleaning the Lens	U84
Cleaning the Projector Case	U84
Color	U46
Color Adjustment	U53
Color Mode	U37
Color Mode Prompt	U50
Colour temperature	U53
Component video	U21
Computer/Component Video port	U7
Connecting to a Computer	U13

Connecting to a Video Source	U20, U23
Continuous Play	E12
Continuous Play (Revive)	E34
Contrast	U45, U46, U48
Control panel	U6
Cool-down	U28, U62
Create a Scenario Easily	E13
Cross	U42

D

Display Conditions	E33
Display order	E34

E

Easy Menu	E22
EasyMP	U1, U48
Editing a Scenario	E28
Effects	E34
Eligible computers	U13
EMP Monitor	E41
EMP SlideMaker2	E4
Error data	E46
ESC/VP21	U95
E-Zoom	U42, E27

F

Focus	U30
Focus ring	U5
Foot adjustment	U32
Freeze	U40, E27, E40
Frequency	U55
Front adjustable foot	U5

G

Graphics files	E30
Guide mode	E22

H

HDTV	U97
Help function	U61
Highest image quality	E6

I

Image Quality	E6
---------------------	----

Image size U12
Indicators U5, U62
Input Signal.....U45, U47, U55
Inserting the Battery..... U86

J

JPEGE6

K

KeystoneU31, U33, U50

L

Lamp U55
Lamp cover U7
Lamp replacement period U87
Language..... U54
Link21L U54

M

Main menu U43
Manually Correcting
 Keystone Distortion U33
Menu U43
Mini D-Sub 15-pin Port U14
Mouse pointer U18

N

Network setupE39
No-Signal Msg. U50

O

Operating distance (Remote control) U10
Operating range (Remote control) U10
Operating temperature U99
Operation mode.....E33
Optional accessories U94
Overheating..... U63

P

Part Names and Functions U5
Playing a ScenarioE26
Port..... U7, U27
PositionU34, U44, U46
Power cable..... U25
Power indicator U5
Power inlet..... U7

PreviewE14
Projection U26
Projection angle U31
Projection distance U12
Projector Control.....E40
Projector Setup.....E38
Prompt..... U50

Q

Quick mode..... E22, E24

R

RCA video cable U20
Rear Proj. U11, U53
Refresh Rate..... U56
Remote control..... U8
Remote control light-emitting area U8
Remote control light-receiving area U5, U7
Replacing the Air Filter U91
Replacing the Lamp U88
Reset All Menu U57
Reset Lamp Timer U55, U90
Resized display U97
Resolution U56, U97
RGB U53

S

Scenario E4, E26
Scenario FolderE6
Scenario NameE6
Scenario PreviewE14
Scenario screen switching.....E27
Screen Size..... U12
Screen switching timeE34
Security lock U5
Sending a Scenario.....E11
Setting Menu..... U50
Setting Up the Projector..... U11
SharpnessU45, U46, U48
sit.....E11
Sleep Mode U51
Slideshow.....E31
SNMP.....E49
Speaker.....U7, U17, U23
Specifications..... U99
squeeze mode..... U41

sRGB..... U37
Standby condition U62
Standby Mode U54
Startup Screen U53
Stereo mini jack audio cable U17, U23
Stop playing a scenario E27
Storage temperature U99
Sub-menu U43
Supported Monitor Displays U97
Suspension bracket fixing point..... U7, U101
Sync U36, U44
SYNC Mode U56
SYNC Polarity U55
S-Video U21, U46, U55
S-Video port..... U7

T

Tint..... U46
Tone U49
Tracking U35, U44
Turning off..... U28

U

USB cable U18
USB connection setup..... U96
USB mouse U18
USB port U7
User's logo U92
User's Logo Menu U52
Using the Configuration
 Menu Functions U43
Using the Indicators U62

V

Video..... U46, U55
Video Menu U46
Video port U7
Video Signal U47, U55
Video Source..... U55
View Image..... E30
Volume..... U49

W

Warm-up U62
Warning indicator U5
Web browser E36

Wide-screen image U41
Wireless Mouse Function U18

Y

YCbCr/YPbPr U27, U46, U55

Z

Zoom ring U5