

"U-xx" refers to a page number of the User's Guide.

"E-xx" refers to a page number of the EasyMP Operation Guide.

"M-xx" refers to a page number of the EMP Monitor Operation Guide.

## Symbols

.bmp .....	E-28, E-43
.gif .....	E-43
.jpg .....	E-28, E-43
.mpg .....	E-28, E-43
.mrk .....	E-43
.png .....	E-43
.sit .....	E-36, E-43
.wav .....	E-28

## A

A/V cable .....	U-24, U-27
A/V Mute .....	U-50
Abs. Color Temp. ....	U-57, U-59
AC-3 .....	E-28, E-43
Advance .....	E-41
Air exhaust vent .....	U-7
Air filter .....	U-10
Air intake vent .....	U-10
Animation .....	E-28, E-40
Aspect ratio .....	U-51
[Audio] port .....	U-9, U-27
Authentication .....	E-16
Auto Keystone .....	U-62
Auto Setup .....	U-44, U-60

Automatic ESSID Search .....	E-25
Autorun .....	E-36

## B

Background Color .....	U-64, E-30
Background music .....	E-39
BGM .....	E-30
Blackboard .....	U-47, U-56, U-58
Brightness .....	U-56, U-58, E-4
Brightness Control .....	U-62
Buzzer for notice of termination .....	U-38

## C

Card slot .....	U-17
CardPlayer .....	E-42, E-44
Cell .....	E-30
Cleaning the Air Filter .....	U-99
Cleaning the Lens .....	U-99
Cleaning the Projector Surface .....	U-99
CMYK colour format .....	E-28, E-43
Color Intensity .....	U-58
Color Mode .....	U-47, U-56, U-58, E-4
Component video .....	U-25
Composite video .....	U-24
Computer cable .....	U-21, U-26

Computer Input .....	U-60, U-61
[Computer/Component Video] port .....	U-9
Connecting to a Computer .....	U-20
Connecting to a Video Source .....	U-24
Continuous Play .....	E-57
Contrast .....	U-56, U-58, E-4
Control Panel .....	U-8
Cool-down .....	U-38, U-77
Create a Scenario Easily .....	E-38
Cross .....	U-52

## D

Destination address .....	E-63
Direct Power ON .....	U-65
Display .....	U-64
Display Conditions .....	E-57
Display order .....	E-57
DPOF .....	E-43
Dynamic .....	U-47, U-56, U-58

## E

Easy Menu .....	E-46
EasyWeb .....	E-60
Editing a Scenario .....	E-52
Effect .....	E-57



Eligible computers ..... U-20  
 EMA ..... E-31  
 EMP Monitor ..... M-2  
 EMP SlideMaker2 ..... E-26, E-27  
 Encrypted Transmissions ..... E-17  
 Encryption ..... E-16  
 Encryption key ..... E-22  
 Entering Characters and Numerals ..... E-24  
 ESC/VP21 ..... U-113  
 "Extended" Menu ..... U-64  
 E-Zoom ..... U-52, E-4

## F

Firewall ..... E-16  
 Focus ..... U-40  
 Focus ring ..... U-7  
 Foot adjustment ..... U-42  
 Format ..... E-22  
 Freeze ..... U-51  
 Front adjustable foot ..... U-7

## G

Glossary ..... U-109  
 Group ..... E-9  
 Guide mode ..... E-46

## H

HDTV ..... U-115

Help function ..... U-73  
 High ..... U-62  
 Highest image quality ..... E-30

## I

If a Problem Notification is Sent by Mail ..... E-64  
 Image ..... E-28  
 "Image" Menu ..... U-56  
 Image Quality ..... E-30  
 Image size ..... U-16, U-40  
 Images and Movie Files ..... E-54  
 Indicators ..... U-7, U-75  
 "Info" Menu ..... U-67  
 Input Signal ..... U-67  
 Inserting the Batteries ..... U-12  
 IP Address ..... E-6  
 IP address of SMTP server ..... E-63  
 IP connect mode ..... E-6

## J

JPEG ..... E-30, E-43

## K

Key ID ..... E-22  
 Keystone ..... U-41, U-62

## L

Lamp cover ..... U-10

Lamp Hours ..... U-67  
 Lamp indicator ..... U-7, U-75  
 Lamp replacement period ..... U-100  
 Lamp-Hours Reset ..... U-68, U-103  
 Language ..... U-66  
 LEAP ..... E-19, E-23  
 Lens cover ..... U-7  
 Linear PCM ..... E-28, E-43  
 Living Room ..... U-47, U-56, U-58  
 Low ..... U-62

## M

Mail Notification Function ..... E-62  
 Main menu ..... U-55  
 Manually Correcting Keystone Distortion ... U-43  
 Menu ..... U-55  
 Message ..... U-64  
 Mini D-Sub 15-pin port ..... U-21  
 Monitoring and Controlling Projector ..... M-2  
 Mouse pointer ..... U-23  
 MPEG ..... E-43  
 MPEG-1 Layer 2 ..... E-28, E-43  
 MPEG2-PS ..... E-28, E-43

## N

Names and Functions of Each Icon ..... E-3  
 Network Screen ..... E-2  
 Network setup ..... E-61



Numeric buttons ..... U-11

## O

Operating distance (Remote control) ..... U-14

Operating range (Remote control) ..... U-14

Operating temperature ..... U-116

Operation ..... U-65

Operation During a Presentation ..... E-51

Operation Lock ..... U-62

Operation Mode ..... E-57

Optional accessories ..... U-108

Overheating ..... U-76

## P

Part Names and Functions ..... U-7

Password ..... E-23

Password Protect ..... U-31

Password Protect stickers ..... U-32

PC card ..... U-17

Play Movie ..... E-48

Play Slideshow ..... E-48

Playing a Scenario ..... E-50

Pointer ..... U-53

Pointer Shape ..... U-62

Port ..... U-9, U-37

Port Number ..... E-63

Position ..... U-44, U-60, U-61

Power cable ..... U-35

Power indicator ..... U-7, U-75

Power inlet ..... U-9

Power ON Protect ..... U-31

PowerPoint ..... E-28

Presentation ..... U-47, U-56, U-58, E-26, E-42

Preventing Unauthorised Access ..... E-18

Preview ..... E-39

Problem Solving ..... U-75

Progressive format ..... E-28, E-43

Projecting Images ..... U-36

Projecting Images and Movie Files ..... E-54

Projecting Scenarios ..... E-50

Projection ..... U-65

Projection angle ..... U-41

Projection distance ..... U-16

Projector Control ..... E-61

Projector Setup ..... E-61

PSK ..... E-23

## Q

Quick mode ..... E-46, E-48

## R

Rear adjustable foot ..... U-42

Refresh Rate ..... U-67

Register projector ..... M-3

Remote control ..... U-11, U-12, U-13, U-22

Remote control light-emitting area ..... U-11

Remote control light-receiving area ..... U-7, U-9

Repeat ..... E-37

Replacing the Air Filter ..... U-104

Replacing the Lamp ..... U-101

Request code ..... U-31

Reset All ..... U-68

"Reset" Menu ..... U-68

Resized display ..... U-115

Resolution ..... U-67, U-115

RGB Video ..... U-26

Rotating the Image ..... E-49

## S

Scenario Folder ..... E-30

Scenario Name ..... E-29

Scenario Preview ..... E-39

Scenarios ..... E-27

Screen size ..... U-16

Screen Switching ..... E-51

Screen switching time ..... E-57

Security lock ..... U-7

Sending a Scenario ..... E-36

Setting a Notification Event ..... E-63

"Setting" Menu ..... U-62

Setting Up the Projector ..... U-15

Sharpness ..... U-56, U-58

"Signal" Menu ..... U-60



Sleep Mode ..... U-65  
 Slideshow ..... E-28, E-55  
 SNMP ..... E-65  
 SNMP trap IP address ..... E-65  
 Source ..... U-67  
 Speaker ..... U-9, U-27, U-28  
 Specifications ..... U-116  
 Squeeze mode ..... U-51  
 sRGB ..... U-47, U-56, U-58  
 Standby Mode ..... U-66  
 Startup Screen ..... U-64  
 Stereo mini jack audio cable ..... U-27  
 StopPlaying ..... E-51  
 Storage temperature ..... U-116  
 Sub-menu ..... U-55  
 Supported Monitor Displays ..... U-115  
 Suspension bracket fixing point ..... U-10, U-117  
 S-Video ..... U-25, U-58, U-61, U-67  
 [S-Video] port ..... U-9  
 Sync ..... U-44, U-60  
 Sync. Info ..... U-67

## T

Temp indicator ..... U-7, U-75  
 Theatre ..... U-47, U-56, U-58  
 Tint ..... U-58  
 Toolbar ..... E-3  
 Tracking ..... U-44, U-45, U-60  
 Translucent screen ..... U-15

Turning the Projector Off ..... U-38

## U

USB cable ..... U-22, U-29  
 USB connection ..... U-114  
 USB mouse ..... U-22  
 [USB TypeA] port ..... U-9  
 [USB TypeB] port ..... U-9  
 User name ..... E-23  
 User's Logo ..... U-50, U-105  
 User's Logo Protect ..... U-32  
 Using the Configuration Menu Functions ..... U-55

## V

Video ..... U-67  
 Video Signal ..... U-61, U-67  
 [Video] port ..... U-9  
 View Image ..... E-48  
 Volume ..... U-48

## W

Web Browser ..... E-60  
 WEP ..... E-19  
 WEP encryption ..... E-22  
 Wide-screen Projection ..... U-51  
 Wireless LAN card ..... U-17  
 Wireless Mouse Function ..... U-22  
 WPA ..... E-19, E-23

## Z

Zoom ring ..... U-7

