


## Firmware Upgrade


The instructions below will guide you through the process of updating your product's firmware

### For Mac OSX


1, Double click on the downloaded firmware icon to begin the install process. The below screen will appear, click next to continue




2, Click on the "I agree" followed by clicking on Next.




3, Read the instructions carefully and follow any actions as directed, click Next to continue.




4, Select the connection method and click next to continue



5, The printer confirmation will appear next. In the event that you are unable to see the printer in the model name window, click find printer button. Once the printer is found click start to continue



6, The following window will then appear confirming that you want to begin the firmware update, click Ok to begin.



7, Click finish once the screen below appears and confirms the procedure is complete.

Epson Firmware Updater

123456789

Overall Progress:1/1

Current Progress:100%

Firmware File: FWC366TL.efu

Software	Version	Vendor Name
Firmware	1C.1C.BW22A7	

Update Printer List:

Status	Model Name
Update successful	Epson Stylus Photo PX820FWD

Detailed Information:

The firmware has been downloaded to your printer.  
Wait for the printer to turn off automatically.

Finish