

Supplemental Information for CD-ROMs

This booklet provides supplemental information about the Expression 1680 Scanner Software CD-ROM and other software CD-ROMs, and includes the following sections.

- ❑ Reading PDF Online Manuals
- ❑ Software Installation Instructions

Before installing TextBridge® Pro or Adobe® Photoshop® 5.0LE, read the PDF Online manuals included on the CD-ROMs. For instructions on how to view PDF documents, see “Reading PDF Online Manuals” on page 2.

Be sure to install Presto!™ PageManager for EPSON to take full advantage of your scanner’s Start Button feature.

Note:

- ❑ *Some manuals include instructions for the retail version of the software. There may be minor differences between the software described and the software on the CD-ROMs. Please read “Software Installation Instructions” on page 4 for more information about the installation procedure.*
- ❑ *In certain locations, some software may not be included.*

Reading PDF Online Manuals

The following applications include PDF files that function as online manuals:

- Presto! PageManager for EPSON
- TextBridge Pro
- Adobe Photoshop 5.0LE

Installing Acrobat Reader

To read PDF files, you need to install Acrobat Reader on your computer. Follow the directions below.

Windows

1. Insert the Expression 1680 Scanner Software CD-ROM into your CD-ROM drive.
2. In the dialog box that appears, select your preferred language.

If a dialog box does not automatically appear, double-click My Computer, then the CD-ROM drive icon, then double-click Cdsetup.exe, and select your preferred language.
3. Click the Add Software icon, then make sure that Acrobat Reader Ver.4.0 is listed with a check mark in the application list.

Note:

Some of the software is selected in the application list by default. If you want to read the PDF files without installing other applications, clear the check marks next to the applications you do not want to install.

4. Click the OK button.

Macintosh

1. Insert the Expression 1680 Scanner Software CD-ROM into your CD-ROM drive.
2. Double-click Reader Installer in the CD-ROM's Acrobat Reader\ English folder.

After installation, double-click any of the PDF files on the CD-ROM to read them.

Finding the PDF files

Windows

Presto! PageManager for EPSON

You need to install PageManager before you can read the online manual for it. See the next section for installation instructions. After installation, the online manual for PageManager, PageManager User's Manual, appears in the Presto! PageManager for EPSON folder.

TextBridge Pro

Insert the TextBridge Pro CD-ROM into your CD-ROM drive. The guided tour of TextBridge is a file named Guided Tour.exe located in the Tour folder. You may be asked to install QuickTime™ for Windows. Follow the on-screen instructions.

After installing TextBridge Pro, to read the online manual, click Start, point to Programs, point to TextBridge Pro 8.0, then click User Guide.

Adobe Photoshop 5.0LE

Insert the Photoshop CD-ROM into your CD-ROM drive. The online manual for Photoshop, User Guide.pdf, is located in the English folder. Other PDF files contain support information.

Macintosh

Presto! PageManager for EPSON

You need to install PageManager before you can access the PDF manual for it. See the next section for installation instructions. After installation, the online manual for PageManager, User's Guide.pdf, is located in the Presto! PageManager for EPSON folder.

TextBridge Pro

Insert the TextBridge® Pro CD-ROM into your CD-ROM drive. The online manual for TextBridge Pro, GettingStarted.pdf, is located in the TextBridge Pro - Documents\English folder.

Adobe Photoshop 5.0LE

Insert the Photoshop CD-ROM into your CD-ROM drive. The online manual for Photoshop, User Guide.pdf, is located in the English folder.

Software Installation Instructions

The following instructions explain how to install the software included on the Expression 1680 Scanner Software CD-ROM and other CD-ROMs. Installation instructions are also included in the software documentation.

Note:

There may be minor differences between the software described and what is on this CD-ROM. If the installation instructions in the software documentation differ from the following instructions, please follow the instructions below.

Installing the software

Windows

Programs on the Expression 1680 Scanner Software CD-ROM

You can install most of the programs on the CD-ROM from the EPSON Software Setup dialog box that appears on your screen after you insert the CD-ROM into your CD-ROM drive. See Chapter 3 of the *Expression 1600 Setup Guide* for details.

TextBridge Pro

1. Insert the TextBridge Pro CD-ROM in your CD-ROM drive.
2. In the dialog box that appears, select your preferred language.

If a dialog box does not automatically appear, double-click My Computer, then the CD-ROM drive icon, then double-click Setup.exe, and select your preferred language.

3. Follow the on-screen instructions.

Adobe Photoshop 5.0LE

1. Insert the Photoshop CD-ROM in your CD-ROM drive.
2. Double-click My Computer, then the CD-ROM drive icon, then double-click Setup.exe in English\Photosle, and follow the on-screen instructions.

Macintosh

Presto! PageManager for EPSON

Double-click Presto! PageManager Installer#1 in the Presto! PageManager\English\Presto! PageManager Disk1 folder which can be found inside the Expression 1680 Scanner Software CD-ROM folder.

TextBridge Pro

1. Insert the TextBridge Pro CD-ROM in your CD-ROM drive.
2. Double-click Install TextBridge® Pro in the TextBridge® Pro folder.
3. Select your preferred language and follow the on-screen instructions.

Adobe Photoshop 5.0LE

1. Insert the Photoshop CD-ROM in your CD-ROM drive.
2. Double-click Install Photoshop® LE in the English\Adobe Photoshop® 5.0LE folder. Then follow the on-screen instructions.