




















EB-696Ui










EN	Quick Start Guide	RO	Ghid de pornire rapidă
DE	Kurzanleitung	ET	Lühijuhend
FR	Guide de démarrage rapide	LV	Ātrās darba uzsākšanas pamācība
IT	Guida di avvio rapido	LT	Trumpas pradžios vadovas
ES	Guía de inicio rápido	EL	Οδηγός γρήγορης εκκίνησης
PT	Guia de Referência Rápida	TR	Hızlı Başlangıç Kılavuzu
NL	Introductiehandleiding	SL	Priločnik za hitri zagon
DA	Introduktion	HR	Kratke upute
FI	Pika-aloitusopas	MK	Прирачник брз почеток
NO	Hurtigveiledning	SR	Uputstvo za brz početak
SV	Snabbstartsguide	CA	Guia d'inici ràpid
CS	Úvodní příručka	RU	Руководство по быстрой установке
HU	Bevezetés	UK	Коротка інструкція "Початок роботи"
PL	Przewodnik szybkiego startu	KK	Қысқа іске қосу нұсқаулығы
SK	Stručná príručka	AR	دليل البداية السريعة
BG	Ръководство за бърз старт	FA	راهنمای سریع برای شروع بکار











1














3

















Easy Interactive Function



7







Auto Calibration





Drawing



PC Interactive





Printed in China
XX.XX-XX(XXX)



4132380