Understanding This Guide

You can carry out the following tasks by clicking on these buttons.

Displays the print window.

Searches for text.

Displays or hides bookmarks.

Moves to another page in the document (first/previous/next/last page).

Moves forward or back to the page that was last displayed. You can use this to return to the page you were viewing if you have jumped to a different page such as a reference page or the Glossary.

Click this button if the text or illustrations are too small to see easily. Move the pointer to the place you would like to view and then click the left mouse button to enlarge the document at that place.
If you hold down the [Ctrl] key when you click the left mouse button, the document viewing size will be reduced.

Acrobat Reader - [English.pdf]

File   Edit   Document   Tools   View   Window   Help

88%

Bookmark

Notations Used in T
Features of the Proj
Before Using the Pr
Part Names and
Front/Top
Control Pane
Rear
Base
Remote Cont
Before Using the
Using the Re
Installation
Setting Up th
Screen Size
Connecting to a
Eligible Com
Projecting Im
Using the Re
Connecting t
Connecting to a
Projecting Co
Projecting S-
Projecting Co
Projecting RG
Playing Sound fr
Preventing theft
When Passw
Setting Pass
Basic Operations

Problem Solving   77

■ Images are fuzzy or out of focus.

Check	Remedy
Has the focus been adjusted correctly?	Turn the focus ring on the projector to adjust the focus. ☛ p.37
Is the lens cover still attached?	Remove the lens cover. ☛ p.32
Is the projector at the correct distance?	The recommended projection distance range is 89–1050 cm (2.9–34.4 ft.). Set the projector up so that it is within this range. ☛ p.15
Is the keystone adjustment value too large?	Decrease the projection angle to reduce the amount of keystone correction. ☛ p.40
Has condensation formed on the lens?	If the projector is suddenly taken from a cold environment to a warm environment or if sudden ambient temperature changes occur, condensation may form on the surface of the lens, and this may cause the images to appear fuzzy. Set the projector up in the room approximately one hour before it is to be used. If condensation forms on the lens, turn the power off and wait for the condensation to disappear.

■ Interference or distortion appear in images.

Check	Remedy
Are the image signal format settings correct?	If signals from the [Computer1/Component Video1] port or the [Computer2/Component Video2] port are being projected, use the "Input Signal" menu command to set the signal format that matches the signal that is being projected from the connected equipment. "Image" - "Input Signal" ☛ p.52, p.55 If a composite video» or S-Video» source is connected to the projector, use the "Video Signal" menu command to select the signal format. "Image" - "Video Signal" ☛ p.56
Are the cables connected correctly?	Check that all of the cables required for projection are securely connected. ☛ p.16–p.24
Is an extension cable being used?	If an extension cable is used, electrical interference may affect the signals. Use the accessory cables and check if this helps.
Has the correct resolution been selected? Only when projecting computer images	Set the computer so that the signals that are output are compatible with this projector. "List of Supported Monitor Displays" p.100 ☛ Computer documentation
Have the "Sync.»" and "Tracking»" settings been adjusted correctly? Computer and RGB video signals only	Press the [Auto] button on the remote control to carry out automatic adjustment. If the images have not been adjusted correctly after using automatic adjustment, you can make the adjustments using the "Sync." and "Tracking" menus. ☛ p.42, p.43

78 of 107   11.69 x 8.26 in

Displays the page at actual size.

Displays the whole of a page in a single window.

Displays the page so that the width of the page is the same as the width of the window.

Click to jump to the TOP page.

Jumps to a page that contains a related topic or a more detailed explanation.

This is displayed when the contents continue from the previous page. Click to move to the previous page.

This is displayed when the contents continue on to the next page. Click to move to the next page.

[Bookmarks]
Click on the title of a section to jump to the first page for that section.

Indicates that an explanation of the underlined word or words in front of this symbol appears in the glossary of terms. Click to jump to the Glossary page.