

"U-xx" refers to a page number of the User's Guide.

"E-xx" refers to a page number of the EasyMP Operation Guide.

"M-xx" refers to a page number of the EMP Monitor Operation Guide.

Symbols

.bmp	E-29, E-44
.gif	E-44
.jpg	E-29, E-44
.mpg	E-29, E-44
.mrk	E-44
.png	E-44
.sit	E-37, E-44
.wav	E-29

A

A/V cable	U-24, U-27
A/V Mute	U-50
Abs. Color Temp.	U-57, U-59
AC-3	E-29, E-44
Advance	E-42
Air exhaust vent	U-7
Air filter	U-10
Air intake vent	U-10
Animation	E-29, E-41
Aspect ratio	U-51
[Audio] port	U-9, U-27
Authentication	E-17
Auto Keystone	U-62
Auto Setup	U-44, U-60

Automatic ESSID Search	E-26
Autorun	E-37

B

Background Color	U-64, E-31
Background music	E-40
BGM	E-31
Blackboard	U-47, U-56, U-58
Brightness	U-56, U-58, E-6
Brightness Control	U-62
Buzzer for notice of termination	U-38

C

Card slot	U-17
CardPlayer	E-43, E-45
Cell	E-31
Cleaning the Air Filter	U-99
Cleaning the Lens	U-99
Cleaning the Projector Surface	U-99
CMYK colour format	E-29, E-44
Color Intensity	U-58
Color Mode	U-47, U-56, U-58, E-6
Component video	U-25
Composite video	U-24
Computer cable	U-21, U-26

Computer Input	U-60, U-61
[Computer/Component Video] port	U-9
Connecting to a Computer	U-20
Connecting to a Video Source	U-24
Continuous Play	E-58
Contrast	U-56, U-58, E-6
Control Panel	U-8
Cool-down	U-77
Create a Scenario Easily	E-39
Cross	U-52

D

Destination address	E-64
Direct Power ON	U-65
Display	U-64
Display Conditions	E-58
Display order	E-58
DPOF	E-44
Dynamic	U-47, U-56, U-58

E

Easy Menu	E-47
EasyWeb	E-61
Editing a Scenario	E-53
Effect	E-58



Eligible computers U-20
 EMA E-32
 EMP Monitor M-2
 EMP SlideMaker2 E-27, E-28
 Encrypted Transmissions E-18
 Encryption E-17
 Encryption key E-23
 Entering Characters and Numerals E-25
 ESC/VP21 U-113
 "Extended" Menu U-64
 E-Zoom U-52, E-4, E-5

F

Firewall E-17
 Focus U-40
 Focus ring U-7
 Foot adjustment U-42
 Format E-23
 Freeze U-51
 Front adjustable foot U-7

G

Glossary U-109
 Group E-10
 Guide mode E-47

H

HDTV U-115

Help function U-73
 High U-62
 Highest image quality E-31

I

If a Problem Notification is Sent by Mail E-65
 Image E-29
 "Image" Menu U-56
 Image Quality E-31
 Image size U-16, U-40
 Images and Movie Files E-55
 Indicators U-7, U-75
 "Info" Menu U-67
 Input Signal U-67
 Inserting the Batteries U-12
 IP Address E-7
 IP address of SMTP server E-64
 IP connect mode E-7

J

JPEG E-31, E-44

K

Key ID E-23
 Keystone U-41, U-62

L

Lamp cover U-10


Lamp Hours U-67
 Lamp indicator U-7, U-75
 Lamp replacement period U-100
 Lamp-Hours Reset U-68, U-103
 Language U-66
 LEAP E-20, E-24
 Lens cover U-7
 Linear PCM E-29, E-44
 Living Room U-47, U-56, U-58
 Low U-62

M

Mail Notification Function E-63
 Main menu U-55
 Manually Correcting Keystone Distortion ... U-43
 Menu U-55
 Message U-64
 Mini D-Sub 15-pin port U-21
 Monitoring and Controlling Projector M-2
 Mouse pointer U-23
 MPEG E-44
 MPEG-1 Layer 2 E-29, E-44
 MPEG2-PS E-29, E-44

N

Names and Functions of Each Icon E-3
 Network Screen E-2
 Network setup E-62



Numeric buttons U-11

O

Operating distance (Remote control) U-14
 Operating range (Remote control) U-14
 Operating temperature U-116
 Operation U-65
 Operation During a Presentation E-52
 Operation Lock U-62
 Operation Mode E-58
 Optional accessories U-108
 Overheating U-76

P

Part Names and Functions U-7
 Password E-24
 Password Protect U-31
 Password Protect stickers U-32
 PC card U-17
 Play Movie E-49
 Play Slideshow E-49
 Playing a Scenario E-51
 Pointer U-53
 Pointer Shape U-62
 Port U-9, U-37
 Port Number E-64
 Position U-44, U-60, U-61
 Power cable U-35

Power indicator U-7, U-75
 Power inlet U-9
 Power ON Protect U-31
 PowerPoint E-29
 Presentation U-47, U-56, U-58, E-27, E-43
 Preventing Unauthorised Access E-19
 Preview E-40
 Problem Solving U-75
 Progressive format E-29, E-44
 Projecting Images U-36
 Projecting Images and Movie Files E-55
 Projecting Scenarios E-51
 Projection U-65
 Projection angle U-41
 Projection distance U-16
 Projector Control E-62
 Projector Setup E-62
 PSK E-24

Q

Quick mode E-47, E-49

R

Rear adjustable foot U-42
 Refresh Rate U-67
 Register projector M-3
 Remote control U-11, U-12, U-13, U-22
 Remote control light-emitting area U-11

Remote control light-receiving area U-7, U-9
 Repeat E-38
 Replacing the Air Filter U-104
 Replacing the Lamp U-101
 Request code U-31
 Reset All U-68
 "Reset" Menu U-68
 Resized display U-115
 Resolution U-67, U-115
 RGB Video U-26
 Rotating the Image E-50

S

Scenario Folder E-31
 Scenario Name E-30
 Scenario Preview E-40
 Scenarios E-28
 Screen size U-16
 Screen Switching E-52
 Screen switching time E-58
 Security lock U-7
 Sending a Scenario E-37
 Setting a Notification Event E-64
 "Setting" Menu U-62
 Setting Up the Projector U-15
 Sharpness U-56, U-58
 "Signal" Menu U-60

Sleep Mode U-65
Slideshow E-29, E-56
SNMP E-66
SNMP trap IP address E-66
Source U-67
Speaker U-9, U-27, U-28
Specifications U-116
Squeeze mode U-51
sRGB U-47, U-56, U-58
Standby Mode U-66
Startup Screen U-64
Stereo mini jack audio cable U-27
StopPlaying E-52
Storage temperature U-116
Sub-menu U-55
Supported Monitor Displays U-115
Suspension bracket fixing point U-10, U-118
S-Video U-25, U-58, U-61, U-67
[S-Video] port U-9
Sync U-44, U-60
Sync. Info U-67

T

Temp indicator U-7, U-75
Theatre U-47, U-56, U-58
Tint U-58
Toolbar E-3
Tracking U-44, U-45, U-60
Translucent screen U-15

Turning the Projector Off U-38

U

USB cable U-22, U-29
USB connection U-114
USB mouse U-22
[USB TypeA] port U-9
[USB TypeB] port U-9
User name E-24
User's Logo U-50, U-105
User's Logo Protect U-32
Using the Configuration Menu Functions U-55

V

Video U-67
Video Signal U-61, U-67
[Video] port U-9
View Image E-49
Volume U-48

W

Web Browser E-61
WEP E-20
WEP encryption E-23
Wide-screen Projection U-51
Wireless LAN card U-17
Wireless Mouse Function U-22
WPA E-20, E-24

Z

Zoom ring U-7

