

بإمكانك تنفيذ المهام التالية بالنقر على هذه الأزرار.



عرض نافذة الطباعة.



للبحث عن نص.



تعمل على إظهار أو إخفاء الإشارات المرجعية.



لإنتقال إلى صفحة أخرى في الوثيقة (الصفحة الأولى/السابقة/التالية/الأخيرة).



انقر هنا للانتقال للأمام أو الخلف إلى آخر صفحة تم عرضها يمكنك استخدام هذا الرمز للرجوع إلى الصفحة التي كنت تستعرضها في حالة الانتقال إلى صفحة مختلفة كصفحة مرجعية على سبيل المثال.



انقر على هذا الزر إذا كان النص أو الأشكال التوضيحية صغيرة جدًا بحيث لا يمكن رؤيتها بسهولة. حرك المؤشر إلى الموضع الذي تريده مشاهدته ثم انقر زر الماوس الأيسر لتكبير الوثيقة في ذلك الموضع.

إذا أتيحت المفتاح [Ctrl] مضغوطاً عند النقر على زر الماوس الأيسر، يتم تصغير حجم مشاهدة الوثيقة.

**Problem Solving**

77

Check	Remedy
Has the focus been adjusted correctly?	Turn the focus ring on the projector to adjust the focus. <a href="#">p.37</a>
Is the lens cover still attached?	Remove the lens cover. <a href="#">p.32</a>
Is the projector at the correct distance?	The recommended projection distance range is 89–1050 cm (2.9–34.4 ft.). Set the projector up so that it is within this range. <a href="#">p.15</a>
Is the keystone adjustment value too large?	Decrease the projection angle to reduce the amount of keystone correction. <a href="#">p.40</a>
Has condensation formed on the lens?	If the projector is suddenly taken from a cold environment to a warm environment or if sudden ambient temperature changes occur, condensation may form on the surface of the lens, and this may cause the images to appear fuzzy. Set the projector up in the room approximately one hour before it is to be used. If condensation forms on the lens, turn the power off and wait for the condensation to disappear.

  

Check	Remedy
Are the image signal format settings correct?	If signals from the [Computer1/Component Video1] port or the [Computer2/Component Video2] port are being projected, use the "Input Signal" menu command to set the signal format that matches the signal that is being projected from the connected equipment. "Image" - "Input Signal" <a href="#">p.52, p.55</a> If a composite video or S-Video source is connected to the projector, use the "Video Signal" menu command to select the signal format. "Image" - "Video Signal" <a href="#">p.56</a>
Are the cables connected correctly?	Check that all of the cables required for projection are securely connected. <a href="#">p.16-p.24</a>
Is an extension cable being used?	If an extension cable is used, electrical interference may affect the signals. Use the accessory cables and check if this helps.
Has the correct resolution been selected?	Set the computer so that the signals that are output are compatible with this projector. "List of Supported Monitor Displays" <a href="#">p.100</a> Computer documentation
Have the "Sync." and "Tracking" settings been adjusted correctly?	Press the [Auto] button on the remote control to carry out automatic adjustment. If the images have not been adjusted correctly after using automatic adjustment, you can make the adjustments using the "Sync." and "Tracking" menus. <a href="#">p.42, p.43</a>
Computer and RGB video signals only	

عرض الصفحة بالحجم الفعلي.



عرض الصفحة بحجم الشاشة الكاملة.



عرض الصفحة بحيث يكون عرضها متساوياً لعرض النافذة.



انقر للقفز إلى الصفحة الرئيسية .TOP

[الإشارات المرجعية]  
انقر على عنوان القسم للقفز إلى الصفحة الأولى من ذلك القسم.

عمل على الانتقال إلى صفحة تحتوى على موضوع ذي صلة أو شرح أكثر تفصيلاً. عندما تكون الحروف باللون الأزرق، انقر لعرض الصفحة أو الدليل المراجع.